HITACHI

Inspire the Next

PLASMA TELEVISION

Operating Guide for 42HDT52, 42HDT52A and 55HDT52

IMPORTANT SAFETY INSTRUCTIONS 2-3
FIRST TIME USE 4-22
THE REMOTE CONTROL 23-41
ON-SCREEN DISPLAY 42-90
USEFUL INFORMATION 91-98
END USER LICENSE AGREEMENT FOR HITACHI DTV SOFTWARE 99
APPENDIXES 100-101
INDEX 102

ENERGY STAR

As an Energy Star® Partner, Hitachi, Ltd. has determined that this product meets the Energy Star® guidelines for energy efficiency.

TV GUIDE

ULTRAVISION

Important Safety Instructions

SAFETY POINTS YOU SHOULD KNOW ABOUT YOUR HITACHI PLASMA TELEVISION

Our reputation has been built on the quality, performance, and ease of service of **HITACHI** plasma televisions.

Safety is also foremost in our minds in the design of these units. To help you operate these products properly, this section illustrates safety tips which will be of benefit to you. Please read it carefully and apply the knowledge you obtain from it to the proper operation of your **HITACHI** plasma television.

Please fill out your warranty card and mail it to **HITACHI**. This will enable **HITACHI** to notify you promptly in the improbable event that a safety problem should be discovered in your product model.

Follow all warnings and instructions marked on this plasma television.

CAUTION
RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK).
NO USER SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of a sufficient magnitude to constitute a risk of electric shock to a person.

The exclamation point within an equilateral triangle, is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

READ BEFORE OPERATING EQUIPMENT

Follow all warnings and instructions marked on this plasma television.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer’s instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use the attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Televisions are designed to comply with the recommended safety standards for tilt and stability. Do not apply excessive pulling force to the front, or top, of the cabinet which could cause the product to overturn resulting in product damage and/or personal injury.
16. Follow instructions for wall, shelf or ceiling mounting as recommended by the manufacturer.
17. An outdoor antenna should not be located in the vicinity of overhead power lines or other electrical circuits.
18. If an outside antenna is connected to the receiver be sure the antenna system is grounded so as to provide some protection against voltage surges and built up static charges. Section 810 of the National Electric Code, ANSI/NFPA No. 70-1984, provides information with respect to proper grounding for the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding connectors, location of antenna-discharge unit, connection to grounding electrodes and requirements for the grounding electrode.


NEC National Electric Code
Antenna lead-in wire
Antenna discharge unit (NEC Section 810-20)
Ground clamp
Grounding conductors (NEC Section 810-21)
Electric service equipment
Power service grounding electrode system (NEC Art 250 Part H)
Ground clamps

Note to the CATV system installer: This reminder is provided to call the CATV system installer’s attention to Article 820-44 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

Important Safety Instructions

Power source
This plasma television is designed to operate on 120 volts 60 Hz, AC current. Insert the power cord into a 120 volt 60 Hz outlet.

To prevent electric shock, do not use the plasma television's (polarized) plug with an extension cord, receptacle, or other outlet unless the blades and ground terminal can be fully inserted to prevent blade exposure.

Never connect the plasma television to 50 Hz, direct current, or anything other than the specified voltage.

Caution

Never remove the back cover of the plasma television as this can expose you to very high voltages and other hazards. If the television does not operate properly, unplug the plasma television and call your authorized dealer or service center.

Caution
Adjust only those controls that are covered in the instructions, as improper changes or modifications not expressly approved by **HITACHI** could void the user's warranty.

Warning
- To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
- The plasma television should not be exposed to dripping or splashing and objects filled with liquids, such as vases, should not be placed on the television.

Modifications
The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Hitachi America, Ltd. Home Electronics Division may void the user's authority to operate the equipment.

Note
This plasma television will display television closed captioning, (CC or), in accordance with paragraph 15.119 and 15.122 of the FCC rules.

Public viewing of copyrighted material
Public viewing of programs broadcast by TV stations and cable companies, as well as programs from other sources, may require prior authorization from the broadcaster or owner of the video program material.

This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited consumer uses only unless otherwise authorized by Macrovision. Reverse engineering or disassembly is prohibited.

Note
This digital television is capable of receiving analog basic, digital basic and digital premium cable television programming by direct connection to a cable system providing such programming. A CableCARD provided by your cable operator is required to view encrypted digital programming. Certain advanced and interactive digital cable services such as video-on-demand, a cable operator's enhanced program guide and data-enhanced television services may require the use of a set-top box. For more information call your local cable company.

Note
- There are no user serviceable parts inside the plasma television.
- Model and serial numbers are indicated on back side of the plasma television.

Prevention of screen damages
Continuous on-screen displays such as video games, stock market quotations, computer generated graphics, and other fixed (non-moving) patterns can be permanently imprinted onto your TV screen. Such "**SCREEN DAMAGES**" constitute misuse and are **NOT COVERED** by your **HITACHI** Factory Warranty.

Lead Notice
This product contains lead. Dispose of this product in accordance with applicable environmental laws. For product recycling and disposal information, contact your local government agency or **www.eRecylcle.org** (in California), the Electronic Industries Alliance at **www.eiae.org** (in the US) or the Electronic Product Stewardship Canada at **www.epsc.ca** (in Canada). **FOR MORE INFORMATION, CALL 1-800-HITACHI.**

Accessories

Check to make sure you have the following accessories before disposing of the packing material.

❶ Remote Control



❷ Two “AA” size, 1.5V batteries



❸ Power Cord

❹ 2 IR Mouse Cables or G-LINK Cables



❺ Table Top Stand (42” models only)



❻ Cleaning Cloth



❼ Power Swivel Cable (42” models only)

❽ 2 Ferrite Core (see page 13)



Note: Please visit our website for optional accessories for the 55” models.

For U.S. models:
For optional accessories, please access our web site at: **www.hitachi.us/tv**

CAUTION:

1. *Ceiling mounting is not recommended. Mounting the panel on the ceiling does not provide adequate ventilation for the electronics or proper support for the front glass panel. This plasma television product is designed for a maximum tilting angle of 45 degrees from vertical.*
2. *This stand for use only with Hitachi 42HDT52 and 42HDT52A. use with other apparatus is capable of resulting in instability causing possible injury. See important marking located on bottom of stand.*

❶ Remote Control Unit CLU-3851WL (Part No. HL02065).
❷ Two “AA” size, 1.5V batteries (P# FQ00021).
❸ Power Cord (P# EV01841).
❹ Two IR Mouse cables (P# EY01641).
❺ Table Top Stand (P# QJ01831K).
❻ Cleaning Cloth (P# MS00931).
❼ Power Swivel Cable (P# EW08431).
❽ 2 (2 pcs.) Ferrite Core (P#2169513).

REMOTE CONTROL BATTERY INSTALLATION AND REPLACEMENT

1. Open the battery cover of the remote control by pushing down and sliding the back cover off.
2. Insert two new “AA” size batteries for the remote control. When replacing old batteries, push them towards the springs and lift them out.
3. Match the batteries to the (+) and (-) marks in the battery compartment.
4. Replace the cover.

BOTTOM VIEW
(Remote Control)



Press down and slide back to remove.

CAUTION: *Do not insert batteries with the ‘+’and ‘-’ polarities reversed as this may cause the batteries to swell or rupture resulting in leakage.*

How To Set Up Your New Hitachi Plasma Television

To take measures to prevent the Plasma Television from tipping over and prevent possible injury it is important to mount the unit in a stable and flat surface.

Securing to a table-top

1. Using wood screws (two) fasten the set to the clamping screw holes on the rear of the Plasma Display stand as shown below.
2. Using commercially available wood screws, secure the set firmly in position.



Securing to a Wall

1. Keep the Plasma television 4 inches away from the wall except when mounted using the wall mount bracket.
2. Secure the television to the wall as shown in fig. (a) or (b).



	A	B
42”	4 in.	12 in.
	10 cm	30 cm
55”	4 in.	16 in.
	10 cm	39 cm

NOTES:

1. *Do not block the ventilation holes of the Plasma Television. Blocking the ventilation holes might cause fire or defect.*
2. *In case of an abnormal symptom, unplug the AC cord.*
3. *If you purchased the wall mount bracket option, please ask for professional installer. Do not install by yourself.*
4. *If the Power Swivel feature will not be used, the Plasma television should be secured to the wall as shown in fig. (a).*
5. *If the Power Swivel feature will be used, the Plasma television should be secured to the wall as shown in fig. (b). The wires need to be long enough to allow the television to turn 30˚ to the left and right.*

Caution when moving the main unit

As this product is heavy, whenever it is moved, two people are required to transport it safely. Whenever the unit is moved it should be lifted forward using the top and base on both sides of the Television for stability. When moving the Television, lift the handles (42” models), support the top frame (55” models) and the bottom frame as shown below. Do not grab the speakers or the back cover when lifting.



42” 55”

ANTENNA

Unless your Plasma Television is connected to a cable TV system or to a centralized antenna system, a good outdoor color TV antenna is recommended for best performance. However, if you are located in an exceptionally good signal area that is free from interference and multiple image ghosts, an indoor antenna may be sufficient.

LOCATION

Select an area where sunlight or bright indoor illumination will not fall directly on the picture screen. Also, be sure that the location selected allows a free flow of air to and from the perforated back cover of the set. In order to prevent an internal temperature increase, maintain a space of 10 cm (4 inches) from the sides/back of the Television, and 30 cm (12 inches) from the top of the television to the wall. To avoid cabinet warping, cabinet color changes, and increased chance of set failure, do not place the TV where temperatures can become excessively hot, for example, in direct sunlight or near a heating appliance, etc.



CONNECT POWER SWIVEL CABLE

Connect one end of cable (Arrow mark facing left) to the swivel slot of the Plasma Rear Panel. Connect the other end (Arrow mark facing front)to the swivel slot of the Table Top Stand.



TURNING RADIUS

The maximum turning radius is 30˚ (left and right). Do not place any objects on the path of the monitor when using the power swivel feature.



	C	D
42”	12 in.	12 in.
	30 cm	30 cm
55”	15.26 in.	16.46 in.
	38.77 cm	41.8 cm

NOTE: *The Table Top Stand and Power Swivel cable for model 55HDT52 are not included (Optional).*

How to set up your new HITACHI Plasma Television

VIEWING

The best picture is seen by sitting directly in front of the TV and about 10 to 18 feet from the screen.

During daylight hours, reflections from outside light may appear on the screen. If so, drapes or screens can be used to reduce the reflection or the TV can be located in a different section of the room.

If the TV's audio output will be connected to a Hi-Fi system's external speakers, the best audio performance will be obtained by placing the speakers equidistant from each side of the receiver cabinet and as close as possible to the height of the picture screen center. For best stereo separation, place the external speakers at least four feet from the side of the TV, place the surround speakers to the side or behind the viewing area. Differences in room sizes and acoustical environments will require some experimentation with speaker placement for best performance.





ANTENNA CONNECTIONS TO REAR JACK PANEL

VHF (75-Ohm) antenna/CATV (Cable TV)
When using a 75-Ohm coaxial cable system, connect **CATV** coaxial cable to the CABLE (75-Ohm) terminal. If you have an antenna, connect the coaxial cable to the **AIR** terminal.

VHF (300-Ohm) antenna/UHF antenna
When using a 300-Ohm twin lead from an outdoor antenna, connect the **VHF** or **UHF** antenna leads to screws of the **VHF** or **UHF** adapter. Plug the adapter into the antenna terminal on the TV.



When both VHF and UHF antennas are connected
Attach an optional antenna cable mixer to the TV antenna terminal, and connect the cables to the antenna mixer. Consult your dealer or service store for the antenna mixer.



NOTE: *Connecting a 300-Ohm twin lead connector may cause interference. Using a 75-Ohm coaxial cable is recommended.*

Hook-up Cables and Connectors

Most video/audio connections between components can be made with shielded video and audio cables that have phono connectors. For best performance, video cables should use 75-Ohm coaxial shielded wire. Cables can be purchased from most stores that sell audio/video products. Below are illustrations and names of common connectors. Before purchasing any cables, be sure of the output and input connector types required by the various components and the length of each cable.

300-Ohm Twin Lead Cable
This outdoor antenna cable must be connected to an antenna adapter (300-Ohm to 75-Ohm).



Phono Connector
Used on all standard video and audio cables which connect to inputs and outputs located on the television's rear jack panel and side control panel.

"F" Type 75-Ohm Coaxial Antenna Connector
For connecting RF signals (antenna or cable TV) to the antenna jack on the television.

S-Video (Super Video) Cable
This cable is used on camcorders, VCRs and laser-disc players with an S-Video feature in place of the standard video cable to produce a high quality picture.

Optical Cable
This cable is used to connect to an audio amplifier with an Optical Audio In jack. Use this cable for the best sound quality.



HDMI Cable
This cable is used to connect your external devices such as Set-Top-Boxes or DVD players equipped with an **HDMI** output connection to the TV's **HDMI** input.



Stereo Cable (3.8mm plug to 3.5mm plug)
Used to connect equipment with mini stereo audio jack to the left and right audio inputs on the rear and side panels.

USB Cable
This cable is used to connect your digital camera to the Photo Input in the side of the Plasma television.

IR Mouse Cable/G-LINK Cable (Provided)
Connect the IR Mouse to the IR Blaster output of your Plasma Television when A/V Network is used. You must place the IR Mouse in front of the corresponding IR window of your cable box and VCR. This connection allows your TV, and the TV Guide On Screen™ system, to control your cable box and/or VCR.



Power Swivel Cable (Provided with 42" Models)
This cable is used to connect the swivel stand to the rear panel of the Plasma Television.

IEEE1394 Cable
This cable is used to connect your digital television to external digital devices.This cable will carry both the video and audio information.

Sub-Woofer Cable
Used to connect the Sub-Woofer Out to the Sub-Woofer Input of an audio amplifeier (not included).



Quick Reference Remote Control Buttons and Functions

In addition to controlling all of the functions on your HITACHI Plasma TV, the new remote control is designed to operate different types of devices, such as, DVD Players, CBL (Cable Boxes), set-top-boxes, satellite receivers, and VCRs. The remote control must be programmed to control the chosen device. Please see pages 23-41 for a complete description of all features and programming of the Remote Control.

POWER BUTTON
(TV, DVD, CBL, STB, PVR/VCR, AMP/CD)
Turns the selected device on and off.

MODE INDICATOR
Turns on or blinks to show remote control mode when the SOURCE ACCESS buttons are pressed.

SOURCE ACCESS BUTTONS
(TV, DVD, CBL, STB, PVR/VCR, AMP/CD)
Changes the mode of the Universal Remote Control to control the device selected.

ASPECT BUTTON
(TV)
Changes the aspect ratio of the TV.

DAY/NIGHT
(TV)
Toggles picture mode settings between DAY and NIGHT mode.

MENU BUTTON
(TV, DVD, CBL, STB, PVR/VCR)
Accesses the OSD menu system.

CURSOR PAD/SELECT BUTTON
(TV, DVD, CBL, STB, PVR/VCR)
The Cursor Pad is used as a cursor to navigate through the OSD and INPUT menu systems. The Select button is used to Select/Activate highlighted menu items.

INFO BUTTON
(TV, STB, CBL, PVR)
Displays various information on the screen, such as channel information.

VOLUME WHEEL
(TV, AMP/CD)
Scroll up and down to adjust the audio level of your TV. Push down on the wheel to mute.

NUMERIC BUTTONS
(TV, DVD, CBL, STB, PVR/VCR, AMP/CD)
Used to manually enter the TV channel, and used for numeric entry when navigating through the OSD, INPUTS, and AV NET menu systems.

(-) BUTTON
(TV,STB)
The (-) button is used when the remote is in Set-Top-Box (STB) mode or when the TV uses a digital input.



DVD/VCR CONTROL BUTTONS
(DVD, PVR/VCR, AMP/CD)
Controls the functions of your VCR, DVD and audio devices.

PAUSE BUTTON
(TV,PVR/VCR, DVD, AMP/CD)
Press to show and change the Freeze mode of the TV. Also used to pause other devices when the remote is in DVD, PVR/VCR, or AMP/CD mode.

PIP CONTROL BUTTONS
(TV)
Press to show and change the Picture-in-Picture mode.

GUIDE BUTTON
(TV, STB, CBL, PVR)
Accesses the TV Guide On Screen™ system (see page 54) of the TV or the program guide of other devices.

EXIT BUTTON
(TV, CBL, STB, PVR/VCR)
Exits out of the OSD, INPUTS or AV NET menu systems if their menu is displayed.

LAST CHANNEL BUTTON
(TV, CBL, STB, PVR)
Switches between the current and last channel viewed.

INPUTS BUTTON
(TV, AMP)
Accesses the INPUTS menu system.

CHANNEL WHEEL
(TV, CBL, STB, PVR/VCR, AMP/CD)
Scroll up or down to change channel. Push down on the wheel to access (FAV) Favorite Channel mode. (Favorite channel is only available for TV mode.)

LIGHT BUTTON
(TV, CBL, STB, PVR)
Press to use the back light feature. Can also be used to change backlight mode.

LEGEND

TV – Television
CBL – Cable Box
STB – Set-Top-Box
VCR – Video Cassette Recorder/Player
DVD – Digital Video Disc Player
SAT – Satellite Receiver

NOTES:

1. *The TV's remote control sensor is located on the right bottom portion of the TV screen. To control TV functions, please point the remote control directly at the remote control sensor for best results.*
2. ***VCR** precode is included in the **PVR** mode.*
3. *CD precode is included in the AMP mode.*
4. *Pressing any button will illuminate the backlight for 4 seconds.*

Front/Rear/Side Panel Controls

FRONT VIEW



REAR/SIDE VIEW



① **SIDE POWER button**
Press this button to turn the Plasma Television ON/OFF. It can also be turned ON/OFF by remote control. The "MAIN POWER" button must be at stand-by mode.

② **MENU/SELECT button**
This button allows you to enter the MENU, making it possible to set TV features to your preference without using the remote. This button also serves as the SELECT button when in MENU mode.

③ **PHOTO INPUT**
Insert USB cable from your Digital Camera, USB memory or memory card USB drive to view your digital still pictures (see pages 27 and 28).

④ **INPUT/EXIT button**
Press this button to access the INPUT menu. Press again to exit the MENU mode.

⑤ **CHANNEL selector**
Press these buttons until the desired channel appears in the top right corner of the TV screen. These buttons also serve as the cursor down (▼) and up (▲) buttons when in MENU mode.

⑥ **VOLUME level**
Press these buttons to adjust the sound level. The volume level will be displayed on the TV screen. These buttons also serve as the cursor left (◀) and right (▶) buttons when in MENU mode.

NOTE: *The Rear View of the 55" model is slightly different from the 42" models. One of the differences are the handles that are only present on the 42" models.*

⑦ **POWER button**
Display Monitor "MAIN POWER" button
This power button is for the complete system, and must be turned ON/OFF manually. It is recommended to leave the "MAIN POWER" to ON condition (lights red) for stand-by mode.



The Main Power button is located on the broadside bottom, under the label "MAIN POWER".

NOTE: *When the "MAIN POWER" button is set to OFF or the TV is unplugged, the clock will stop and may eventually reset itself.*

Front/Rear/Side Panel Controls

⑧ **POWER light indicator**
To turn the monitor ON, press the main power switch located on the lower right side of the monitor. A red stand-by indicator lamp located on the lower right corner of the front bezel will illuminate. The Plasma TV is now ready for remote ON/OFF operation.

Indicating Lamp	Power Status	Operating
Off	Off	When the main power switch is set to OFF.
Lights Red	Off (Stand-by)	When the main power switch on the display monitor is ON.
Lights Green	On	Display monitor MAIN POWER is ON.
Lights Orange	Off (Power Saving)	Display monitor MAIN POWER is ON with no signal input except antenna (no sync. signal).

⑨ **REMOTE CONTROL sensor**
Point your remote at this area when selecting channels, adjusting volume, etc.

⑨ **LEARNING AV NET sensor**
Point your equipment's remote control at this area while using the AV NET Learning Wizard.

⑩ **SIDE INPUT JACKS (for VIDEO: 5)**
Use these audio/video jacks for a quick hook-up from a camcorder or VCR to instantly view your favorite show or new recording. Press the INPUTS button then use the CURSOR PAD and the SELECT button on the remote control to select INPUT 5. If you have mono sound, insert the audio cable into the left audio jack.

⑪ **IEEE1394 (DV Input)**
This input provides a digital interface for your external digital devices such as your digital video (DV) camcorder.

NOTES:
1. *Your HITACHI Plasma TV will appear to be turned OFF (lights orange) if there is no video input when VIDEO: 1, 2, 3, 4 and 5. Check the Power Light to make sure the Display Monitor is turned off or in Stand-by mode (lights red) when not in use.*
2. *Remote Control can not turn ON/OFF the "MAIN POWER" of the display monitor.*

Rear Panel Connections

① **Antenna Input**
The remote control allows you to switch between two separate 75-Ohm RF antenna inputs, CABLE and AIR.

② **Audio/Video INPUTS 1, 2, 3 and 4**
By using the INPUTS button, the CURSOR PAD (▲ and ▼), and the SELECT button or CURSOR PAD ► of the remote control, you can select each video source. Use the audio and video inputs to connect external devices, such as VCRs, camcorders, laserdisc players, DVD players etc. (if you have mono sound, insert the audio cable into the left audio jack).

③ **MONITOR OUT & HI-FI AUDIO OUT**
These jacks provide fixed and variable audio and video signals (CABLE/AIR, INPUT 1, 2 and 5) which are used for recording. Use the S-VIDEO Output for high quality video output. Component signal to INPUT 3 and 4, and HDMI inputs will not have monitor output.

④ **Optical Out (Digital Audio)**
This jack provides Digital Audio Output for your audio device that is Dolby® Digital and PCM compatible, such as an audio amplifier.

NOTE: **Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.*

⑤ **S-VIDEO INPUTS 1 and 2**
INPUTS 1 and 2 provide S-VIDEO (Super Video) jacks for connecting equipment with S-VIDEO output capability.

NOTE:
1. *You may use VIDEO, HDMI or S-VIDEO inputs to connect to INPUT 1 and 2, but only one of these inputs may be used at a time.*
2. *S-VIDEO output may be used for recording, only when the input is of S-VIDEO type.*

⑥ **HDMI INPUTS 1 and 2 (High Definition Multimedia Interface)**
ABOUT HDMI – **HDMI** is the next-generation all digital interface for consumer electronics. **HDMI** enables the secure distribution of high-definition video and multi-channel audio in a single cable. Because digital television (DTV) signals remain in digital format, **HDMI** assures that pristine high-definition images retain the highest video quality from the source all the way to your television screen.

Use the **HDMI** input for your external devices such as Set-Top-Boxes or DVD players equipped with an **HDMI** output connection.

***HDMI**, the **HDMI** logo and High-Definition Multimedia Interface are trademarks or registered trademarks of **HDMI** Licensing LLC.*



NOTE:
1. *The **HDMI** input is not intended for use with personal computers.*
2. *Only DTV formats such as **1080i, 720p, 480i** and **480p** are available for **HDMI** input.*

⑦ **Component: Y-PBPR Inputs**
INPUTS 3 and **4** provide Y-PBPR jacks for connecting equipment with this capability, such as a DVD player or Set Top Box. You may use composite video signal for both inputs.

NOTE:
1. *Do not connect composite **VIDEO** and **S-VIDEO** to **INPUT 1, 2** or **5** at the same time. **S-VIDEO** has priority over **VIDEO** input.*
2. *Your component outputs may be labeled Y, B-Y, and R-Y. In this case, connect the components B-Y output to the TV's PB input and the components R-Y output to the TV's PR input.*
3. *Your component outputs may be labeled Y-CBCR. In this case, connect the component CB output to the TV's PB input and the component CR output to the TV's PR input.*
4. *It may be necessary to adjust **TINT** to obtain optimum picture quality when using the Y-PBPR inputs (see page 44).*
5. *To ensure no copyright infringement, the **MONITOR OUT** output will be abnormal, when using the Y-PBPR jacks.*
6. ***INPUT 3** and **INPUT 4** (Y/VIDEO) can be used for composite video and component video input.*

⑧ **IR Blaster/G-LINK**
This jack provides IR output to your external components (VCR, Cable box, DVD player, etc.). With this connection, your external components can automatically be controlled by the A/V network feature. This connection will allow you to control the external components with your Plasma Television's remote control in TV mode. The G-LINK connection will enable the TV Guide On Screen™ recording feature.

⑨ **For Service Use Only**
Do not connect anything to this terminal. Specifically for Service use only.

Rear Panel Connections

⑩ **Subwoofer Out**
Connect this SUB WOOFER OUT output to the external audio component input using the sub woofer cable (not provided).

⑪ **Upgrade Card**
This card slot is for future software upgrades. HITACHI will notify you if a software upgrade is required for your TV. In order to receive written notification, please complete and return your warranty card.

⑫ **To Power Swivel Connector**
Connects to the Power Swivel Table Top Stand.

⑬ **IEEE1394 (DV INPUT)**
These jacks provide a digital interface for your external digital devices, such as a Digital VCR (D-VHS), Set-Top-Box or Digital Camcorder by means of a single cable (see page 19). When using IEEE1394 connections, you enable video and audio digital data exchange between a compatible device. This connection also enables you to control basic equipment functions (such as VCR play, rewind, fast forward, stop, etc.) from your TV On-Screen Display.

⑭ **CableCARD Slot**
This slot is for the CableCARD that will be provided by your local cable operator to gain access to chosen cable channels. Please call your local cable operator if this service is available before requesting a CableCARD (also known as Point of Deployment (POD) module).

1. Connect a coaxial cable to cable terminal of the Rear Panel Jacks.
2. Insert the CableCARD into the slot (Top of card should be facing towards you as shown below).



NOTE: *1. A digital cable subscription is required.*
2. Do not insert a PCMCIA card into the CableCARD slot.

If the CableCARD is properly installed or not installed, the TV will display the following respective screens.



OR



After the CableCARD is installed, wait until the second screen below appears. The third screen below will appear if a channel is not authorized for viewing. Press the **EXIT** button to exit the second screen.


In order to start cable service for this device, please contact your cable provider
CableCARD(tm): 123-456-789-1
Host: 123-456-789-1
Data: 123-456-789-1
Unit Address: 123-456-789-1
Press EXIT to return

OR



Please take note of all information on the screen (you will provide this information to your cable operator). Call your cable operator and give them the information from the card to start your cable service.

NOTE: *Please see Appendix E on page 101 for additional CableCARD information.*

Connecting External Video Sources

The front panel jacks are provided as a convenience to allow you to easily connect your video camcorder, digital camera or Digital Video Camcorder as shown in the following examples:


Left Side Panel
Left Side Panel
INPUT 5
R L/MONO AUDIO VIDEO S-VIDEO
IEEE1394 DV INPUT
PHOTO INPUT
Ferrite Core Instructions:
1. Wrap once the USB cable or IEEE 1394 cable (not supplied) on the ferrite core near the Photo Input or IEEE 1394 Input as shown.
2. Fold and close the ferrite core while being careful not to pinch the cable.
Ferrite Core
Ferrite Core
S-Video cable
(Optional, see note)
IEEE 1394 Cable
USB Cable
S-VHS V L R
OUTPUT
Video Camera
Digital Video Camcorder
Digital Camera

NOTE: *1. Completely insert connection cord plugs when connecting to left side panel jacks. If you do not, the played back picture may be abnormal.*
2. If you have a S-VHS VCR, use the S-VIDEO cable in place of the standard video cable.
3. If you have a mono VCR, insert the audio cable into the left audio jack of your TV.
4. S-VIDEO input takes priority over VIDEO input.
5. If you have a VHS or 8mm camcorder, use the S-VIDEO cable in place of the VIDEO cable.

The exact arrangement you use to connect the VCR, camcorder, laserdisc player, DVD player, or HDTV Set Top Box to your Plasma TV is dependent on the model and features of each component. Check the owner's manual of each component for the location of video and audio inputs and outputs.

The following connection diagrams are offered as suggestions. However, you may need to modify them to accommodate your particular assortment of components and features. For best performance, video and audio cables should be made from coaxial shielded wire.

Before Operating External Video Source
Connect an external source to one of the INPUT terminals, then press the INPUTS button to show the INPUTS menu. Use the CURSOR PAD (▲ and ▼) to select the Antenna or Input of your choice. Then press the SELECT button or the CURSOR PAD ▶ to confirm your choice (see page 26).



Rear Panel Connections



NOTE: *Cables are optional, except when specified.*

Tips on Rear Panel Connections

- S-VIDEO, YPBPR, or HDMI connections are provided for high performance laserdisc players, VCRs etc. that have this feature. Use these connections in place of the standard video connection if your device has this feature.
- If your device has only one audio output (mono sound), connect it to the left audio jack on (L/(MONO)) the Rear Panel.
- Refer to the operating guide of your other electronic equipment for additional information on connecting your hook-up cables.
- A single VCR can be used for VCR #1 and VCR #2, but note that a VCR cannot record its own video or line output (INPUT: 1 in the example on page 14). Refer to your VCR operating guide for more information on line input-output connections.
- Connect only 1 component (VCR, DVD player, camcorder, etc.) to each input jack.
- COMPONENT: Y-P_BP_R (Input 3 & 4) connections are provided for high performance components, such as DVD players and set-top-boxes. Use these connections in place of the standard video connection if your device has this feature.
- Your component outputs may be labeled Y, B-Y, and R-Y. In this case, connect the components B-Y output to the TV's P_B input and the components R-Y output to the TV's P_R input.
- Your component outputs may be labeled Y-C_BC_R. In this case, connect the components C_B output to the TV's P_B input and the components C_R output to the TV's P_R input.
- It may be necessary to adjust TINT to obtain optimum picture quality when using the Y-P_BP_R inputs. (See page 44)
- To ensure no copyright infringement, the MONITOR OUT output will be abnormal, when using the Y-P_BP_R, and HDMI input jacks.
- INPUT 1 or 2 can accept HDMI signal.
- S-VIDEO monitor output may be used for recording only when the input is of S-VIDEO type.
- When using a HDMI input from a Set-Top-Box, it is recommended to use a 1080i or 720p input signal.

MACROVISION NOTES:

1. Video signals fed through a VCR may be affected by copyright protection systems and the picture will be distorted on the television.
2. Connecting the television directly to the Audio /Video output of a Set-Top-Box will assure a more normal picture.

Connecting External Video Sources

CONNECTING A VIDEO AND STEREO AUDIO SOURCE TO INPUT1 – INPUT5

1. Connect the cable from the VIDEO OUT of the VCR or the laserdisc player to the INPUT (VIDEO) jack, as shown on the Rear Panel on the right.
2. Connect the cable from the AUDIO OUT R of the VCR or the laserdisc player to the INPUT (AUDIO/R) jack.
3. Connect the cable from the AUDIO OUT L of the VCR or the laserdisc player to the INPUT (AUDIO/L) jack.
4. Press the INPUTS button, then select INPUT 2 from the INPUTS menu to view the program from the VCR or laserdisc player.
5. Select CABLE or AIR from the INPUTS menu to return to the last channel tuned.



NOTE: *1. Completely insert the connection cord plugs when connecting to rear panel jacks. The picture and sound that is played back will be abnormal if the connection is loose.*
2. A single VCR can be used for VCR #1 and VCR #2 (see page 14) but note that a VCR cannot record its own video or line output. Refer to your VCR operating guide for more information on line input-output connections.
3. When INPUT 3 or 4 are used, it is necessary to connect the video output of the device to the Y/VIDEO input jack of the TV.

CONNECTING AN S-VIDEO AND STEREO AUDIO SOURCE TO INPUT 1, 2 AND 5

1. Connect the cable from the S-VIDEO OUT of the S-VHS VCR or the laserdisc player to the INPUT (S-VIDEO) jack, as shown on the Rear Panel on the right.
2. Connect the cable from the AUDIO OUT R of the VCR or the laserdisc player to the INPUT (AUDIO/R) jack.
3. Connect the cable from the AUDIO OUT L of the VCR or the laserdisc player to the INPUT (AUDIO/L) jack.
4. Press the INPUTS button, then select INPUT 1 from the INPUTS menu to view the program from the VCR or laserdisc player.
5. Select CABLE or AIR from the INPUTS menu to return to the last channel tuned.



NOTE: *1. Completely insert the connection cord plugs when connecting to rear panel jacks. The picture and sound that is played back will be abnormal if the connection is loose.*
2. A single VCR can be used for VCR #1 and VCR #2 (see page 14), but note that a VCR cannot record its own video or line output. Refer to your VCR operating guide for more information on line input-output connections.

Connecting External Video Sources

CONNECTING A COMPONENT SOURCE WITH HDMI OR DVI CAPABILITY TO INPUT 1 OR 2

1. Connect the HDMI or DVI output of the HDTV set top box or DVD player to the HDMI input as shown on the Rear panel below.
2. With DVI output, connect the cable from the AUDIO OUT R of the HDTV set top box or DVD player to the INPUT (AUDIO/R) jack as shown on the Rear Panel below.
3. With DVI output, connect the cable from the AUDIO OUT L of the HDTV set top box or DVD player to the INPUT (AUDIO/L) jack as shown on the Rear Panel below.
4. Press the INPUTS button, then select INPUTS 1 or 2 to view the program from the HDTV set top box or DVD player.
5. Select CABLE or AIR from the INPUTS menu to return to the last channel tuned.

NOTE:
1. *Completely insert the connection cord plugs when connecting to rear panel jacks. The picture and sound that is played back will be abnormal if the connection is loose.*
2. *The HDMI input on INPUT 1 and 2 contains the copy protection system called High-bandwidth Digital Content Protection (HDCP). HDCP is a cryptographic system that encrypts video signals when using HDMI connections to prevent illegal copying of video contents.*
3. *HDMI is not a "NETWORK" technology. It establishes a one-way point-to-point connection for delivery of uncompressed video to a display.*
4. *The connected digital output device controls the HDMI interface so proper set-up of device user settings determines final video appearance.*
5. *When using a DVI to HDMI cable, connect the Audio Out L and R cables at the same INPUT (1 or 2) as your HDMI INPUT (1 or 2).*

HDMI input



DVI to HDMI Input



Connecting External Video Sources

CONNECTING A COMPONENT AND STEREO AUDIO SOURCE TO INPUT 3 OR 4: Y-PBPR.

1. Connect the cable from the Y OUT of the Laserdisc/DVD player or HDTV set top box to the INPUT (Y) jack, as shown on the Rear panel below.
2. Connect the cable from the P_B/C_B OUT or B-Y OUT of the Laserdisc/DVD player or HDTV set top box to the INPUT ($P_{B)}$ jack.
3. Connect the cable from the P_R/C_R OUT or R-Y OUT of the Laserdisc/DVD player or HDTV set top box to the INPUT (P_R) jack.
4. Connect the cable from the AUDIO OUT R of the Laserdisc/DVD player or HDTV set top box to the INPUT (AUDIO/R) jack.
5. Connect the cable from the AUDIO OUT L of the Laserdisc/DVD player or HDTV set top box to the INPUT (AUDIO/L) jack.
6. Press the INPUTS button, then select INPUT 4 from the INPUTS menu to view the program from the Laserdisc/DVD player or HDTV set top box.
7. Select CABLE or AIR to return to the last channel tuned.

NOTE: *1. Completely insert the connection cord plugs when connecting to rear panel jacks. The picture and sound that is played back will be abnormal if the connection is loose.*
2. See page 15 for tips on REAR PANEL CONNECTIONS.



Connecting External Video Sources

CONNECTING A COMPONENT SOURCE WITH DIGITAL INTERFACE CAPABILITY TO IEEE1394 TERMINALS.

1. Connect the IEEE1394 cable from the output of the component with IEEE1394 capability, such as a Digital VCR or AVHD (External Hard Drive) Digital Recorder, to the IEEE1394 input terminals shown below. IEEE 1394 allows the plasma television and the external device to communicate with one another. When using IEEE1394 connections, you enable video and audio digital data exchange between a compatible device. This connection also enables you to control basic equipment functions (such as VCR play, rewind, fast forward, stop, etc.) from your TV On-Screen Display.

2. Press the INPUTS button on the Remote Control.

3. Select the IEEE1394 option (see page 29).

NOTE: *1. With IEEE1394 connection, video and audio will be received by the TV. It will enable you to control the D-VHS from the TV IEEE1394 menu (see page 29).*
2. The IEEE1394 interface contains the copy protection standard called 5C or Digital Transmission Content Protection (DTCP).



Connecting External Audio/Video Devices

CONNECTING A VIDEO AND MONAURAL AUDIO SOURCE TO INPUT 1, INPUT 2 OR INPUT 5

1. Connect the cable from the VIDEO OUT of the VCR or the laserdisc player to the INPUT (VIDEO) jack, as shown on the Rear Panel on the right.

2. Connect the cable from the AUDIO OUT of the VCR or the laserdisc player to the INPUT (MONO)/L(AUDIO) jack.

3. Press the INPUTS button, then select INPUT 2 from the INPUTS menu to view the program from the VCR or the laserdisc player.

4. Select CABLE or AIR from the INPUTS menu to return to the last channel tuned.



CONNECTING AN EXTERNAL AUDIO AMPLIFIER

To monitor the audio level of the Plasma TV to an external audio amplifier, connect the system as shown on the right. The “OPTICAL OUT” from the Rear Panel is a fixed output. The Volume of the amplifier is controlled by the amplifier, not by the Plasma Television. The OPTICAL OUT terminal outputs all audio sources with Optical IN capability.

1. Connect an optical cable from the Optical out to the Optical input of a separate Stereo System Amplifier as shown on the Rear Panel on the right.



CONNECTING MONITOR OUT

The MONITOR OUT terminal outputs video and audio of CABLE/AIR and INPUTS 1, 2, 3, 4 and 5. It does not output component video.

1. Connecting S-Video:
   Connect the cable from the S-VIDEO OUT of the Rear Panel to the INPUT (S-VIDEO) jack, of the VCR or Laserdisk player.

   Connecting Video:
   Connect the cable from the VIDEO INPUT of the VCR or the laserdisc player to the VIDEO out jack on the TV Rear Panel.

2. Connect the cable from the AUDIO IN R of the VCR or the laserdisc player to the OUTPUT (AUDIO/R) jack on the TV Rear Panel.

3. Connect the cable from the AUDIO IN L of the VCR or the laserdisc player to the OUTPUT (AUDIO/L) jack on the TV Rear Panel.



NOTE: *1. When making video connections, connect S-Video only or Video only. If both are connected, S-Video takes priority (see table on page 8).*
2. For further information on using MONITOR OUT, refer to pages 88 and 89.

Connecting External Video Sources

Your Hitachi Plasma Television is equipped with an AV Network feature. This feature helps to control your external Audio/Video equipment (VCR, Set Top Box, DVD, etc.). Once this is setup, it allows your IR Mouse connector to control your equipment using your Hitachi Plasma TV Remote Control. You can use your HITACHI remote control to control the Audio/Video equipment command without the equipment's remote control.

The Plasma Television Rear Panel has 2 IR BLASTER jacks. Each IR Mouse cable can connect up to 2 external Audio/Video components. Therefore, you can connect the Plasma Television with up to four components. Please see the following example of an AV Network setup between your Hitachi Plasma Television and external Audio/Video equipment (VCR and DVD Player).

CONNECTING EXTERNAL AUDIO/VIDEO COMPONENTS TO IR BLASTER FOR AV NETWORK

1. Connect your external Audio/Video components to the Rear Panel shown below.

2. Connect the IR Mouse cable to the IR BLASTER output of the Rear Panel.

3. Place the IR Mouse in front of the infrared sensor of the external components you wish to control.



4. ACCESS THE AV NET SETUP WIZARD
   Press the MENU button.

5. Use the CURSOR PAD ▼ or channel scroll down to highlight SETUP.

6. Press the SELECT or CURSOR PAD ▶ button to select.

7. Use the CURSOR PAD ▼ or channel scroll to highlight the SET AV NET features then press the SELECT button.

8. Follow the Setup procedure on pages 79-86.





NOTE: *1. The Rear Panel has two IR BLASTER outputs which can control up to a total of four external components.*
2. The IR Mouse must be placed in front of the external components infrared sensor for the AV Network to work. Double-sided mounting tape may be used to hold the IR Mouse in place.
3. The correct codes must be chosen for each of the Audio/Video components for the AV Network to function properly.

Connecting External Video Sources

Your Hitachi Plasma Television is equipped with a G-LINK feature. This connection is necessary for the TV Guide On Screen™ system to work with your cable box to receive program listings and to enable VCR recording features. Once you setup the G-LINK (IR Mouse) connector, then you can use your HITACHI Plasma TV Remote Control and the TV Guide On Screen system to control your cable box and VCR recording features.

The Plasma Television Rear Panel has IR BLASTER/G-LINK jacks. One IR Mouse cable can connect up to 2 external Audio/Video components. Please see the following example of a G-LINK setup between your HITACHI Plasma Television and external Audio/Video equipment (VCR and Cable box).

CONNECTING THE CABLE BOX/VCR TO G-LINK FOR TV GUIDE ON SCREEN™ SYSTEM

1. Connect your external Audio/Video components to the Rear Panel shown below.

2. Connect the IR Mouse cable to the IR BLASTER/G-LINK output of the Rear Panel.

3. Place the IR Mouse in front of the infrared sensor of the external components you want to control.



4. To access the TV Guide On-Screen™ system, press the MENU button.

5. Use the CURSOR PAD ▼ or channel scroll down to highlight TV GUIDE ON SCREEN.

6. Press the SELECT or CURSOR PAD ▶ button to select.

7. Follow the Setup procedure on pages 49-53.



NOTE: *1. The G-LINK connection is not necessary for D-VHS recording devices.*
2. The IR Mouse must be placed in front of the external components infrared sensor for the AV Network to work.
3. G-LINK connections are available on both IR BLASTER jacks.

The Remote Control

In addition to controlling all the functions on your HITACHI Plasma TV, the new remote control is designed to operate different types of VCRs, CATV (Cable TV) converters, set-top-box, satellite receiver, DVD players, and other audio/video equipment with one touch. Basic operation keys are grouped together in one area.

To operate your Plasma TV, point the remote control at the remote sensor of the Television and select the TV by pressing the ◀ or ▶ button of the Source Access on the remote. The TV mode indicator will blink, indicating that the remote will now control your television.

To operate your VCR, point the remote at the remote sensor of the VCR and select PVR by pressing the ◀ or ▶ button of the Source Access on the remote. The PVR mode indicator will blink, indicating that the remote will now control your VCR (see page 37 for instructions on how to program the remote to control your VCR).

To operate your PVR (Personal Video Recorder), point the remote at the remote sensor of the PVR and select PVR by pressing the ◀ or ▶ button of the Source Access on the remote. The PVR mode indicator will blink, indicating that the remote will now control your PVR (see page 37 for instruction on how to program the remote to control your PVR).

To operate your cable box, point the remote at the remote sensor of the cable box and select the CABLE (CBL) by pressing the ◀ or ▶ button of the Source Access on the remote. The CBL mode indicator will blink, indicating that the remote will now control your cable box (see page 34 for instructions on how to program the remote to control your cable box).

To operate your set-top-box or satellite receiver point the remote at the remote sensor of the set-top-box and select the SET-TOP-BOX (STB) by pressing the ◀ or ▶ button of the Source Access on the remote. If you have a satellite receiver, use this button to program your satellite receiver. The STB mode indicator will blink, indicating that the remote will now control your set-top-box (see page 35 for instructions on how to program the remote to control your set-top-box).

To operate your DVD player, point the remote at the remote sensor of the DVD player and select DVD by pressing the ◀ or ▶ button of the Source Access on the remote. The DVD mode indicator will blink, indicating that the remote will now control your DVD Player (see page 36 for instruction on how to program the remote to control your DVD
player).

To operate additional audio equipment, point the remote at the remote sensor of the component you wish to control and select AMP by pressing the ◀ or ▶ button of the Source Access on the remote. The AMP mode indicator will blink, indicating that the remote will now control your audio equipment (see page 38 for instructions on how to program the remote to control additional Audio/Video equipment).

NOTE: *When you press any remote control button, the buttons will light up. The illumination will light a few seconds during this time. The buttons will appear to light if the room is dark.*

There are two modes of lighting the Remote Control buttons. They are the Automatic and Manual modes.

AUTOMATIC MODE (Default mode)
In Automatic mode, if any button is pressed (including the LIGHT button), the illumination will light for 4 seconds.

MANUAL MODE (Optional mode)
In Manual mode, the illumination will only work when the LIGHT button is pressed. When the LIGHT button is pressed, the illumination will light for 8 seconds. During the illumination, if the LIGHT button is pressed, the illumination will turn off.

CHANGING LIGHTING MODES (Automatic to Manual/Manual to Automatic)
1. *Place the Remote Control in TV Mode by using the SOURCE ACCESS ◀ and ▶ buttons. The TV mode indicator will blink 3 times to confirm the remote control mode.*
2. *Press and hold the LIGHT button for 10 seconds. After releasing the LIGHT button, the TV mode indicator will blink 3 times to confirm the mode switch.*



How to Use the Remote to Control Your TV



① **POWER button**
Press this button to turn the TV set on or off when the remote is in TV mode. (See page 23 for instructions on how to set the remote control to TV mode.)

② **MODE Indicator**
Turns on or blinks to show remote control mode.

③ **SOURCE ACCESS (◄ or ►) buttons**
Press these buttons to select remote control mode.

④ **SOURCE ACCESS (ENT) button**
Hold down this button while entering your device code to program the remote (see pages 34-41). You can also use this button in an optional Input access feature (see page 39).

⑤ **PAUSE button**
Press the PAUSE button to freeze the picture. Press the EXIT button to return the picture to motion. Press the PAUSE button repeatedly to cycle through the three different freeze modes (see page 33).



⑥ **ASPECT button**

Press this button to quickly change the picture format ASPECT ratio. Depending on the input signal format received, the picture format ratio allows you to adjust the images through the following options.

4:3 STANDARD
Use this aspect mode to display conventional (4:3) images. Side panels (gray areas) are placed to the left and right of the image to preserve the original aspect ratio of the source. Note: Use this mode for only 15% of your total viewing time to prevent uneven aging of the phosphors. Phosphors in the lighted area of the picture will age more rapidly than the gray areas.

4:3 EXPANDED
Use this aspect mode to display conventional (4:3) sources by linearly increasing image expansion from the center towards the edges of the display area in order to fill it.

4:3 ZOOM1/ZOOM2
Use these aspect modes to zoom in on conventional (4:3) sources.

16:9 STANDARD
Use this aspect mode to display 16:9 sources like HDTV and DVD's preserving the original 16:9 aspect ratio.

16:9 ZOOM
Use this aspect to Zoom-in once while in 16:9 aspect.

- **Antenna-Analog**
- **S-Video/Video Input (Auto Aspect: Off)**
- **HDMI-480i/480p Input (Auto Aspect: Off)**
- **Component-480i/480p Input (Auto Aspect: Off)**

Note: Please see Appendix A on page 100.



- **Antenna-Digital (4:3)**
- **S-Video/Video 4:3/Letter Input (Auto Aspect: On)**
- **HDMI-480i/480p 4:3/ Letter Input (Auto Aspect: On)**
- **Component-480i/480p 4:3/ Letter Input (Auto Aspect: On)**

Note: Please see Appendix B on page 100.



- **S-Video/Video 16:9 Input (Auto Aspect: On)**
- **HDMI-480i/480p 16:9 Input (Auto Aspect: On)**
- **Component-480i/480p 16:9 Input (Auto Aspect: On)**

Note: Please see Appendix C on page 100.



- **Antenna-Digital (16:9)**
- **HDMI-720p/1080i Input**
- **Component-720p/1080i Input**

Note: Please see Appendix D on page 100.



NOTE: *1. The Aspect Style setting you select for an ANT input will automatically be set for the other ANT input. However, all five video inputs have independent Aspect Style settings.*
2. Vertical position adjustments are directly available when you choose 4:3 EXPANDED/ZOOM1/ZOOM2 or 16:9 ZOOM aspect style (see also page 45).

⑦ **DAY/NIGHT button**
Press this button to toggle between Day and Night picture mode settings. Select Day for day time viewing with more brightness and contrast to compete with room light. Select Night for night time viewing with less brightness and contrast for a more detailed picture (see page 44 for settings changes).

NOTE: *For automatic DAY/NIGHT picture mode settings, see page 44.*

⑧ **PICTURE-IN-PICTURE button**
See separate section on pages 31-33 for a description.

⑨ **MENU button**
The MENU button will start the On-Screen Display.

⑩ **INFO button**
Press this button when you want to check the channel being received, the picture source, if the channel has stereo (ST) or second audio program (SAP), the time, CHANNEL ID and if the TIMER is set.

ANALOG/DIGITAL CHANNELS



When an S-VIDEO Input is connected to INPUT 3



When a Component Video: Y-PbPr Input is connected to INPUT 1



NOTE: *1. The Sleep Timer info will show momentarily after releasing INFO button.*
2. The Aspect setting will not be shown if the channel is locked.

⑪ **EXIT button**
This button will exit all On-Screen Displays.

⑫ **CURSOR PAD/SELECT button**
All the On-Screen Display features can be set or adjusted by using the CURSOR PAD, except for numeric entries. The CURSOR PAD will highlight functions or adjust and set different features. Press the CURSOR PAD toward desired direction and press the SELECT button to select.

⑬ **GUIDE button**
Press this button to access the TV Guide On Screen™ interactive display (see page 54). Press this button to access the Channel Guide of the (CBL), and (SAT/STB) while in (CBL)(SAT/STB) mode.

⑭ **INPUTS button**
When the remote control is in TV mode, press this button to access the INPUTS menu. Use the CURSOR PAD and SELECT button to select the inputs that are being used. Pressing the INPUTS button repeatedly will also cycle through the Inputs menu items. Then press the SELECT button to select.



INPUT 1	Select to choose INPUT 1.
INPUT 2	Select to choose INPUT 2.
INPUT 3	Select to choose INPUT 3.
INPUT 4	Select to choose INPUT 4.
INPUT 5	Select to choose INPUT 5.
CABLE	Select to choose Cable.
AIR	Select to choose Air.
PHOTO INPUT	Select to access your pictures from a digital camera, USB memory or memory card USB drive connected to the Photo Input in the side panel of the Plasma TV (see pages 27-28).
IEEE1394	Select to choose the IEEE1394 Input (see page 29).

How to Use the Remote to Control Your TV

PHOTO INPUT

This feature is useful for viewing digital still pictures from your digital camera, USB Drive or memory cards USB drive using the Photo Input in the left side panel of the TV.

1. Press the INPUTS button to cycle through the INPUTS selections until the PHOTO INPUT is selected. Press the SELECT button or CURSOR PAD ▶.



2. Press the CURSOR PAD ◀ or ▶ to access the next or previous photo.



3. Press the SELECT button to view THUMBNAIL.
4. Use the CURSOR PAD buttons ▲, ▼, ◀ or ▶ and the SELECT button to navigate and select individual chosen photos.



5. Press the picture number to jump from picture to picture.



6. Press the INFO button to access PHOTO Input menu and to view Photo information.
7. Press the CURSOR PAD ▲ or ▼ and the SELECT button to navigate and select the PHOTO Input menu.



NOTES:

1. *Contrast will decrease automatically if stationary images such as digital still photos are left on the screen for more than 3 minutes.*
2. *The maximum number of digital Photos that can be displayed is 999.*
3. *Press INFO button to show Picture Numbers in Thumbnail view, plus other information in individual photos.*
4. *Digital photos recorded on a DVD-RAM disc may not work with this Photo Input.*
5. *Certain types of digital cameras may not work with this Photo Input.*
6. *Digital cameras with low battery power may not properly display your photos in this input.*
7. *The screen may show "Input device not detected" if the digital camera's large capacity memory is fully loaded, or because of slow access time on some digital cameras. Please wait 1 or 2 minutes before checking your Photo Input connections.*

How to Use the Remote to Control Your TV

ROTATE

Select this menu item to rotate selected photos either clockwise (CURSOR PAD ▶) and counterclockwise (CURSOR PAD ◀).



SLIDESHOW

Select this menu item to start a slideshow of the digital photos. While the Interval sub menu is highlighted, press the SELECT button to cycle through the interval time from 5, 10 and 30 seconds. Press the SELECT button to stop on a chosen picture of the slideshow. After 30 seconds, the slideshow will resume or press the SELECT button again to continue with the slideshow.



DEVICE

Select this menu item to select the Photo Input Device Drive when using a USB Drive device. Use the CURSOR PAD ◀ or ▶ to select Device Drive. Press the INFO button to highlight a device, then press the SELECT button or CURSOR PAD ▶ to access it. Use the CURSOR PAD ◀ or ▶ to choose the device to read.



NOTES:

1. *Automatic contrast reduction also applies during SLIDESHOW, then press any button to continue.*
2. *Photo file names modified on a computer should be 8 characters (Ex. ABCD1234.jpg). 1st character: letters; 2nd to 4th: letters or numbers; 5th to 8th: numbers. Photo files should be first placed on a sub directory name with 8 characters (Ex. 123ABCDE). 1st to 3rd: number; 4th to 8th: letters. The sub directory then should be placed on a main directory with a "dcim" file name format.*
3. *Supported image types are up to 3072 x 2304; JPEG format should conform with DCF Standard (Design rule for Camera File System).*
4. *This TV set displays only digital pictures from digital cameras which meet DCF Standard. Pictures that were copied, edited or modified on a computer may not be displayed on the TV set.*

How to Use the Remote to Control Your TV

IEEE1394

Use this function to control your devices with digital interface capabilities.

When an IEEE1394 device is not connected





When an IEEE1394 device is connected







1. Press INPUT button, CURSOR PAD and SELECT button to select IEEE 1394.
2. Use CURSOR PAD ► to select connected device (example D-VHS1).
3. Use CURSOR PAD cursors to highlight POWER.
4. Press the SELECT button to power on the device.
5. Use CURSOR PAD cursors to select D-VHS operation.
6. Press down on the CURSOR PAD to enable the selected operation.
7. Use CURSOR PAD cursors to highlight the TV IN/OUT operation.
8. Press the SELECT button to select:
   TV IN is DVHS
   TV OUT is Cable

NOTES:

1. *The digital device will be automatically recognized if properly connected.*
2. *Four (4) IEEE1394 devices can be listed on the menu, but only one device at a time can be used. If a fifth device is connected, it will replace the first device on the menu list.*
3. *The On-Screen display will not disappear until the EXIT button is pressed.*
4. *Not all devices with IEEE1394 capability are compatible with this TV. Any compatibility problems with other manufacturers devices should be brought to the attention of those manufacturers.*
5. *TV IN/OUT functions are not available when D-VHS is in playback or recording.*
6. *Digital channels may contain Copy Control Information (CCI). When using a CableCARD, this CCI data will prevent recording of some programs depending on its content value.*

⑮ **LAST CHANNEL (LAST CH) button**
Press this button to toggle between the current and last channel viewed.

⑯ **VOLUME (VOL) WHEEL, MUTE button**
Use the VOL WHEEL (▲ or ▼) until you obtain the desired sound level.

To reduce the sound to one half of normal volume (SOFT MUTE) to answer the telephone, etc., press the VOL wheel down. Press the VOL wheel again to turn the sound off completely (MUTE). To restore the sound, press the VOL wheel one more time or VOL Up (▲).





Closed Captioning will display automatically when MUTE/SOFT MUTE is on and Closed Caption is set to AUTO (see page 88).

When the TV power is turned off at a volume level 31 or greater, the volume level will default to 30 when the TV is turned on. However, if it is set to a level 30 or less, the volume level will be at the level it was set when the TV is turned ON.

⑰ **CHANNEL (CH) WHEEL/CHANNEL SELECTOR buttons**
The CHANNEL wheel or the CHANNEL SELECTOR buttons are used to select channels, lock access code, etc. Use the CHANNEL WHEEL (▲ or ▼) to select the desired channel. Use the CHANNEL SELECTOR buttons to enter one, two, or three numbers to select channels. Enter “0” first for channels 1 to 9, or simply press the single digit channel you wish to tune then wait a few seconds for the TV to tune. For Digital Channels, use the CHANNEL SELECTOR buttons with the (-) DASH button. Channel selection may also be performed by CHANNEL WHEEL up (▲) or CHANNEL WHEEL down (▼).

Press the channel (CH) wheel to switch to Favorite (FAV) channel mode. You will know you are in Favorite Channel mode when (FAV) is displayed and the displayed channel is GREEN. Press it again to return to your regular tuned channels. You can add any channel to your Favorite channel list by pressing and holding down the Channel (CH) wheel until the displayed channel turns from WHITE to highlighted GREEN. You can also delete a channel from your favorite channel list by pressing and holding down the Channel (CH) wheel until the displayed channel turns highlighted GREEN to WHITE.

⑱ **(-) DASH button**
Use the (-) DASH button with the CHANNEL SELECTOR buttons to enter Digital Channels that have subchannel numbers indicated by (-) DASH (example 15-1).

⑲ **BACKLIGHT button**
Press this button to light up and illuminate the buttons of the remote control.

Picture-in-Picture (PIP)

Your HITACHI Plasma TV incorporates Two Tuner technology designed for improved viewing enjoyment. This Two Tuner feature allows you to view antenna inputs on both the main picture and sub picture simultaneously, with separate tuning control for each. When a Digital channel is viewed in the main picture, the Digital channel can not be viewed in the sub picture. And when the Analog channel input is viewed in the main picture, the Analog channel input can not be viewed in the sub picture.

The CABLE and AIR input cannot be viewed in PIP mode at the same time. To select between main picture and PIP sub picture tuning, use the CURSOR PAD button the remote. The Green highlighted channel display will move with every press of the CURSOR PAD buttons.

The Picture-in-Picture feature is convenient when you want to watch more than one program at the same time. You can watch a TV program while viewing other programs from any of the video inputs.

Use connection shown at the right to view VCR program as a sub-picture while viewing another program as main picture (CABLE or AIR).

When installing a CableCARD, connect your coaxial cable to CABLE (see page 12).



① **PIP button**
Press the PIP button and a sub-picture will appear in one of the four different modes (POP, PIP, SPLIT or SURF), depending on the INPUT signal. To change the PIP mode, use the PIP button to cycle through the four different modes.

POP MODE PICTURE-IN-PICTURE
POP Mode PIP displays the sub-picture outside of the main picture. Use the CURSOR PAD (▲ or ▼) to move the sub-picture. This feature is not available with a 1080i signal. Please refer to the PICTURE-IN-PICTURE MODES Table (see page 32).





NOTES:
1. *PIP MODE Picture-in-Picture is only available with a 1080i signal.*
2. *Press the CURSOR PAD (◄ or ►) to enable the sub-picture sound.*
3. *Sub-picture channel availability depends on the channel list.*

Picture-In-Picture (PIP)

PIP MODE PICTURE-IN-PICTURE

Select AIR from the INPUTS menu. Select a channel that has a 1080i signal. To prevent a pattern burn, occasionally move the sub-picture using the CURSOR PAD.



SPLIT MODE PICTURE-IN-PICTURE

Split Mode PIP displays the main picture and sub-picture evenly on the screen.



SURF MODE PICTURE-IN-PICTURE

Surf Mode PIP automatically scans all active channels (those set in Memory) and displays them as PIP sub-pictures or Thumbnails. Press the SELECT button to stop on a chosen channel. Use the remote CURSOR PAD ▲, ▼, ◀ or ▶ to navigate the Thumbnails. Press the SELECT button to restart channel scan or press the EXIT button to enable your chosen channel and return to normal viewing.

Picture-in-Picture (PIP) Modes

PIP Mode	Main/ Sub	Aspect	Digital Tuner 16:9	Digital Tuner 4:3	1080i/ 720p 16:9	480p/480i/ Analog Tuner Video/S-Video 16:9	480p/480i/ Analog Tuner Video/S-Video 4:3
POP	ANT Digital	16:9	–	–	–	–	–
		4:3	–	–	Yes	Yes	Yes
	480p/480i	16:9	Yes	Yes	–	–	–
	ANT Analog S-Video/Video	4:3	Yes	Yes	–	–	–
PIP 4:3	ANT Digital	16:9	–	–	–	Yes	Yes
	1080i/720p	16:9	–	Yes	–	–	–
	480p/480i S-Video/Video	16:9	–	–	–	–	–
PIP 16:9	ANT Digital	16:9	–	–	Yes	Yes	Yes
	1080i/720p	16:9	Yes	–	–	–	–
	480p/480i S-Video/Video	16:9	–	–	–	–	–
SPLIT	ANT Digital	16:9	–	–	Yes	Yes	Yes
		4:3	–	–	Yes	Yes	Yes
	1080i/720p	16:9	Yes	Yes	–	–	–
	480p/480i	16:9	Yes	Yes	–	–	–
	ANT Analog S-Video/Video	4:3	Yes	Yes	–	–	–
SURF 12 PIX	–	–	Yes	Yes	–	–	Yes[1]

1. Available only in Analog Tuner.

Picture-In-Picture (PIP)

② **PAUSE button**
If you wish to freeze the sub-picture, press the PAUSE button. This is convenient when trying to write down the address for a mail order company, recording statistics for a sporting event, etc. To return the picture to motion, press the EXIT button. Press the PAUSE button repeatedly to toggle between FREEZE modes (Main Freeze, SPLIT and STROBE).



MAIN FREEZE
Press the PAUSE button to freeze one frame of the picture you are currently viewing and the frozen frame will show in the Main Picture. Press the EXIT button to return to normal viewing. This feature is useful for freezing a picture frame with addresses.



SPLIT FREEZE
Press the PAUSE button to freeze the picture you are currently viewing (only the right sub-picture will freeze). Press the EXIT button to return to normal viewing.



STROBE FREEZE
Press the PAUSE button to freeze three frames of the picture you are currently viewing (only the 3 sub-pictures will freeze). Press the EXIT button to return to normal viewing. This feature is useful for viewing a moving picture that has many details, for example, a close play in a sporting event or a golf swing.



NOTE: *1. The default FREEZE mode is the MAIN freeze followed by the SPLIT freeze and then the STROBE freeze. The last FREEZE mode you selected before you pressed the EXIT button will be the one that comes up after pressing the PAUSE button again.*
2. Each freeze frame in Strobe Freeze is delayed about 0.1 (1/10) second.

The Remote Control for Cable Box Functions

Operating the precoded function for your cable box.

This remote is designed to operate different types of cable boxes. You must first program the remote to match the remote system of your cable box (refer to pages 40-41 for pre-codes).

1. Turn ON your cable box.
2. Aim the remote control at the front of your cable box.
3. To switch to Cable (CBL) pre-coded mode, use the SOURCE ACCESS buttons (◀ or ▶) on the remote control to position the LED light to the corresponding selection.
4. Hold down the ENT button on the remote and enter the four digit preset code that matches your cable box as shown on pages 40-41. Release the ENT button. The indicator light will flash 3 times if the code was accepted.
5. Aim the remote at the cable box and press the POWER button. The remote will turn off your cable box when the correct four digit preset code is entered. When this occurs, the remote control is programmed for your cable box. If the cable box does not turn off, try a different four digit preset code.
6. The remote will now control your Cable box.

NOTE: *1. If your cable box cannot be operated after performing the above procedures, your cable box code has not been precoded into the remote.*
2. In the unlikely event that your cable box cannot be operated after performing the above procedures, please consult your cable box operating guide.
3. The remote control will remember the codes you have programmed until the batteries are removed from the from the remote control. After replacing the batteries repeat the entire programming procedure as stated above.

① **PRECODED CABLE BOX buttons**
These buttons transmit the chosen precoded cable codes.

② **EXCLUSIVE TV buttons**
These buttons are for operating the TV.



MY CABLE BOX CODE IS: _____

NOTE: *Refer to instruction manual of the Cable Box for operation of the buttons exclusively for the Cable Box.*

The Remote Control for Set-Top-Box/Satellite Receiver Functions

Operating the precoded function for your set-top-box/satellite receiver.

This remote is designed to operate different types of set-top-box/satellite systems. You must first program the remote to match the remote system of your set-top-box/satellite systems (refer to pages 40-41 for pre-codes).

1. Turn ON your set-top-box/satellite systems.
2. Aim the remote control at the front of your set-top-box/satellite systems.
3. To switch to set-top-box/satellite (STB) pre-coded mode, use the SOURCE ACCESS buttons (◄ or ►) on the remote control to position the LED light to the corresponding selection.
4. Hold down the ENT button on the remote and enter the four digit preset code that matches your set-top-box/satellite receiver as shown on page 40-41. Release the ENT button. The indicator light will flash 3 times if the code was accepted.
5. Aim the remote at the set-top-box/satellite receiver and press the POWER button. The remote will turn off your set-top-box/satellite receiver when the correct four digit preset code is entered. When this occurs, the remote control is programmed for your set-top-box/satellite receiver. If the set-top-box/satellite receiver does not turn off, try a different four digit preset code.
6. The remote will now control your set-top-box/satellite receiver.

NOTE: *1. If your set-top-box/satellite receiver cannot be operated after performing the above procedures, your set-top-box/satellite receiver code has not been precoded into the remote.*
2. In the unlikely event that your set-top-box/satellite receiver cannot be operated after performing the above procedures, please consult your set-top-box/satellite receiver operating guide.
3. The remote control will remember the codes you have programmed until the batteries are removed from the from the remote control. After replacing the batteries repeat the entire programming procedure as stated above.

① **PRE-CODED SET-TOP-BOX/SATELLITE RECEIVER buttons**
These buttons transmit the chosen pre-coded set-top-box/satellite codes.

② **EXCLUSIVE TV buttons**
These buttons are for operating the TV.



MY Satellite RECEIVER/ SET-TOP-BOX CODE IS: _____

NOTE: *Refer to instruction manual of the Set-Top-Box/Satellite Receiver for operation of the buttons exclusively for the Set-Top-Box/Satellite Receiver.*

The Remote Control for DVD Functions

Operating the precoded function for your DVD player.

This remote is designed to operate different types of DVD players. You must first program the remote to match the remote system of your DVD player (refer to pages 40-41 for pre-codes).

1. Turn ON your DVD player.
2. Aim the remote control at the front of your DVD player.
3. To switch to DVD pre-coded mode, use the SOURCE ACCESS buttons (◀ or ▶) on the remote control to position the LED light to the corresponding selection.
4. Hold down the ENT button on the remote and enter the four digit preset code that matches your DVD player, as shown on pages 40-41. Release the ENT button. The indicator light will flash 3 times if the code was accepted.
5. Aim the remote at the DVD player and press the POWER button. The remote will turn off your DVD player when the correct four digit preset code is entered. When this occurs, the remote control is programmed for your DVD player. If the DVD player does not turn off, try a different four digit preset code.
6. The remote will now control your DVD player.
7. You will need to set the display type of your DVD player to 16:9 widescreen.

NOTE: *1. If your DVD player cannot be operated after performing the above procedures, your DVD player code has not been precoded into the remote.*
2. In the unlikely event that your DVD player cannot be operated after performing the above procedures, please consult your DVD player operating guide.
3. The remote control will remember the codes you have programmed until the batteries are removed from the from the remote control. After replacing the batteries repeat the entire programming procedure as stated above.

① **PRECODED DVD Buttons**
These buttons transmit the chosen precoded DVD codes.

② **EXCLUSIVE TV Buttons**
These buttons are for operating the TV.



MY DVD PLAYER CODE IS: _____

NOTE: *Refer to instruction manual of the DVD Player for operation of the buttons exclusively for the DVD Player.*

The Remote for VCR/PVR Functions

Operating the precoded function for your VCR/PVR (Personal Video Recorder).

This remote is designed to operate different types of VCRs/PVRs. You must first program the remote to match the remote system of your VCR/PVR (refer to pages 40-41 for pre-codes).

1. Turn ON your VCR/PVR.
2. Aim the remote control at the front of your VCR/PVR.
3. To switch to VCR/PVR pre-coded mode, use the SOURCE ACCESS buttons (◄ , ►) on the remote control to position the LED light to the corresponding selection.
4. Hold down the ENT button on the remote and enter the four digit preset code that matches your VCR/PVR, as shown on pages 40-41. Release the ENT button. The indicator light will flash 3 times if the code was accepted.
5. Aim the remote at the VCR/PVR and press the POWER button. The remote will turn off your PVR when the correct four digit preset code is entered. When this occurs, the remote control is programmed for your VCR/PVR. If the VCR/PVR does not turn off, try a different four digit preset code.
6. The remote will now control your VCR/PVR.

NOTE: *1. If your VCR/PVR cannot be operated after performing the above procedures, your VCR/PVR code has not been precoded into the remote.*
2. In the unlikely event that your VCR/PVR cannot be operated after performing the above procedures, please consult your VCR/PVR operating guide.
3. The remote control will remember the codes you have programmed until the batteries are removed from the from the remote control. After replacing the batteries repeat the entire programming procedure as stated above.

① **PRECODED VCR/PVR Buttons**
These buttons transmit the chosen precoded VCR/PVR codes.

② **EXCLUSIVE TV Buttons**
These buttons are for operating the TV.



MY VCR/PVR CODE IS: _____

NOTE: *Refer to instruction manual of the VCR/PVR for operation of the buttons exclusively for the VCR/PVR.*

The Remote Control for Additional Audio Equipment

Operating the precoded function for your Audio component.

This remote is designed to operate different types of Audio component. You must first program the remote to match the remote system of your Audio component (refer to pages 40-41 for pre-codes).

1. Turn ON your Audio component you wish to control with the Remote.
2. Aim the remote control at the front of your Audio component.
3. To switch to Audio (AMP) component pre-coded mode, use the SOURCE ACCESS buttons (◄ or ►) on the remote control to position the LED light to the corresponding selection.
4. Hold down the ENT button on the remote and enter the four digit preset code that matches your Audio component, as shown on pages 40-41. Release the ENT button. The indicator light will flash 3 times if the code was accepted.
5. Aim the remote at the Audio component and press the POWER button. The remote will turn off your Audio component when the correct four digit preset code is entered. When this occurs, the remote control is programmed for your Audio component. If the Audio component does not turn off, try a different four digit preset code.
6. The remote will now control your Audio component.
7. Repeat steps 1 - 6 if you wish to program the remote to control another Audio component.

NOTE:
1. *If your Audio component cannot be operated after performing the above procedures, your Audio component code has not been precoded into the remote.*
2. *In the unlikely event that your Audio component cannot be operated after performing the above procedures, please consult your Audio component operating guide.*
3. *The remote control will remember the codes you have programmed until the batteries are removed from the from the remote control. After replacing the batteries repeat the entire programming procedure as stated above.*

① **PRECODED AUDIO Buttons**
These buttons transmit the chosen precoded Audio component codes.

② **EXCLUSIVE TV Buttons**
These buttons are for operating the TV.



MY AUDIO COMPONENT CODE IS: _____

NOTE: *Refer to instruction manual of the VCR/PVR for operation of the buttons exclusively for the VCR/PVR.*

How to Use the ENT Button

INPUT ACCESS

This optional feature allows the user of the remote control to setup it's ENTER (ENT) button to access the specified input of the TV. Setup for this feature is applicable to the remote control's normal mode only and only applies to the DVD, CBL, STB, PVR and AMP modes.

1. Select the desired device mode (DVD, CBL, STB, PVR, or AMP) by using your SOURCE ACCESS buttons (◄ or ►) to position the LED indicator to the corresponding selection.

2. Hold down the ENTER (ENT) button on the remote and enter the four digit preset code that matches your device as shown on pages 40-41.

3. Then enter the assigned input number (1-5) that the device is related to.

4. Release ENTER (ENT) button.

5. If done correctly, the device LED indicator will flash 3 times to confirm proper setup.

6. The remote will now control the desired device.

7. Pressing the ENTER (ENT) button will now access the video input (1-5) of the desired device.

SETUP EXAMPLE (Hitachi DVD with precode 0573 connected to INPUT 1 of the TV)

(1) Select DVD mode by using your SOURCE ACCESS buttons (◄ or ►) to position the LED indicator to DVD.

(2) Hold down the ENTER (ENT) button and press the numbers 0, 5, 7 and 3.

(3) Then press the number 1 for the assigned input number of the DVD player.

(4) Release ENTER (ENT) button.

(5) If done correctly, the device LED indicator will flash 3 times to confirm proper setup.

(6) The remote will now control the DVD player.

(7) Press the ENTER (ENT) button to instantly access the video input of your DVD on Input 1.



NOTE: *1. This feature is optional*
2. Assigned input numbers can be used more than once if applicable.

Remote Control Codes

VCR BRAND .....CODE
ABS 1972
Admiral 0048, 0209
Adventura 0000
Aiko.....0278
Aiwa 0000, 0037, 0307
Akai 0041, 0061, 0106
Alienware 1972
America Action 0278
American High 0035
Asha 0240
Audiovox.....0037, 0278
Beaumark 0240
Bell & Howell 0104
Broksonic.....0121, 0184, ...0002, 0209, 0479
CCE 0072, 0278
Calix 0037
Canon 0035
Carver.....0081
Cineral 0278
Citizen.....0278, 0037
Colt 0072
Craig .....0037, 0072, ...0047, 0240, 0271
Curtis Mathes .....0035, 0041, ...0060, 0162
CyberPower 1972
Cybernex 0240
Daewoo 0278, 0045, 0561
Dell 1972
Denon 0042
Durabrand.....0039, 0038
Dynatech 0000
Electrohome 0037
Electrophonic 0037
Emerex 0032
Emerson0037, 0184, 000, 0121, 0043, 0209, 0002, 0278, 0061, ..0208, 0212, 0479, 0561, 1593
Fisher 0104, 0047, 0066
Fuji 0033, 0035
Funai.....0000, 1593
GE .....0035, 0060, 0240, ...0202, 0761
Garrard 0000
Gateway 1972
Go Video 0432, 0526
GoldStar 0037, 0038
Gradiente 0000, 0008
HI-Q 0047
HP.....1972
Harley Davidson 0000
Harman/Kardon 0038, 0081
Harwood 0072
Headquarter 0046
Hewlett Packard 1972
Hitachi 0000, 0041, 0042, 0105
Howard Computers.....1972
Hughes Network Systems 0042
iBuy Power 1972
JVC.....0067, 0041, 0008
Jensen 0041
KEC 0037, 0278
KLH.....0072
Kenwood 0041, 0067, 0038
Kodak 0035, 0037
LG.....0037
LXI 0037
Lloyd's 0000, 0208
Logik.....0072
MEI 0035
MGA 0043, 0240, 0061
MGN Technology 0240
MTC 0000, 0240
Magnasonic 0593
Magnavox 0035, 0081, 0563, 0000, 0039, 0593
Magnin 0240
Marantz.....0081, 0035
Marta 0037
Matsushita 0035, 0162, 1162
Media Center PC 1972
Memorex .....0035, 0162, 0037, ...0048, 0039, 0047, 0240, ...0000, 0104, 0209, 0046, ..0307, 0479, 1037, 1162, 1262
Microsoft 1972
Mind 1972
Minolta 0042, 0105
Mitsubishi 0061, 0043, 0067
Motorola 0035, 0048
Multitech 0000, 0072
NEC 0038, 0041, 0067, 0104
Nikko.....0037
Noblex 0240
Northgate 1972
Olympus 0035
Optimus .....0593, 1062, 0162, ...0037, 0048, 0104, 0432, ...1048, 1162, 1262
Optonica 0062
Orion....0184, 0209, 0002, 0479
Panasonic ....0162, 1062, 0035, ...0616, 1162, 1262
Penney0035, 0037, 0240, 0042, ...0038
Pentax 0042, 0105
Philco ..0035, 0209, 0479, 0561
Philips .....0081, 0035, 0618, ...1081, 1181, 0062
Pilot.....0037
Pioneer 0067
Polk Audio.....0081
Profitronic 0240
Proscan 0060, 0202, 0761
Protec 0072
Pulsar 0039
Quarter 0046
Quartz.....0046
Quasar 0035, 0162, 1162
RCA....0060, 0240, 0042, 0105, ...0106, 0202, 0761, 0880
Radio Shack 0000, 1037
Radix 0037
Randex. 0037
Realistic.....0035, 0037, 0048, ...0047, 0000, 0104, 0046, ...0062, 0066
ReplayTV 0614, 0616
Runco 0039
STS.....0042
Samsung 0045, 0240, 0432
Sanky 0039, 0048
Sansui .....0000, 0067, 0209, ...0041, 0479, 1479, 0271
Sanyo ..0047, 0240, 0104, 0046
Scott .....0184, 0045, 0121, ...0043, 0210, 0212
Sears ..0035, 0037, 0047, 0000, 0042, 0104, 1237, 0046, 0066, ...0105
Semp. 0045
Sharp 0048, 0848, 0062
Shintom 0072
Shogun 0240
Singer 0072
Sonic Blue 0614, 0616
Sony .....0035, 0032, 0000, ...0033, 0636, 1032, 1972
Sylvania.....0035, 0081, 0000, ...0043, 0593, 1593
Symphonic 0000, 0593, 1593
Systemax 1972
TMK 0240, 0208
Tagar Systems 1972
Tatung.....0041
Teac 0000, 0041
Technics 0035, 0162
Teknika 0000, 0035, 0037
Thomas.....0000
Tivo.....0618, 0636, 1503
Toshiba .....0045, 0043, 0066, ...0210, 0212, 0366, 0845, ...1008, 1145, 1503, 1972
Totevision 0037, 0240
Touch 1972
Unitech 0240
Vector 0045
Vector Research.....0038
Video Concepts 0045, 0061
Videomagic.....0037
Videosonic 0240
Viewsonic 1972
Wards 0060, 0062, 0035, 0048, ...0047, 0081, 0240, 0000, ...0042, 0072, 0212
White Westinghouse..... .....0072, 0209
XR-1000 .....0072, 0000, 0035
Yamaha 0038
ZT Group 1972
Zenith 0039, 0000, 0209, 0033, ...0479, 1479

DVD BRAND .....CODE
AMW.....0872
Aiwa 0641
Allegro 0869
Apex Digital ..0672, 0717, 0755, 0794, 0796, 0797, 1004, 1020, ..1056, 1061, 1100, 1915, 1937
Audiovox.....0790, 1072
Axion.....1072
Blaupunkt 0717
Blue Parade 0571
Brooksonic 0695
CAVS 1057
CineVision 0876, 0869
Classic 1917
Coby 1086
Curtis Mathes 1087
CyberHome ..0816, 1023, 1024
DVD2000 0521
Daewoo .....0784, 0705, ...0833, 0869, 1918
Denon.....0490, 0634
Dual 1068, 1085
Emerson 0591, 0675
Enterprise 0591
Fisher 0670
Funai.....0675
GE 0522, 0717, 0815
GPX 0699, 0769
Gateway 1073
Go Video .....0744, 0715, 0783, ...0833, 0869, 1075
Gradiente 0651
Greenhill 0717
Grundig.....0705
Harman/Kardon 0702
Hitachi 0573, 0664, 0695
Hiteker 0672
IRT 0783
Initial 0717
Integra 0627
Hiteker 0672
JBL 0702
JVC.....0623, 0558, 0867, 1901
KLH 0717, 0790, 1020
Kawasaki 0790
Kenwood.....0490, 0534
Koss 0651
Lasonic 0798
Lite-On 1058
Magnavox .....0503, 0675, ...1914, 1976
Marantz.....0539
Memorex.....0695
Microsoft 0522
Mintek 0717, 0839
Mitsubishi 0521, 1521
Nesa 0717
Norcent 1003, 0872
Onkyo 0627, 0503
Oritron.....0651
Panasonic.....0490
Philco 0790
Philips..0503, 0539, 0646, 0854
Pioneer 0525, 0571, 1902
Polaroid 1061, 1086
Polk Audio.....0539
Proscan 0522
Qwestar 0651
RCA.....0522, 0571, 0717, ...0790, 0822, 1974
Recco 0698
Rio 0869
Rotel 0623
Rowa 0823
Sampo 0698, 0752
Samsung .....0490, 0573, ...0820, 0744, 1075
Sansui.....0695
Sanyo 0670, 0695, 0873
Semp 0503
Sharp 0630, 0752
Shinsonic 0533, 0839
Sonic Blue 0869
Sony 0533
Sylvania 0675
Symphonic 0675
TYT.....0705
Teac 0790
Technics 0490
Theta Digital 0571
Tivo.....1996
Toshiba .....0503, 0695, 1045, ...1988, 1996, 2006
Tredex 0799, 0803
US Logic.....0839
Urban Concepts 0503
Venturer 0790
XBox.....0522
Yamaha 0490, 0545, 0539
Zenith 0591, 0503, 0869

CABLE BRAND.....CODE
ABC ....0003, 0008, 0011, 0013, ...0014, 0017
Allegro 0153, 0315
Americast 0899
Antronix 022
Archer.....022, 0153, 0797
Bell & Howel 0014
Bell South 0899
Cabletenna 0022
Cableview 0022
Century 0153
Citizen.....0153, 0315
ClearMax 0883
Clearmaster 0883
Colour Voice 0025, 0031
Comtronics 0040
Contec 0019
Coolmax 0883
Digi 0637
Director 0476
Dumont 0637
Emerson 0797
Everquest 0015, 0040
Focus 0400
Garrard 0153
Gemini 0015, 0797
General Instrument 0003, 0011, ...0476, 0276, 0810
GoldStar 0040, 0144
Goodmind 0797
Hamlin 0009, 0020, 0034, 0273
Hitachi 0011

Jasco 0015, 0153, 0315
Jerrold ..... 0003, 0011, 0012, 0014, 0015, 0024, 0276, 0476, ...0810
Memorex 0000
Motorola ..... 0276, 0476, 0810, ...1106, 1254, 1376
Movie Time 0063
Multivision.....0012
NSC 0063
Novaplex.....0618
Oak.....0019
Optimus 0021
Pace 0237, 1877
Panasonic.....0000, 0021, 0107
Panther.....0637
Paragon 0000
Philips.....0305, 0317
Pioneer0023, 0025, 0031, 0153, ...0144, 0533, 0877, 1877
Popular Mechanics.....0400
Pulsar 0000
Quasar.....0000
RCA 0021
RadioShack..0015, 0315, 0797, ...0883
Recoton 0400
Regal.....0020, 0273, 0279
Rembrandt 0011
Runco 0000
SL Marx 0040
Samsung 0040, 0144
Scientific Atlanta ....0877, 0008, ...0017, 0477, 1877
Signal 0015, 0040
Signature 0011
Sony 1006
Sprucer.....0021
Starcom 0003, 0015
Stargate 0015, 0040, 0797
Starquest 0015
Supercable 0276
Supermax 0883
TFC.....0310
TV86.....0063
Tandy 0258
TeleCaption.....0221
Teleview 0040
Timeless 0040
Tocom.....0012, 0013
Torx.....0003
Toshiba 0000
Tristar 0883
Tusa 0015
Unika 0022, 0153
Universal 0022, 0153, 0191
V2 0883
ViewMaster.....0883
Viewstar 0063, 0258
Vision 0883
Vortex View.....0883
Zenith ..0000, 0054, 0525, 0899
Zentek.....0400

SATELLITE BRAND (Set-Top-Box) .....CODE
AlphaStar 0772
Amway 0043, 0075
Astro Industries.....0095
BSR 0095
Cable Innovations.....0554
Capetronic 0095
Century.....0856
Channel Master 0018, 0212
Chapparral 0053, 0209, 0216
Conifer 0004
Crossdigital 1109
Curtis Mathes 061
DX Antenna 0041
DirecTV .....0392, 0566, 0639, ...1639, 1142, 0247, 0749, ...1749, 0724, 0819, 1856, ...1076, 1109, 0099, 1052, ..1053, 1054, 1442, 1443, 1444
Dish Network System 1005, 0775, 1170
DishPro.....1005, 0775
Drake 0018, 0064, 0245
Echostar .....1005, 0775, 0148, ...0269, 0280, 1170
Expressvu.....0775
GE 0566
GOI.....0775
General Instrument .....0869, ...0547, 0554
Gradiente 0856
HTS 0775
Hitachi.....0819
homecable 0238
Hughes Network Systems 1142, ..0749, 1749, 1442, 1443, 1444
Hytek 0095
IQ 0210
IQ Prism 0210
Innova.....0099
Intersat 0043
JVC.....0775, 1170
Janeil 0152
Legend 0269
Macom 0018, 0061
Magnavox.....0724, 0722
Memorex.....0724, 0269
Mitsubishi 0749
Motorola 0869
Netsat 0099
Next Level.....0869
Norsat.....0004
Pace 0455
Panasonic.....0247, 0701, 0152
Paysat.....0724
Philips 1142, 0749, 0724, 1076, ...0722, 1749, 0856, 0099
Pico.....0075
Proscan 0392, 0566
RCA 0392, 0566, 0855, 0143
Radioshack.....0869, 0554
Ramsey 0075
Realistic 0052
SKY 0856, 1856, 0099
STS.....0041, 0210
Samsung.....1276, 1109
Sony 0639, 1639
Star Choice.....0869
Star Trak.....0180, 0421, 0547
Strong 0421
Tivo.....1142, 1442, 1443, 1444
Toshiba .....0749, 1749, 0790, ...0061, 0082, 1052, 1053, ..1054, 1285, 1286, 1287, 1289
Town & Country 0547
Uniden0724, 0722, 0052, 0074, ...0076, 0238, 0370, 0554
Zenith ..0856, 1856, 0061, 0064

AMPLIFIER BRAND .....CODE
Aiwa.....0406
Bose 0674
Carver.....0269
Curtis Mathes 0300
Denon 0160
Durabrand.....1561
GE 0078
Harman/Kardon 0892
JVC 0331
Left Coast 0892
Lenoxx 1561
Linn 0269
Luxman.....0165
Magnavox.....0269
Marantz 0269, 0321, 0892
NEC 0264
Nakamichi.....0321
Optimus 0395, 0300
Panasonic.....0308, 0521
Parasound 0246
Philips.....0269, 0892
Pioneer.....0013, 0300
Polk Audio 0269, 0892
RCA 0300
Realistic.....0395
Sansui.....0321
Shure 0264
Sony 0815, 0689, 0220
Soundesign.....0078, 0211
Technics 0308, 0521
Toshiba 0353
Victor 0331
Wards 0013, 0078, 0211
Yamaha 0354, 0133

RECEIVER BRAND (Amplifier) CODE
ADC 0531
Aiwa....1405, 0121, 0158, 0189, 0405
Anam 1074, 1609
Arcam 1120
Audiotronic 1189
Bose 0639, 1229, 1253
Capetronic 0531
Carver.....1189, 0042, 0189
Casio 0195
Clarinette 0195
Coby 1263
Compaq 1136
Curtis Mathes 0080
Dell 1383
Denon 0004, 1360
Fisher 0042
Garrard 0463
Glory Horse 1263
Harman/Kardon 0891, 0110, 0189
Hewlett Packard 1181
Hitachi.....0228
Integra 0135
JBL 0110
JVC.....0074, 1263
KLH.....1428
Kenwood .....1313, 1570, 1569, ...0027, 0042, 0186, 0239
LXI 0181
Linn 0189
Lloyd's.....0195
MCS 0039
Magnavox 1189, 1269, 0189, 0195, 0391, 0531
Marantz1189, 0039, 0189, 1269
Mitsubishi 1393
Modulaire 0195
Musicmagic.....1089
Nakamichi.....0097
Onkyo 0135, 0842
Optimus .....1023, 0042, 0080, ...0177, 0181, 0186, 0219, ..0531, 0670, 0738, 0801, 1074
Panasonic 1518, 0039, 0309, 0367
Penney 0195
Philips .....1189, 1269, 0189, ...0391, 1120
Pioneer .....1023, 0014, 0080, ...0150, 0244, 0531, 0630
Polk Audio.....0189
Proscan 1254
Quasar 0039
RCA.....1023, 1254, 0080, ...0531, 1074, 1609
Radio Shack 1263
Realistic 0181, 0195
Rio 1383
Sansui.....0189
Sanyo 0801, 1251
Scott 0163, 0322
Sharp 0186
Sharper Image 1263
Sherwood 0491, 0502
Sonic Blue 1383
Sony ..1058, 1441, 1759, 0158, ...0474, 1349, 1406, 1442
Soundesign.....0670
Stereophonics.....1023
Sunfire 1313
Teac 0463, 1074
Technics.....1308, 1518, ...0039, 0309
Thorens.....1189
Toshiba 1572
Victor 0074
Wards .0014, 0080, 0158, 0189
Yamaha.....0176, 0186, 1176
Yorx. 0195
Zenith 0857

AUDIO BRAND .....CODE
Aiwa 0010, 0159
AudioSource 0351
Cambridge Soundworks 0351
Carver.....0351
Fisher 0052
Fosgate.....0259
Harmon/Kardon 0477
JBL 0477
JVC.....0073
KLH.....0351
Magnavox 0325
Nikko.....0376
Paramount Pictures 0317, 0351
RCA 0056
SSI 0317
Sansui.....0325
Schneider 0376
Sony 0010, 0576
Soundesign.....0376
Yorx.....0376

SET TOP BOX BRAND..CODE
Panasonic 1120
Pioneer 1010
Princeton.....0113, 0295
Samsung.....1190
Sensory Science.....1126
Sharp 1010
Sony 0639

PERSONAL VIDEO RECORDER BRAND.....CODE
Panasonic.....0616
Philips 0618
ReplayTV 0614, 0616
SonicBlue 0614, 0616
Sony 0636
Tivo 0618, 0636

On-Screen Display

1. Press MENU on the remote control to display the different features on your HITACHI Plasma TV.

2. Use the CURSOR PAD (buttons ▲, ▼, ◄ and ►) or CHANNEL WHEEL to navigate to a different menu item.

3. Press EXIT on the remote control to quickly exit from a menu.





On-Screen Display

Video

Picture Mode	Select between the two picture modes; Day and Night.
Contrast	Adjust contrast.
Brightness	Adjust brightness.
Color	Adjust color.
Tint	Adjust tint.
Sharpness	Adjust sharpness.
Color Temperature	Set this to High for less intense color with more blue, set to Medium for natural color, set to Standard for standard colors or Black and White for more reddish color.
Black Enhancement	Enhance picture brightness in light scenes.
Contrast Mode	Use this function to choose between 3 Contrast Mode settings.
Noise Reduction	Reduces conspicuous noise in the picture.
Auto Movie Mode	Turn On/Off the 3:2 Pulldown detection feature.
Aspect	Choose the picture format aspect ratio.
Black Side Panel	Set the gray side bars On/Off when watching 4:3 signals in standard mode.
Reset Video Settings	Choose to Reset Video Settings to factory settings.

Audio

Treble	Adjust the treble.
Bass	Adjust the bass.
Balance	Adjust the balance.
SRS	Select SRS settings (Off, Wide, Normal)
BBE	Select BBE settings (Off, Soft, Hard)
TruBass	Select TruBass settings.
Audio Source	Select between three Audio Sources.
Internal Speakers	Select internal or external speakers.
Auto Noise Cancel	Eliminates the noise between stations.
Perfect Volume	Adjust volume in fixed setting.
Loudness	Adjust Loudness.
Language	Select Language options if available.
Digital Output	Select Optical Output options.
DRC	Select Dynamic Range Compression to ON or OFF.

NOTE: *The Language, Digital Output, and the Dynamic Range Compression feature of the Audio OSD are only available for Digital channels.*

TV Guide On Screen

TV Guide On Screen	Set, Control and navigate the system

Channel Manager

Signal Meter	Access Signal Meter.
Auto Channel Scan	Set Auto Channel Scan.
Channel List	Set Channel List.

Locks

Change Access Code	Change Lock access code.
Engage Lock	Choose to lock channel, video input, and/or front panel.
Movie Ratings	Block various types of movies and video types based on motion picture ratings.
TV Ratings	Block various types of movies and television programming based on a parental guide ratings.
Canadian Ratings (ENG)	Block various types of movies and television programming based on the Canadian ratings system.
Canadian Ratings (FRN)	Block various types of movies and television programming based on the Canadian French ratings system.

Timers

Set the Clock	Set Clock Settings.
Set Sleep Timer	Set Sleep Timer intervals (30 min. intervals, 00:30-3:00).
Set Day/Night Timer	Set Day/Night picture mode settings.

Setup

Menu Preference	Choose English, French, or Spanish text.
Screen Saver	Set Screen Saver to prevent screen burn.
Set The Inputs	Label Video Inputs, VCR, DVD, etc.
Set AV NET	Set AV NET Wizard
Set Closed Captions	Feature to display dialogue/text.
Set Monitor Out	Set Monitor Out source.
Upgrades	Select to upgrade TV software.
Set Stand-By Mode	Select the Set Stand-By Mode options.

Power Swivel

Unlocked	Power Swivel enabled. Control the motorized Table Top Stand
Locked	Power Swivel disabled.

NOTE:
1. *The Signal Meter feature of the Channel Manager OSD is only available for Digital channels.*
2. *The CableCARD information feature of the Setup OSD is only available when a CableCARD from your cable operator is installed in the rear panel of the TV.*
3. *Power Swivel feature is only available when Table Top Stand is connected.*

Video

Select VIDEO to adjust picture settings and improve picture quality. You can independently customize each of the Video Inputs to your preference to increase viewing performance and pleasure depending upon the video program being viewed. If RESET is selected, only the selected input will reset to initial conditions.



Picture Mode
Use this function to choose from automatic picture settings to optimize your TV's performance.

1. Use the **CURSOR** buttons ◀ or ▶ to highlight and select **PICTURE MODE** settings (Day or Night).

2. Then press the **SELECT** button to set the mode and return to the Video menu or press **EXIT** to quit menu.



Function	Day	Night
Contrast	100%	90%
Brightness	50%	50%
Color	50%	30%
Tint	50%	50%
Sharpness	50%	30%
Color Temperature	High	Standard
Black Enhancement	High	Off
Contrast Mode	Dynamic	Normal
Noise Reduction	Low	Low
Auto Movie Mode (TV/Cinema Detection)	Off	Off

1. Use the **CURSOR PAD** ▲ or ▼ to highlight the function to be adjusted.

2. Press the **SELECT** button or the CURSOR PAD ▶ to select the function settings.

3. Press the **CURSOR PAD** ◀ or ▶ to adjust the function.

4. Press **MENU** to return to main menu.

5. Press **EXIT** to quit menu.

Contrast
Use this function to change the contrast between black and white levels in the picture.

Brightness
Use this function to adjust overall picture brightness.

Color
Use this function to adjust the level of color in the picture.



Tint
Use this function to adjust flesh tones so they appear natural.

Sharpness
Use this function to adjust the amount of fine detail in the picture.

Video

Color Temperature
Set this to High for cooler color with more blue, set to Medium for more natural color, set to Standard for accurate color or set to Black/White for more reddish color.

Black Enhancement
Use this function to enhance the shadow detail in dark scenes using the settings off, low, middle and high.

NOTE: *1. If **CONTRAST** is selected, you are adjusting **CONTRAST**. The additional menu items **BRIGHTNESS, COLOR, TINT,** and **SHARPNESS** can be selected and adjusted in the same manner.*
*2. It may be necessary to adjust **TINT** to obtain optimum picture quality when using the **COMPONENT VIDEO Y-PBPR** input jacks.*
*3. **CABLE** and **AIR** share a Video setting. Also, each of the video inputs have their own independent settings.*

Contrast Mode
Use this function to choose between 3 Contrast Mode settings. Set to Dynamic for darker images more in the level of Black, set to Normal for a balanced White to Black level, and set to Auto for automatic Contrast selection.

Noise Reduction
The **NOISE REDUCTION** function automatically reduces conspicuous noise in the picture without degrading picture quality. Set **NOISE REDUCTION** to **OFF** if the TV experiences picture blocking.

Auto Movie Mode
The **AUTO MOVIE MODE** function turn ON or OFF the 3:2 PULLDOWN DETECTION SPECIAL FEATURE. Theatrical movies are shot on film at 24 frames or still pictures per second, instead of 30 frames or 60 fields like video. When film is transferred to video for television viewing, the disparity between the two frame rates must be reconciled. This involves a process known as 3:2 pulldown.

When **AUTO MOVIE MODE** is turned ON from the VIDEO menu, your Hitachi Plasma Television will activate the circuitry for this special feature to improve video performance when watching film based sources.

NOTE: *1. When using a Progressive Scan Component or HDMI Input (480p or 720p), AUTO MOVIE MODE will not be available.*
2. All Video settings are independent of each other based on it's input (Cable/Air, Input 1~5).

Aspect
Use this function to select the Picture Format Aspect Ratio.



Auto Aspect
Automatically adjust the Aspect Ratio depending on the input signal to fill the screen.

Mode
Manually select the Aspect Ratio.

Vertical Position
This function allows you to select when aspect style is either 4:3 EXPANDED/ZOOM1/ZOOM2 or 16:9 ZOOM. Vertical position can be changed with these modes. For example, it will be useful for centering the picture area at both the top and bottom of the picture with 480i/480p signal. Adjustable range is -10 (video center is toward bottom of screen) to +10 (video is toward top of screen).

1. Use the **CURSOR PAD** ▲ or ▼ to to select menu item.

2. Press the **CURSOR PAD** ◄ or ► to adjust the function**.**

3. Press the EXIT to quit the MENU, or select ASPECT to return to the main menu.

NOTE: *Vertical Position will not be available in 4:3 Standard and 16:9 Standard modes.*

Set Black Side Panel

The **BLACK SIDE PANEL** function turns the gray side bars on/off when watching 4:3 signals in Standard mode or use of the PIP modes.

1. Press the **CURSOR PAD** ◀ or ▶ to set to ON or OFF.
2. Press **EXIT** to quit menu or select **SET BLACK SIDE PANEL** to return to the previous menu.





NOTE: *To prevent uneven aging when watching 4:3 signal, turn off the BLACK SIDE PANEL. It is recommended to watch 4:3 signal with gray side bar.*

Reset Video Settings

This function allows you to Reset the Video Menu Settings of the present input and return it to the Day VIDEO mode.

1. Use CURSOR PAD ▲, ▼ or CHANNEL WHEEL to highlight functions.
2. Press the SELECT button or CURSOR PAD ▶ to select Reset Video Settings.
3. Use the CURSOR PAD ▼ to access at the Reset softkey.
4. Press the SELECT button to Reset the Video Settings.



You can customize each of the Video Inputs to your preference to increase viewing performance and pleasure, depending upon the video program being viewed. If RESET is selected, only the selected Input will reset to the initial conditions as explained above.

If RESET is selected in Input 1, only Input 1 will return to factory conditions.


OR
Video
Reset Video Settings
Select "Reset" to return the video menu settings on this Input to the original factory settings.
Reset
Select "Yes" to fix the Video Menu Settings to the original factory Settings on all modes after power "ON".
No
Yes
Move
SEL Return

NOTE: *If YES is selected, the **VIDEO MENU SETTINGS** will be reset to the original factory settings on all modes during the next power on/off.*

Audio

Audio

Select AUDIO to adjust the TV to your preference and to improve the sound quality.

1. Press CURSOR PAD ▲ or ▼ to select menu item.
2. Press CURSOR PAD ◄ or ► to adjust the function.
3. Press EXIT to quit the MENU, or select AUDIO to return to the main menu.

NOTE: *If TREBLE is selected you are adjusting treble. The additional menu items Bass and Balance can be selected and adjusted in the same manner.*



Treble
This function controls the high frequency audio to all speakers.

Bass
This function controls the low frequency audio to all speakers.

Balance
This function will control the left to right balance of the Plasma TV internal speakers.

SRS
Based on the principles of the human hearing system, **SRS** technology delivers and exciting and realistic 3D Sound experience from just two external speakers (or) the two internal speakers of your **HITACHI** Television. If your **HITACHI** Television is connected to an external audio system, **SRS** will also create an incredible 3D sound experience from two speakers and even enhance a complete multi-speaker surround sound system.

SRS and the (●) symbol are trademarks of SRS Labs, Inc. SRS technology is incorporated under license from SRS Labs, Inc.

BBE
Sound reproduction quality enhancement system. The **BBE** technology produces sound that is natural and crisp from just two speakers or the two internal speakers found in your **HITACHI** television. If your **HITACHI** television is connected to an external audio system, **BBE** will also create an incredible crisp sound experience from two speakers. **BBE** brings to the listener's ear a more complete and accurate reproduction of the original performance. Each voice, speaking or singing, each instrument or sound effect is presented with its attendant harmonics or partials more clearly audible. The ear can then more easily recognize the unique tonal colors of each sound as though the sound was being produced live.

Licensed by BBE Sound, Inc. under USP5510752 and 5736897. BBE and BBE symbol are registered trademarks of BBE Sound, Inc. Manufactured under license from BBE Sound, Inc.

SRS TruBass
TruBass is an audio enhancement technology from SRS Labs that provides deep, rich bass on any speaker system without the need for a subwoofer or additional extra physical components. For systems with a subwoofer, TruBass complements and enhances the bass performance. This feature can be set to Off, Low, Medium and High.

TruBass, SRS and the (●) symbol are trademarks of SRS Labs, Inc. TruBass technology is incorporated under license from SRS Labs, Inc.

Audio

Audio Source
Multi-Channel Television Sound will allow you to select **STEREO** (a stereo broadcast), **MONO** (monaural sound) used when receiving a weak stereo broadcast or **SECOND AUDIO PROG** (SAP) which may be a secondary language, weather report, etc.

Internal Speakers
This function is useful when setting up the external speakers.

ON	Select this feature if using the internal speakers only.
TV as Center	Select this feature when setting up external speakers from a separate stereo system. The TV's speakers will work as the center speaker.
OFF	Select this feature if you prefer to use only speakers from a separate stereo system.

Auto Noise Cancel
This function eliminates the noise between stations. If a channel is tuned and is noisy, this function will automatically eliminate the audio for that channel.

Perfect Volume
This function will automatically adjust volume so each channel and input has the same average volume level.

Loudness
Set this function to ON to emphasize bass and treble at low volume levels.

Language
Some programs transmit more than one DTV language option. Most will have English as a default language. The language function will allow you to select up to 4 language options (if available).

Digital Output
This function allows you to select between Dolby® Digital and PCM.

Dolby® Digital - Select this feature if the TV is connected to an amplifier/receiver with a Dolby® Digital only decoder; it will provide six independent soundtrack channels through the optical output jack (Digital Audio).

NOTE: **Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.*

PCM - Select this feature if the TV is connected to an amplifier/receiver with a PCM only decoder; it will provide two independent soundtrack channels through the optical output jack (Digital Audio).

DRC
Dynamic Range Compression - Use this function to compress the range of sound volume. By compressing the range of sound volume, it is possible not only to suppress the output of loud sound at night but also to raise the volume of low sound. This is only effective when the TV is connected via the optical out (digital audio) to an amplifier/receiver with a Dolby® Digital decoder. The default setting is ON.
Use the CURSOR PAD ◄ or ► to select the chosen options.

NOTE: The functions Language, Digital Output and DRC are only available when viewing digital programs.

Use the functions at right if your TV is connected to an amplifier/receiver with optical digital input with Dolby Digital or PCM decoder capabilities.





On-Screen Display

TV Guide On Screen

The TV Guide On-Screen system is a built-in feature that provides a channel lineup and program listings in your area. Once the setup process is complete, the program listings are automatically updated several times a day. This interactive guide can also be programmed to receive listings from a cable box or record your favorite shows using a VCR.

If using a Cable Box or VCR, you must first setup the Plasma TV as shown on Page 22.

To Setup the TV Guide On Screen System:

1. Press the MENU button. Use the CURSOR PAD ▼ to highlight TV GUIDE ON SCREEN, then press the SELECT button.




TV GUIDE
Welcome to the TV Guide On Screen System!
Key Features:
Subscription-free listings for your cable or broadcast service
Category sort to quickly find movies, sports, high-definition shows and more
Keyword search
One-touch recording
Reminders to mark your favorite shows
And much more!
Finding Out What's On TV Has Never Been Easier...
Press the Select key on your TV remote to begin setup.

Note: Pressing the GUIDE button also allows you immediate access to this feature.

2. Press the SELECT button to continue.

Setup Procedure:

Screen 1: Select which country your TV is located in:
Use the CURSOR PAD ▲ and ▼ to highlight your TV location (USA or CANADA), then press the SELECT button to continue.


TV GUIDE
STEP 1: Identifying Your Location
To supply your TV with correct program listings, the TV Guide On Screen system needs to know your TV's location.
Which country is your TV located in?
USA
Canada
Using your TV remote, move up or down to highlight your answer. Press Select to choose.

Screen 2: Enter the ZIP code (USA) or postal code (Canada):
Use the Numeric buttons and the CURSOR PAD ▲ and ▼ for letter entries to enter the ZIP code (USA) or postal code (CANADA) of your location.


TV GUIDE
STEP 1: Identifying Your Location
To supply your TV with the correct program listings, the TV Guide On Screen system needs to know the town or city where your TV is installed.
Please enter the 5-digit ZIP code where your TV is located:
Using your TV remote, move up, down, left or right to enter your information. Press Select to confirm.


TV GUIDE
STEP 1: Identifying Your Location
To supply your TV with the correct program listings, the TV Guide On Screen system needs to know the town or city where your TV is installed.
Please enter the 6-character postal code where your TV is located:
Using your TV remote, move up, down, left or right to enter your information. Press Select to confirm.

Screen 3:
Do you have Cable service connected?
Use the CURSOR PAD ▲ and ▼ to highlight your choice, then press the SELECT button to continue.
If YES: Please see Screen 4.
If NO: Please see Screen 12.


TV GUIDE
STEP 2: Configuring for Cable
To supply your TV with correct program listings, the TV Guide On Screen system needs to know if your TV receives its signal from a cable service.
Do you have cable service connected to this TV?
Yes
No
Using your TV remote, move up or down to highlight your answer. Press Select to choose.

TV Guide On Screen

Screen 4:

Do you have a Cable box connected?
Use the CURSOR PAD ▲ and ▼ to highlight your choice, then press the SELECT button to continue.
If YES: Please see Screen 5.
If NO: Please see Screen 12.


TV GUIDE
STEP 2: Configuring for Cable
You have indicated that you have cable service. Now the TV Guide On Screen system needs some additional information.
Is a cable box connected to this TV?
Yes
No
Using your TV remote, move up or down to highlight your answer. Press Select to choose.

Screen 5:

Which TV input is the Cable box plugged into?
AIR/CABLE: Please see Screen 6.
INPUT 1/2: Please see Screen 7.


TV GUIDE
STEP 2: Configuring for Cable
Your TV has more than one input jack. To operate properly with your cable box, the TV Guide On Screen system needs to know which one your cable box is plugged into. You may have to look at the back of your TV if you are unsure, as an incorrect selection will result in a blue or snowy screen while watching TV.
Please indicate which TV input the cable box is plugged into.
AIR
CABLE
INPUT-1
INPUT-2
Using your TV remote, move up or down to highlight your answer. Press Select to choose.

Screen 6:

Select the channel your TV is tuned to when using a Cable box. Use the CURSOR PAD ▲ and ▼ to highlight your choice, then press the SELECT button to continue.


TV GUIDE
STEP 2: Configuring for Cable
To operate properly with your cable box, the TV Guide On Screen system needs to know the channel your TV is on when using the cable box. The most commonly used output channel is 03. Please consult your cable provider if you are unsure, as an incorrect selection will result in a blue or snowy screen while watching TV.
What is your TV tuned to when using the cable box?
Ch 2
Ch 3
Ch 4
Using your TV remote, move up or down to highlight your answer. Press Select to choose.

Screen 7:

This screen shows the correct way to setup the Cable box with the G-LINK. Please confirm connection (see Page 22). Press the SELECT button to continue.


TV GUIDE
STEP 2: Configuring for Cable
The TV Guide On Screen system communicates with your cable box through the G-LINK cable. If you have not already connected this part to your TV and cable box, please refer to the TV Guide On Screen Setup Sheet or the diagram below.
G-LINK jack
front of cable box
back of TV
G-LINK cable
G-LINK wand
Plug the G-LINK cable into the G-LINK jack on the back of your TV. Then, place one of the G-LINK cable wands underneath the cable box so that the wand's lens faces the front of the cable box at a distance of about one (1) inch.
Press Select to continue.

Screen 8:

Use the CURSOR PAD ▲ and ▼ to highlight your Cable box brand or choose “Not Listed” if not listed, then press the SELECT button to continue.


TV GUIDE
STEP 2: Configuring for Cable
Selecting the correct cable box brand from the list is needed to automatically receive program listings. If you do not know the cable box brand, please consult your cable provider.
What brand of cable box is connected to this TV?
Not Listed
ABC
Americast
Bell South
Using your TV remote, move up or down through the list to find your brand (move down for more brands). Press Select to choose.

Screen 9:

To allow the TV Guide On-Screen system to find the correct code for your brand of Cable box, tune the Cable box to channel 2. Please make sure that the Cable box and TV are ON. Press the SELECT button to continue.


TV GUIDE
STEP 2: Configuring for Cable
The TV Guide On Screen system will conduct a series of tests to find the correct code to control your cable box.
Follow steps A and B below:
A. Please tune your cable box to channel 02
B. Make sure to leave your cable box turned ON
Once you have completed these steps, press Select on the TV remote to begin testing.

TV Guide On Screen

Screen 10:

The TV Guide On Screen system will test the code of your Cable box. No TV, Cable or remote buttons should be pressed while performing the automatic test. After the testing process is complete, the setup procedure will continue, see screen 11.


STEP 2: Configuring for Cable
Code testing in progress... please do not press any keys on any remote control.
Now testing code 472 (Not Listed)...

Screen 11:

Did your Cable box tune to channel 28?
Use the CURSOR PAD ▲ and ▼ to highlight your choice, then press the SELECT button to continue.
If YES: Please see screen 12.
If NO: Select NO to test a different code or select TEST THIS CODE AGAIN to test the same code.


STEP 2: Configuring for Cable
The TV Guide On Screen system needs to locate the correct code for your cable box brand in order to work properly.
Is your cable box now tuned to channel 28?
Yes
No
Test this code again
Using your TV remote, move up or down to highlight your answer. Press Select to choose.

Screen 12:

Do you have an antenna connected? Use the CURSOR PAD ▲ and ▼ to highlight your choice, then press the SELECT button to continue.

NOTE: In order to receive the program listings, you must select YES in this screen if you chose NO in Screen 3.


STEP 3: Configuring for Antenna
To supply your TV with correct program listings, the TV Guide On Screen system needs to know if you have attached an antenna to your TV to receive over-the-air stations.
Do you have an antenna connected to your TV?
Yes
No
Using your TV remote, move up or down to highlight your answer. Press Select to choose.

Screen 13:

Please confirm your initial settings. Use the CURSOR PAD ▲ and ▼ to highlight your choice, then press the SELECT button to continue.
If YES, FINISH SETUP PROCESS: Please see screen 14.
If NO, REPEAT SETUP PROCESS: Please see screen 1.


Confirm Your Settings
You have entered the following TV Guide On Screen system settings. If any setting is marked INCOMPLETE, you will not be able to use that feature until you complete that portion of TV Guide On Screen system setup.
ZIP code - 91914 (USA)
Antenna on input "AIR"
Cable Box on input "CABLE" Ch. 3
Cable Box selected: code 472 (Not Listed)
Are the above settings correct?
Yes, finish setup process
No, repeat setup process
Using your TV remote, move up or down to highlight your answer. Press Select to choose.

Screen 14:

The Basic TV Guide On Screen system setup has just been completed. Press the SELECT button to continue.


Congratulations!
You have completed the basic setup of your TV Guide On Screen system. Up-to-date listings will begin loading over the next 24 hours when your TV is powered off.
It may take more than one day for all eight days of listings to update. During this period feel free to use your TV. The guide will automatically receive updates during the period when your TV is turned off.
If you have changed the location or cable configuration settings, you will receive any changes to your local channel lineup within 24 hours.
In the following screen you will be given the opportunity to set up a VCR to enable one-touch recording from the guide's program listings.
Press Select to continue.

Screen 15:

Would like the TV Guide On-Screen system to control the recording of your VCR?
Use the CURSOR PAD ▲ and ▼ to highlight your choice, then press the SELECT button to continue.
If YES: Please see Screen 16.
If NO: Please see Screen 21.


STEP 4: Configuring a VCR
If a VCR is connected to this TV, you can use the TV Guide On Screen system's program listings to easily schedule recordings using the one-touch recording feature.
Would you like to use TV Guide On Screen to control the recording of your VCR?
Yes, setup VCR control
No, end setup
Using your TV remote, move up or down to highlight your answer. Press Select to choose.

TV Guide On Screen

Screen 16:

This screen shows the correct way to setup the VCR with the G-LINK. Please confirm connection (see Page 22). Press the SELECT button to continue.


TV GUIDE
STEP 4: Configuring a VCR
The TV Guide On Screen system communicates with your VCR through the G-LINK cable. If you have not already connected this part to your TV and VCR, please refer to the TV Guide On Screen Setup Sheet or the diagram below.
G-LINK jack
front of VCR
back of TV
G-LINK cable
G-LINK wand
Plug the G-LINK cable into the G-LINK jack on the back of your TV. Then, place one of the G-LINK cable wands underneath the VCR so that the wand's lens faces the front of the VCR at a distance of about one (1) inch.
Press Select to continue.

Screen 17:

Use the CURSOR PAD ▲ and ▼ to highlight your VCR brand or choose “Not Listed” if not listed, then press the SELECT button to continue.


TV GUIDE
STEP 4: Configuring a VCR
To operate properly with your VCR, the TV Guide On Screen system needs to know what brand of VCR is connected to your TV. An incorrect brand selection may result in program recording errors.
What brand of VCR is connected to this TV?
Not Listed
ABS
Admiral
Adventura
Using your TV remote, move up or down through the list to find your brand (move down for more brands). Press Select to choose.

Screen 18:

Please turn on your VCR and insert a tape for recording purposes. Press PLAY from the VCR, then press the SELECT button to continue.


TV GUIDE
STEP 4: Configuring a VCR
The TV Guide On Screen system will now conduct a series of tests to find the correct code to control your VCR.
Follow steps A and B below:
A. Please turn on your VCR and insert a tape.
B. Next, press “Play” to play the tape.
Once you have completed these steps, press Select on the TV remote to begin testing.

Screen 19:

The TV Guide On Screen system will test the code of your VCR. No TV, VCR or remote buttons should be pressed while performing the automatic test. After the testing process is complete, the setup procedure will continue, see screen 20.


TV GUIDE
STEP 4: Configuring a VCR
Code testing in progress... please do not press any keys on any remote control.
Now testing code 240 (Not Listed)...

Screen 20:

Did your VCR stop playing?
Use the CURSOR PAD ▲ and ▼ to highlight your choice, then press the SELECT button to continue.
If YES: Please see screen 21.
If NO: Select NO to test a different code or select TEST THIS CODE AGAIN to test the same code.


TV GUIDE
STEP 4: Configuring a VCR
Testing complete.
If your VCR stopped playing the tape, the test was successful.
Did your VCR stop playing?
Yes
No
Test this code again
Using your TV remote, move up or down to highlight your answer. Press Select to choose.

Screen 21:

Please confirm your initial settings. Use the CURSOR PAD ▲ and ▼ to highlight your choice, then press the SELECT button to continue.
If YES, FINISH SETUP PROCESS: Please see screen 22.
If NO, REPEAT SETUP PROCESS: Please see screen 1.


TV GUIDE
Confirm Your Settings
You have entered the following TV Guide On Screen system settings. If any setting is marked INCOMPLETE, you will not be able to use that feature until you complete that portion of TV Guide On Screen system setup.
ZIP code - 91914 (USA)
Antenna on input "AIR"
Cable Box on input "CABLE" Ch. 3
Cable Box selected: code 472 (Not Listed)
VCR — code 043 (Not Listed)
Are the above settings correct?
Yes, end setup
No, repeat setup process
Using your TV remote, move up or down to highlight your answer. Press Select to choose.

TV Guide On Screen

Screen 22:

Congratulations! The TV Guide On Screen system setup is complete. Press the SELECT button to finalize.


TV GUIDE
Congratulations!
You have completed the setup of your TV Guide On Screen system. Up-to-date listings will begin loading over the next 24 hours when your TV is powered off.
It may take more than one day for all eight days of listings to update. During this period feel free to use your TV. The guide will automatically receive updates during the period when your TV is turned off.
If you have changed the location or cable configuration settings, you will receive any changes to your local channel lineup within 24 hours.
Press Select to continue.

Screen 23:

The last screen gives tips on using the TV Guide On Screen system. Press the SELECT button to exit the Setup.


TV GUIDE
Helpful Information
1. To receive your channel lineup and program listings, leave your cable box ON. Your VCR and TV should be turned OFF overnight.
2. To view program listings, press the GUIDE key on your TV remote.
3. Before recording to your VCR, make sure your cable box is ON. Put a tape in your VCR, tune the VCR to the LINE input, then turn the VCR OFF.
4. You must redo TV Guide On Screen system setup if you:
▸ Move your TV to a new ZIP or postal code
▸ Cancel cable service or change cable boxes
▸ Change your VCR brand or model
To enter the TV Guide On Screen system setup, press the GUIDE key, then go to the Menu Bar and highlight Setup.
Press Select to continue.

NOTE: *1. The Plasma TV should be in standby mode in order to continually receive updated program listings from your cable company.*
2. If using a Cable box, please leave it ON to continually receive updated program listings from your cable company.

TV Guide On Screen

Using the TV Guide On Screen System

This free interactive program guide provides up to 8 days of TV programming. The advanced program listings make watching and recording TV shows and programs much easier.

The TV Guide On Screen system consists of 5 main services:

- **Listings:** Displays the available program listings and descriptions.
- **Search**: Allows you to find shows by keyword, alphabetically, or by program category.
- **Recordings**: Displays a list of recorded programs or a currently recording program.
- **Schedule**: Allows you to review, edit or delete "Record/Remind" events that were previously set.
- **Setup**: Allows you to make changes to System Settings, Channel Display and Default Options.

NOTE:

1. *After initial setup it may take up to 24 hours to receive initial program listings. It may take up to one week to receive a full 8 days of program listings.*
2. *The Program Guide provides listings for cable-ready, cable box, and digital cable services as well as over-the-air programs. It does not support satellite services.*
3. *The Recordings services will not be available until an IEEE1394 HDD recording device is connected to the TV.*
4. *The Listings services also have a recording function to other devices such as a VCR.*
5. *The TV Guide On Screen representations shown in this Operating Guide are for illustration purposes only. Channels and program availability will depend on your location.*
6. *If Cable and Air are both connected, channels from both antennas will be downloaded and shown grouped together in the listings.*



- **Video Window**- Displays the current TV program while the Guide is enabled.
- **Clock Window**- Displays the current time.
- **Tile Highlight**- Indicates the current active tile.
- **Current Services Label**- Indicates currently viewed Service Label.
- **Service Bar**- Provides access to the 5 main Guide services.
- **Time Slot**- Provides the program broadcast time frame.
- **Info Icon**- Indicates additional information is available, or the Info Box has additional sizes.
- **Info Box**- Provides information on the highlighted program.
- **Tile**- Displays the program's title.
- **Remind Icon**- Indicates the program is set to remind and the remind frequency (Once, Daily, Weekly, or Regularly).
- **Record Icon**- Indicates the program is set to record and the record frequency (Once, Daily, Weekly, or Regularly).
- **Channel Logo**- Indicates the channel logo for easy identification.
- **Panel Menu/Panel Ad**- Displays Menu options and program advertising.

TV Guide On Screen

NAVIGATING THE TV GUIDE ON SCREEN SYSTEM

- Press the GUIDE button while watching TV to access the TV Guide On Screen system. The LISTINGS screen will be presented with the current show displayed in the Video Window.
- Use the CURSOR PAD ◄, ►, ▲, and ▼ to highlight any program, and press the SELECT button to tune to that program (if it is currently airing) or channel (if the program airs in the future). You can also press the GUIDE button to exit the Guide and automatically tune to the program displayed in the Video Window.
- Press the MENU button to access the Panel Menu where you can set reminders and recordings for the highlighted program.
- To access another Service screen:
  1. Press the MENU button to access the Panel Menu. Press the CURSOR PAD ▲ to highlight "GO TO SERVICE BAR". Press the SELECT button to jump to the Service Bar. You can also jump to the Service Bar by repeatedly pressing PAGE UP or CURSOR PAD ▲.
  2. Press the CURSOR PAD ◄ or ► to highlight a different Service (LISTINGS, SEARCH, SETUP, SCHEDULE, and RECORDINGS).
  3. Press the CURSOR PAD ▼ to use the highlighted Service.



Video Window: Press the PIP button to Lock the Video Window to one single channel. Press the PIP button again to Unlock the Video Window so it displays the channels as you navigate through the listings.

Panel Menus: Press the MENU button to access the Panel Menus.

Info Box: Press the INFO button to access or resize the Info Box. Info Boxes contain information about a show, Service or Panel Ad, or Help information for a Panel Menu.

Remote Control Functions of the TV Guide On Screen system

Button	Function
① GUIDE	- Press to access the TV Guide On Screen system. - Press again to exit the TV Guide On Screen system.
② CHANNEL SELECTOR (Numbers)	- For Channel Tuning, Channel editing
③ (-) DIGITAL SEPARATOR	- For entering Digital Channels.
④ MENU	- Press to access the Panel Menu for other options.
⑤ INFO	- Press to cycle between levels of Information.
⑥ SELECT	- Press to enable your selection. - Press to directly tune to a currently airing program. - Press to display Panel Menu while checking future program tiles.
⑦ CURSOR PAD	- Press to navigate the Cursor.
⑧ RECORD	- Press to record current program.
⑨ PIP	- Press to toggle the Lock and Unlock feature of the Video Window.
⑩ PAGE UP / PAGE DOWN	- Rotate the Channel Wheel one click up or down to move one set of screen information up or down.



On-Screen Display

TV Guide On Screen

TV Guide On Screen Icons

	Icon	NAME	DESCRIPTION
1.		Progress Bar	- Elapsed time in current program
2.		Info Icon	- Indicates Info Box has additional sizes and information.
3.		HDTV	- Program is presented in High Definition.
4.		New	- Program is new (not a repeat).
5.		CC	- Closed Captioning is available.
6.		TV Rating	- TV rating for the program.
7.		Record Once	- Program is set to record one time.
8.		Record Daily	- Program is set to record every weekday that it airs on the same channel and starts at the same time. (Only available in manual recording).
9.		Record Regularly	- Program is set to record every time it airs on the same channel and starts at the same time.
10.		Record Weekly	- Program is set to record every time it airs on the same day of the week and on the same channel, and starts at the same time.
11.		Record Off	- Program is set to record but is currently Off (Still in Schedule) until the frequency is changed.
12.		Record Suspended	- Program recording is suspended due to a schedule conflict (Still in Schedule). - The Recording will resume when the conflict no longer exists.
13.		Remind Once	- Program is set to remind one time.
14.		Remind Daily	- Program is set to remind every weekday that it airs on the channel and starts at the same time (Only available when setting a manual reminder).
15.		Remind Regularly	- Program is set to remind every time it airs on the same channel and starts at the same time.
16.		Remind Weekly	- Program is set to remind every time it airs on the same day of the week and on the same channel, and starts at the same time.
17.		Remind Off	- Program is set to remind but is currently Off (Still in Schedule) until the frequency is changed.
18.		Remind Suspended	– Program reminder is suspended due to a schedule conflict (Still in Schedule). - The Reminder will resume when the conflict no longer exists.
19.		Stereo	- Program is available in stereo.
20.		AC3 Dolby Digital	- Program is presented in High-Definition, if available.
21.		Recording Media HDD	- Displays to indicate HDD storage.
22.		Recording Media DVD	- Displays to indicate DVD storage.
23.		Keep Recording	- Indicates recording will not be deleted until done so by user.

On-Screen Display

TV Guide On Screen

Five (5) Services:
- LISTINGS
- SEARCH
- RECORDINGS
- SCHEDULE
- SETUP

NOTE: *1. The RECORDINGS service is only available when an IEEE1394 HDD recording device is connected to the TV (see page 19).*
2. Recording to other devices such as a VCR is available in the LISTINGS, SEARCH and SCHEDULE services.

LISTINGS:
The LISTINGS service screen is always the first service displayed when accessing the TV Guide On Screen system.

Use the CURSOR PAD and SELECT buttons to navigate the LISTINGS screen.
- View current day and up to 7 days of future programs.
- Read program information.
- Press the SELECT button to tune directly to a current program.
- Lock and Unlock the Video Window.
- Set a program to remind.
- Set a program to Record.
- Access the panel ads and channel ads when available.
- Use the CHANNEL SELECTOR (Number) buttons to jump to a specific channel.

Press the INFO button while the LISTINGS service is highlighted on the Service Bar to display a Help screen.


TV GUIDE
8:08
INFO
See up to 8 days of shows by channel, day & time.
Use ▲/▼/◄/► keys to navigate through show listings.
Press SELECT to watch a currrently airing show.
Press Menu to display additional options (such as remind and record).
Press Guide to tune to a show in the Video Window.
STILL UNSOLVED
with Craig Smith
Friday 10:00pm
CLICK HERE
Guide Tip: Jump to a Channel or Hour!
• Enter a number using the remote to display the "Shortcuts" menu.
Just press INFO to close

Press the MENU button while a program is highlighted to access the Episode Options Panel Menu.

EPISODE OPTIONS Panel Menu:
- Go to Service Bar
- Watch Now
- Set a recording
- Set a reminder
- Tune to the channel

GO TO SERVICE BAR:
Select to highlight the Service Bar.

TUNE TO CHANNEL / WATCH NOW:
Select to exit the TV Guide On Screen system and tune to the program or channel of the highlighted current and future program tile respectively.

SET RECORDING:
Select to display the Record Options Panel Menu from which you can set a program to record (see page 61).

SET REMINDER:
Select to display the Remind Options Panel Menu from which you can set a reminder for a program (see page 62).

CANCEL:
Select to close the menu and return to the highlighted program.

TV Guide On Screen

SEARCH:
The SEARCH service screen allows you to find programs by the following:

- Keyword
- Alphabetical
- Category
  - HDTV
  - Movies
  - Sports
  - Children
  - Educational
  - News
  - Variety
  - Series

Press the INFO button while the SEARCH service is highlighted on the Service Bar to display a Help screen.


TV GUIDE
8:08
INFO
There are dozens of ways to find shows you'd like to watch, record or set as a reminder.
• HDTV – Don't miss out on HDTV-enhanced programming! Fine-tune your search with nine subcategories.
• Keyword – Don't know the full title? Find it based on a word (use All or several subcategories).
• Alphabetical – search A-Z, and shows that begin with numbers or other non-letter characters
• Categories: Movies, Sports, Children, News, Educational, Variety, Series
Guide Tip: Search Remembered!
• When you enter Search, TV Guide On Screen remembers the last Search and takes you to that section.
Just press INFO to close
STILL UNSOLVED
with Craig Smith
Friday 10:00pm
CHANNEL 9
CLICK HERE

Example Category Search (Movies)

1. From the Search Screen, press the CURSOR PAD ▼ to highlight a category (Example: Movies).

2. Press the CURSOR PAD ▼ to highlight a subcategory (Example: ALL).



3. Press the SELECT button to display a list of all movies organized by date and time.

4. Use the CURSOR PAD ▲ and ▼ to highlight a current program, and then press the SELECT button to watch now. You can also press the MENU button to access the Episode Options Panel Menu (see page 57).

TV Guide On Screen

Example: Keyword Search

The Keyword search allows you to enter a word or words to find a program title that matches.

1. From the Search Screen, use the CURSOR PAD ◄ or ► to highlight KEYWORD, and then press the SELECT button.

2. Use the CURSOR PAD ▲ or ▼ to highlight NEW SEARCH in the Panel Menu, and then press the SELECT button.



3. After the Search Options Panel Menu is accessed, use the CURSOR PAD ▲ or ▼ to highlight CATEGORY. Then, use the CURSOR PAD ◄ or ► to highlight a category to search (ALL, HDTV, Children, Sports, etc.).

4. Press the CURSOR PAD ▼ to highlight ENTER KEYWORD, and then press the SELECT button.



5. A keyboard is displayed. Use the CURSOR PAD ▲, ▼, ◄ and ► to highlight a letter, and then press the SELECT button to enter it. After entering all necessary letters, highlight DONE and press the SELECT button.



6. A list of all the shows that matched the keyword is displayed.

7. Use the CURSOR PAD ▲ and ▼ to highlight a program, and then press the SELECT button to display all play times. Use the CURSOR PAD ▲ and ▼ to highlight a chosen listing, then press the SELECT button to watch a current program or press the MENU button to display the Episode Options menu (see page 57).

NOTE: *The TV Guide On Screen system stores up to 250 keywords.*

To Edit or Delete a keyword:
From the SEARCH/KEYWORD screen, use the CURSOR PAD ▲ and ▼ to highlight the keyword you want to edit or delete. Press the MENU button to access the Search Options Panel Menu.

GO TO SERVICE BAR:
Select to highlight the Service Bar.

EDIT SEARCH:
Select to display the keyboard for editing the keyword.

DELETE SEARCH:
Select to display the Confirmation Panel Menu. Select YES to delete the search or NO to exit the Panel Menu.

CANCEL:
Select to close the Panel Menu and return to the highlighted program.

RECORDINGS:
The RECORDINGS Service screen displays a list of previously recorded or currently recording programs on an IEEE1394 recording device connected to the TV.

NOTE: The RECORDINGS Service will only appear in the Service Bar if an IEEE1394 recording device is connected to the TV (see page 19).

Press the INFO button while the RECORDINGS Service is highlighted on the Service Bar to display a Help screen.


TV GUIDE
8:08
INFO
Recordings catalogs a list of:
• Previously recorded shows
• Currently recording shows
Note: A DVR lists only shows on the current DVD. A PVR lists all recorded shows.
You can choose how the catalog is displayed
• Group
• List
And even customize further by
• Date
• Title
See details when you press Menu to open the "Recording Options" panel.
Just press INFO to close this info box
STILL UNSOLVED
with Craig Smith
Friday 10:00pm
CHANNEL 9
CLICK HERE

To choose the way recordings are displayed:

1. Use the CURSOR PAD ◄ or ► to highlight RECORDINGS on the Service Bar, and then press the MENU button to access the Recording Options Panel Menu.

2. Use the CURSOR PAD ▲ or ▼ to choose between View As and Sort By.

View As:
Use the CURSOR PAD ◄ or ► to select between List View and Group View.

- Group – Select to display recorded programs without listing every recorded episode. (Example: Screen A) Highlight a program, and then press the SELECT button to view a summary of all recorded programs.
- List – Select to display every recorded episode for a program. (Example: Screen B) Highlight an episode to display an Info Box with program information. Press the MENU button to display the Episode Options Panel Menu.

Sort By:
Use the CURSOR PAD ◄ or ► to select between Title and Date.

- Title – Select to display recorded programs in alphabetical order. (Example: Screen A)
- Date – Select to display recorded programs by Date and Time. (Example: Screen B)

3. Press the SELECT button to highlight DONE, and then press the SELECT button again to exit the Panel Menu.

To view a recording:

1. Use the CURSOR PAD ▲ or ▼ to highlight an episode and press the SELECT button to view it now. If viewed previously, the episode will resume from where it was stopped.

2. Use the CURSOR PAD ▲ or ▼ to highlight an episode, and then press the MENU button to display the Episode Options Panel Menu.

GO TO SERVICE BAR:
Select to highlight the Service Bar from the Recordings Screen.

RESUME:
Select to start from the beginning or from where it was stopped.

PLAY FROM BEGINNING:
Select to always start from the beginning.

DELETE EPISODE:
Select to delete the episode from the Recordings list and from the IEEE1394 recording device. A confirmation Panel Menu will display. Select YES to delete or NO to exit the Panel Menu.

CANCEL:
Select to exit the Panel Menu.

TV Guide On Screen

SCHEDULE:
The SCHEDULE Service screen allows you to review, edit and delete Record and Remind events.

SEARCH
SETUP
SCHEDULE
RECORDINGS
LISTINGS
Shows for Record or Remind listed here
Press Menu now for more Schedule choices
Move ♦ to highlight any show
and press Menu for show options
SCHEDULE
Friends Thu 6/24 8:10pm
North Shore Thu 6/24 8:04pm
Without a Trace Thu 6/24 8:05pm
CSI: Crime Scene Investigation Thu 6/24 8:59pm
Jamie Kennedy Experiment Thu 6/24 8:59pm
This Old House Hour Fri 6/25 4:00am
Ripley's Believe It or Not! Fri 6/25 5:59am
Today Fri 6/25 6:59am
STILL UNSOLVED
with Craig Smith
Friday 10:00pm
CLICK HERE

Press the INFO button while the SCHEDULE Service is highlighted on the Service Bar to display a Help screen.


Recordings catalogs a list of:
• Previously recorded shows
• Currently recording shows
Note: A DVR lists only shows on the current DVD. A PVR lists all recorded shows.
You can choose how the catalog is displayed
• Group
• List
And even customize further by
• Date
• Title
See details when you press Menu to open the "Recording Options" panel.
Just press to close this info box
STILL UNSOLVED
with Craig Smith
Friday 10:00pm
CLICK HERE

Use the CURSOR PAD ▲ or ▼ to highlight an event, and then press the MENU button to display the applicable Schedule Options Panel Menu options.

GO TO SERVICE BAR:
Select to highlight the Service Bar.

WATCH NOW/TUNE TO CHANNEL:
Select to exit the TV Guide On Screen system and tune to the highlighted program.

SET RECORDING:
Select to open a menu in which you can set a recording for the program (see page 61).

DELETE RECORDING:
Select to remove the recording from the schedule. A confirmation Panel Menu will display. Select YES to delete the recording or NO to exit the Panel Menu.

EDIT RECORDING:
Select to open a menu in which you can edit existing information (see page 61).

SET REMINDER:
Select to open a menu in which you can set a reminder for the program (see page 63).

DELETE REMINDER:
Select to remove the reminder from the schedule. A confirmation panel menu will display. Select YES to delete the reminder or NO to exit the panel menu.

EDIT REMINDER:
Select to open a menu in which you can edit existing reminder information (see page 63).

CANCEL:
Select to exit the Panel Menu.

How to Record:
The Record options can be set in the LISTINGS, SEARCH, and SCHEDULE Services. You can also edit record settings for a program in the SCHEDULE Services. There are 3 ways to set a program to record.

- Use the RECORD button on the Remote Control. Press the RECORD button to record the program Once with the current default setting. Each press of the RECORD button cycles through the RECORD frequency of Once (default), Regularly, Weekly and Cancel.

NOTE: *The specific Record Icon appears on the tile each time the RECORD button is pressed.*

- Use the Panel Menu record features.

1. Use the CURSOR PAD ▲ or ▼ to highlight a program and press the MENU button to access the Panel Menu.


SEARCH
SETUP
SCHEDULE
RECORDINGS
LISTINGS
SCHEDULE
CSI: Crime Scene Investigation Thu 6/24 8:59pm
Friends Thu 6/24 8:10pm
Jamie Kennedy Experiment Thu 6/24 8:59pm
Schedule Options
go to Service Bar
tune to channel
set recording
delete reminder
edit reminder
cancel
Jamie Kennedy Experiment (Comedy) Jamie pretends to be a marine biologist at the Miami Seaquarium, where he tries to convince a guard that he's communicating with a dolphin. Jamie Kennedy. TV14 (Strong Language, Suggestive Dialogue)
North Shore Thu 6/24 8:04pm
Ripley's Believe It or Not! Fri 6/25 5:59am
This Old House Hour Fri 6/25 4:00am
Today Fri 6/25 6:59am
Without a Trace Thu 6/24 8:05pm

2. Use the CURSOR PAD ▼ to highlight Set Recording and press the SELECT button to display the Record Options Panel Menu.

3. Use the CURSOR PAD ▲ or ▼ to highlight the Frequency field and press the CURSOR PAD ◄ or ► to select among Once, Regularly, Weekly or Off.

4. Press the CURSOR PAD ▼ to highlight the Start field, and then press the CURSOR PAD ◄ or ► to select in the range from 120 minutes early to 120 minutes late. The default time is ON Time.

5. Repeat step 4 for the End Field.

6. Use the CURSOR PAD ▼ to highlight the Recorder field and then press the CURSOR PAD ◄ or ► to select the Recording device.

7. Use the CURSOR PAD ▼ to highlight the Keep Until field and then press the CURSOR PAD ◄ or ► to select a save option.

8. Press the SELECT button to highlight SCHEDULE RECORDING. Press the SELECT button again to exit the menu or highlight CANCEL and press the SELECT button to close the menu and return to the highlighted program.

NOTE: *Steps 6, 7 and 8 are for connected IEEE1394 recording only.*

- Use Manual Recording:

1. From the SERVICE bar, use the CURSOR PAD ◄ or ► to highlight the SCHEDULE. Press the MENU button to display the Schedule Options Panel Menu.

2. Use the CURSOR PAD ▲ or ▼ to highlight New Manual Recording, and then press the SELECT button to access the Record Options Panel Menu.

3. Set the information in the Panel Menu fields.

4. After completing the information in the fields, press the SELECT button to highlight SCHEDULE RECORDING, and then press the SELECT button again to exit the menu or use the CURSOR PAD ▲ or ▼ to highlight CANCEL then press the SELECT button to exit the menu.

NOTE: *1. When setting Manual recording, the option DAILY is available instead of Regularly.*
2. A specific Record icon appears on the tile.

Recording Notification Banner:
If the channel you are watching is different from the one that is set to record, a notification banner appears and will prompt you before recording starts. The banner will ask you to choose to start or cancel recording. If no choice is made within 3 minutes, the banner will close automatically and the channel will tune to the one set to record. If you want the recording cancelled, select "Don't change; cancel recording" in the banner and press the SELECT button.


TV GUIDE
Recording starting!
TV Guide On Screen needs to change the channel at 8:10pm to record:
CBS 4 Without a Trace 8:00pm
change channel; start recording
don't change; cancel recording

Recording Conflict:
A recording conflict message will appear if:

- A program set to record overlaps with part of another program previously set to record.
- A program set to record overlaps with the program previously set to auto-tune (see page 63).
  Select these options:
- Record Anyway – The selected program will override an existing program set to record or auto-tune.
- Don't record this show – Cancels the recording.

How to Remind:
The Remind options can be set in the LISTINGS, SEARCH, and SCHEDULE Services. You can also edit remind settings for a program in the SCHEDULE Services. Set the Reminder to perform the following functions.

- Set to automatically turn ON the TV and tune to the channel at the scheduled reminder time.
- Set to automatically tune the TV, at the scheduled reminder time, to the channel specified by the reminder.
- Set to display an on-screen notification banner that reminds you that the program is about to start. You will be given the choices to tune to the program channel or cancel the reminder.

TV Guide On Screen

How to set a reminder:

- Set from the Panel Menu

1. Use the CURSOR PAD ▲ or ▼ to highlight a program and press the MENU button to access the Episode Options Panel Menu.
2. Use the CURSOR PAD ▼ to highlight SET REMINDER and press the SELECT button to access the Remind Options Panel Menu.

3. Use the CURSOR PAD ▲ or ▼ to highlight the frequency field, and then use the CURSOR PAD ◄ or ► to select from Once, Regularly, Weekly, Daily (Only available in Manual reminder), or Off.

4. Use the CURSOR PAD ▼ to highlight the Power on TV field, and then use the CURSOR PAD ◄ or ► to select YES (Turns the TV On automatically at the specified reminder time) or NO (Default setting).

5. Use the CURSOR PAD ▼ to highlight the Auto Tune TV field, and then use the CURSOR PAD ◄ or ► to select YES (Tunes the TV which is currently ON automatically to the channel specified at specified reminder time).

6. Use the CURSOR PAD ▼ to highlight the When field (set the time for displaying the reminder screen), and then use the CURSOR PAD ◄ or ► to select from 15 minutes early to 15 minutes late or On time (Default is 1 minute early).

7. Press the SELECT button to highlight Schedule reminder, and then press the SELECT button again to exit the menu or you can highlight Cancel and press the SELECT button to exit the menu or you can highlight Cancel and press the SELECT button to exit the menu.

NOTE: *Default options can be set for the values of the Remind Options Panel Menu fields (see page 66).*

- Set Manual reminder

1. From the Service bar, use the CURSOR PAD ◄ or ► to highlight SCHEDULE, and then press the MENU button to access the Schedule Options Panel Menu.
2. Use the CURSOR PAD ▲ or ▼ to highlight New Manual Reminder and then press the SELECT button to access the Remind Options Panel Menu.

4. Use the CURSOR PAD ▲, ▼, ◄, ► to highlight and enter information in the panel menu fields (Date, start/end time, channel, input, power on TV, auto tune TV, and frequency).

5. Press the SELECT button to highlight SCHEDULE REMINDER, and then press the SELECT button again to exit the menu or you can highlight Cancel and press the SELECT button to exit the menu.

NOTE: *1. When setting Manual Reminders, the Option Daily is available instead of Regularly.*
2. A specific Reminder icon appears on the tile.

Reminder Notification Banner

Depending on your option settings, a notification banner will appear at the scheduled reminder time.

Press the SELECT button to hide the Reminder banner, or, if more than one reminder appears, use the CURSOR PAD ▲ or ▼ to highlight a program. Press the SELECT button to tune to the program.

If no choice is made within 3 minutes, the banner closes automatically.

Remind Conflict

A remind conflict message will appear if:

- A program set with an auto-tune reminder has the same start time as an existing auto-tune reminder.
- A program set with an auto-tune reminder overlaps with a scheduled recording.

Select these options:

- Auto-Tune anyway – The selected program will override an existing program set to auto-tune.
- Proceed, No Auto-Tune – Set the program as a reminder but do not auto-tune.
- Don't set this reminder – Cancels the reminder.







SETUP:

The SETUP Service screen allows you to modify settings that were entered at initial TV Guide On Screen system setup (see page 49). The 3 settings will be the following:

- Change System settings
- Change channel display
- Change default options

Press the INFO button while the SETUP Service is highlighted on the Service Bar to display a Help screen.



Use the CURSOR PAD ▼ to highlight a setting option, and then press the SELECT button to access each setting.

TV Guide On Screen

CHANGE SYSTEM SETTINGS:
Use this option if you want to change something after completing initial TV Guide On Screen system setup.

1. From the SETUP screen, use the CURSOR PAD ▼ to highlight Change system settings, and then press the SELECT button to reconfirm your settings.


TV GUIDE
Confirm Your Settings
You have entered the following TV Guide On Screen system settings. If any setting is marked INCOMPLETE, you will not be able to use that feature until you complete that portion of TV Guide On Screen system setup.
ZIP code - 01730 (USA)
Cable Box on input "Cable" Ch. 3
Cable Box selected: code 044 (Archer)
VCR — code 096 (Aiwa)
Are the above settings correct?
Yes, everything is correct
Yes, but my channel lineup is incorrect
No, repeat setup process
Using your TV remote, move up or down to highlight your answer. Press Select to choose.

2. Use the CURSOR PAD ▲ or ▼ to highlight your selected options, and then press the SELECT button. Follow the On Screen instructions.

CHANGE CHANNEL DISPLAY:
Use this option to edit channel information that appears in the LISTINGS Service screen. The channel information that can be edited includes:

- Change the position order channels appear in the LISTINGS Service screen.
- Change the tune channel number.
- Change a channel to one of the following settings:
  - ON (Channel is displayed in LISTINGS)
  - OFF (Channel is not displayed in LISTINGS)
  - AUTO-HIDE (Channel is displayed in LISTINGS only when program information is available
- Change the service type for the source:
  - Cable
  - Cable Box
  - Over-the-Air
  - Antenna
  - Etc.

1. From the SETUP Screen, Use the CURSOR PAD ▼ to highlight Change Channel Display, and then press the SELECT button.

2. Highlight a channel row and press the SELECT button to access the Grid Options Panel Menu.


TV GUIDE
8:08
LISTINGS
SEARCH
SETUP
SCHEDULE
RECORDINGS
CHANNEL EDITOR
1 abc WCVB Cable Box 5 ON
INFO
Press SELECT to change the channel, tune channel number, turn channel on/off or Auto-Hide it, set cable or over-the-air or change the video input.
Grid Options
go back to Setup
channel on
service Cable Box
tune channel 5
position 1
done
cancel
2 FOX WFXT Cable Box 13 ON
3 CBS WBZ Cable Box 4 ON
4 NBC WHDH Air 7 ON
5 PBS WGBH Air 2 ON
6 WSBK Cable Box 14 ON
7 abc WCVB Air 5 ON
8 abc WCVB-DT Cable Box 805 ON
9 FOX WFXT Air 25 ON

3. Press the INFO button to view the On-Screen instructions.
4. Use the CURSOR PAD ▲ or ▼ to highlight one of the options, and make any necessary changes, and then press the SELECT button.

NOTE: *The Tune channel is the channel on which the TV receives a station depending on its type of cable, cable box or antenna service.*

CHANGE DEFAULT OPTIONS:
Use this option to change default settings:

- General Defaults
- Record Defaults
- Remind Defaults
- IR Defaults

GENERAL DEFAULT OPTIONS

1. From the SETUP screen, use the CURSOR PAD ▲ or ▼ to highlight Change Default Options and then press the SELECT button



2. Use the CURSOR PAD ▲ or ▼ to highlight General Default Options, and then press the MENU button to access the General Default Options Panel Menu.

3. Enter your choices in the Panel Menu fields:

- BOX SIZE: The initial Info box size (No, Small, Large, and Last Used -default)
- BOX CYCLE: The Info Box size rotation when the INFO button is pressed. (No Only, Small Only, Large Only, No and Small, No and Large, Small and Large, and All –default).
- AUTO GUIDE: Automatic access into the TV Guide On Screen system when the TV is turned ON (On-default and Off).

4. Press the SELECT button to highlight Done, and then press the SELECT button again to exit the menu or use the CURSOR PAD ▲ or ▼ to highlight Cancel. Then press the SELECT button to exit the menu.

RECORD DEFAULTS

1. From the SETUP screen, use the CURSOR PAD ▲ or ▼ to highlight Change Default Options and then press the SELECT button.

2. Use the CURSOR PAD ▲ or ▼ to highlight Record defaults and then press the MENU button to access the Record Defaults Panel Menu.

3. The following options woud not appear in the panel menu and should be deleted from the list and the screen “recorder choice”, how long to keep a Record event, the quality of the recording.

4. Press the SELECT button to highlight Done, and then press the SELECT button to exit the menu or use the CURSOR PAD ▼ to highlight Cancel. Then press the SELECT button to exit the menu.

REMIND DEFAULTS

1. From the SETUP screen, use the CURSOR PAD ▲ or ▼ to highlight Change Default Options and then press the SELECT button.

2. Use the CURSOR PAD ▲ or ▼ to highlight Remind defaults and then press the MENU button to access the Remind Defaults Panel Menu.

3. Enter the chosen information in the Panel Menu fields (Power On TV, auto-tune, when to display the Remind screen).

4. Press the SELECT button to highlight Done, and then press the SELECT button to exit the menu or use the CURSOR PAD ▼ to highlight Cancel. Then press the SELECT button to exit the menu.

IR DEFAULTS

IR Defaults lets you modify the channel dialing defaults if your cable box and/or VCR is not changing channels properly.

1. From the SETUP screen, use the CURSOR PAD ▼ to highlight Change Default Options and then press the SELECT button.

2. Use the CURSOR PAD ▲ or ▼ to highlight IR defaults and then press the MENU button to access the IR Defaults Panel Menu.



3. Enter the chosen information in the Panel Menu fields.

   - Cable box – if you have a cable box, indicates whether or not you want to modify the default channel dialing options.
     Choices are Yes and No (default).
   - Dial mode – select whether you must enter 2-digit or 3-digit (default) channel numbers to change channels on your cable box.
   - Enter key – indicate if you currently press the Enter key after you enter a channel number with your cable box remote.
     Choices are Yes and No (default).
   - VCR – if you have a VCR, indicates whether or not you want to modify the default channel dialing options.
     Choices are Yes and No (default).
   - Dial mode – select whether you must enter 2-digit (default) or 3-digit channel numbers to change channels on your VCR.
   - Enter key – indicate if you currently press the Enter key after you enter a channel number with your VCR remote.
     Choices are Yes and No (default).

4. Press the SELECT button to highlight Done, and then press the SELECT button to exit the menu or use the CURSOR PAD ▼ to highlight Cancel. Then press the SELECT button to exit the menu.

Channel Manager

Select **CHANNEL MANAGER** to set your Antenna options, run Auto Channel Scan, Check Signal Meter and Set Channel List.

1. Press CURSOR PAD ▲, ▼ or CHANNEL WHEEL to highlight function

2. Press the SELECT button or CURSOR PAD ▶ to select.





Signal Meter

Select **SIGNAL METER** when using an indoor or outdoor antenna. This feature will show the signal strength and peak values of the Antenna signal to help you adjust your antenna to optimize signal reception.

Use the **CURSOR PADS** and the **SELECT** button to highlight and select **CLOSE** to exit.

NOTE: *The Signal Meter will not be available (grayed out) when watching analog channels.*





Auto Channel Scan

This feature will automatically store active Analog and Digital channels in Auto Channel Scan memory.

1. Use the **CURSOR PAD** ▲ or ▼ or CHANNEL WHEEL to highlight **CABLE** or **AIR**.

2. Press the **CURSOR PAD** ◀ or ▶ to highlight the **START** or **RESET** option.

3. Press the **SELECT** button to start **AUTO CHANNEL SCAN**.

NOTE: *1. When a CableCARD is installed, Auto Channel Scan will not be available since channels will be fixed based on what was agreed upon by you and your cable operator.*
2. If certain channels are poor or not possible in cable(1) mode, set cable source to cable(2) by using the CURSOR buttons ◀ or ▶.





Channel Manager

Channel List
This function allows you to review which channels are labeled **(CH ID)**, which have been added to **CHANNEL MEMORY (SCAN)**, which are protected by **LOCK** and which are your **FAVORITE (FAV) CHANNELS**.

1. Use the **CURSOR PAD** to navigate the Channel List.
2. Press the **SELECT** button to select **ON** or **OFF** on the **SCAN** and **LOCK** columns.
3. To select **LOCK** column, input the access code. (Default access code: 0000)
4. Press the **FAV** button to set or remove the **FAVORITE** settings.
5. Press the **EXIT** button to return to normal viewing.





NOTE: *1. When a CableCARD is installed, the Channel List will be dependent on channels agreed upon by you and your cable operator.*
2. The Channel List cannot be updated by only changing the cable source. Auto Channel Scan must be performed for the Channel List to be updated.

Locks

This function will block out the picture and sound of the selected channel or video input. It can also be used to keep the TV from being viewed for a scheduled time period that you set.

The code to enter the Locks feature is a four digit access code number. The factory preset code is **0000**. Use the **NUMBER** buttons to enter the access code.

1. Use the **CURSOR PAD** ▲, ▼ or **CHANNEL WHEEL** to highlight the desired function in the **LOCKS** menu.

2. Press the **SELECT** button to select.



Change Access Code

1. To change the **ACCESS CODE NUMBER**, select **CHANGE ACCESS CODE** to change the factory preset code **(0000)** to your preference.

   If you forget your **ACCESS CODE NUMBER**, use the factory code **7777** to erase your key number. This will reset the access code number back to the factory preset **(0000)**.

2. Enter a new four digit number.

3. Press **EXIT** to quit the menu.



Engage Lock

When **ENGAGE LOCK** is selected, **SET CHANNEL LOCK** and **SET FRONT PANEL LOCK** can be set individually.

When **SET CHANNEL LOCK** is turned on, the picture and sound for the chosen channel will be blocked out.

When **FRONT PANEL LOCK** is turned on, all buttons on the Side Panel will be deactivated, except the **POWER** button.

When **MOVIE RATINGS** is selected, you can block various types of movies and video tapes based on motion picture ratings. Picture-in-Picture will also be blocked automatically (see page 71).

When **TV RATINGS** is selected, various types of television programming based on a parental guide ratings will be blocked. Picture-in-Picture will also be blocked automatically (see page 72).

Use **CANADIAN RATINGS** to block various types of movies and television programs based on the two rating systems used in Canada that you feel may be inappropriate due to its content (see pages 73-74).

NOTE: *If any Movie/TV Ratings are locked, Surf Mode PIP will not be available.*

Locks

Movie Ratings

Use Movie Ratings to prevent viewing of any movie that you feel may be inappropriate due to its content.

1. Use the CURSOR PAD ▲, ▼ or **CHANNEL WHEEL** to select the **MOVIE RATING** category that you want to block.

2. Press **SELECT** to block the **MOVIE RATING** that you have selected. Once rating is selected, for example PG-13, all movies rated PG-13 and higher (R, NC-17, and X) will be blocked.

3. Press **EXIT** to quit the menu or select **MOVIE RATING** to return to the previous menu.





Motion Picture Ratings Table

NOT RATED	Contains no rating. Not Rated (NR) and Not Applicable (NA) programs. Movie has not been rated or ratings do not apply.
G	General audiences. All ages admitted.
PG	Parental guidance suggested. Some material may not be suitable for children.
PG-13	Parents strongly cautioned. Some material may be inappropriate for children under 13.
R	Restricted. Under 17 requires accompanying parent or adult guardian.
NC-17	No one 17 and under admitted.
X	Adults only

NOTE: *1. A movie rating is dependent upon the movie that is viewed. If the movie does not carry a rating, the TV will not block it.*

*2. Blocking **NOT RATED** programs may block emergency programming, sports, news, public service announcements, religious programs and weather.*

*3. If a CableCARD is installed, your cable operator may provide an Emergency Alert System (EAS) message in the event of a local or national emergency with the purpose of alerting the general public. When you receive such messages, the Television will immediately tune to an **EAS** channel as directed by the **EAS** message. Please be advised that if the **EAS** channel is blocked using the **LOCKS** feature, you will not be able to tune to that channel.*

Locks

TV Ratings

Use **TV RATINGS** to prevent the viewing of any TV program that you feel may be inappropriate due to its content.

1. Use the **CURSOR PAD** ▲, ▼ or **CHANNEL WHEEL** to select the **TV RATING** category that you want to block.

2. Press **SELECT** to block the **TV RATING** that you have selected.

3. Press **EXIT** to quit the menu or select **TV RATING** to return to the previous menu.





TV Parental Guide Ratings Table

TV-Y	All children. The themes and elements in this program are specifically designed for a very young audience, including children from ages 2-6.
TV-Y7	Directed to older children. Themes and elements in this program may include mild physical or comedic violence, or may frighten children under the age of 7.
TV-G	General audience. It contains little or no violence, no strong language, and little or no sexual dialogue or situations.
TV-PG	Parental guidance suggested. The program may contain infrequent coarse language, limited violence, some suggestive sexual dialogue and situations.
TV-14	Parents strongly cautioned. This program may contain sophisticated themes, intense sexual situation, more intense violence and intensely suggestive dialogue.
TV-MA	Mature audiences only. This program may contain mature themes, indecent language, graphic violence, and explicit sexual content.
FV	Fantasy Violence
V	Violence
S	Sexual Situation
L	Adult Language
D	Sexually Suggestive Dialogue

NOTE: *1. If you Block **TV-14D**, you will still permit **TV-MA** programs; If you block **TV-14V**, you will automatically block **TV-MAV** programs, but you will still permit **TV-MALS** programs. This means that the TV will block violence in **TV-14** and higher (**TV-MA**), but not language and sex.*

2. TV program ratings are dependent on the broadcaster. If the program is not rated, the TV will not block it.

*3. If a CableCARD is installed, your cable operator may provide an Emergency Alert System (**EAS**) message in the event of a local or national emergency with the purpose of alerting the general public. When you receive such messages, the Television will immediately tune to an **EAS** channel as directed by the EAS message. Please be advised that if the EAS channel is blocked using the **LOCKS** feature, you will not be able to tune to that channel.*

Locks

Canadian Ratings (Eng)
Use **CANADIAN RATINGS (ENG)** to block any type of movie and television program in Canada that you feel might be inappropriate in its content.

1. Use the **CURSOR PAD ▲**, **▼** or **CHANNEL WHEEL** to select the **CANADIAN RATINGS (ENG)** category that you want to block.

2. Press **SELECT** to block the **CANADIAN RATINGS (ENG)** that you have selected. Once rating is selected, for example **C8+**, all movies and television programs rated **C8+** and higher (**G**, **PG**, **14+** and **18+**) will be blocked automatically.

3. Press **EXIT** to quit the menu or select **CANADIAN RATINGS (ENG)** to return to the previous menu.





Canadian Ratings English Table

C	Programming intended for children under age 8 - Violence Guidelines; Careful attention is paid to themes, which could threaten children's sense of security and well-being. There will be no realistic scenes of violence. Depictions of aggressive behaviour will be infrequent and limited to portrayals that are clearly imaginary, comedic or unrealistic in nature. Other Content Guidelines: There will be no offensive language, nudity or sexual content.
C8+	Programming generally considered acceptable for children 8 years and over to watch on their own - Violence Guidelines: Violence will not be portrayed as the preferred, acceptable, or only way to resolve conflict; or encourage children to imitate dangerous acts which they may see on television. Any realistic depictions of violence will be infrequent, discreet, of low intensity and will show the consequences of the acts. Other Content Guidelines: There will be no profanity, nudity or sexual content.
G	General Audience - Violence Guidelines: Will contain very little violence, either physical or verbal or emotional. Will be sensitive to themes which could frighten a younger child, will not depict realistic scenes of violence which minimize or gloss over the effects of violent acts. Other Content Guidelines: There may be some inoffensive slang, no profanity and no nudity.
PG	Parental Guidance - Programming intended for a general audience but which may not be suitable for younger children. Parents may consider some content inappropriate for unsupervised viewing by children ages 8-13. Violence Guidelines: Depictions of conflict and/or aggression will be limited and moderate; may include physical, fantasy, or supernatural violence. Other Content Guidelines: May contain infrequent mild profanity, or mildly suggestive language. Could also contain brief scenes of nudity.
14+	Programming contains themes or content which may not be suitable for viewers under the age of 14 - Parents are strongly cautioned to exercise discretion in permitting viewing by pre-teens and early teens. Violence Guidelines: May contain intense scenes of violence. Could deal with mature themes and societal issues in a realistic fashion. Other Content Guidelines: May contain scenes of nudity and/or sexual activity. There could be frequent use of profanity.
18+	Adult - Violence Guidelines: May contain violence integral to the development of the plot, character or theme, intended for adult audiences. Other Content Guidelines: May contain graphic language and explicit portrayals of nudity and/or sex.

Locks

Canadian Ratings (Frn)
Use **CANADIAN RATINGS (FRN)** to block Canadian French programs according to various program ratings that you feel might be inappropriate in its content.

1. Use the **CURSOR PAD ▲**, **▼** or **CHANNEL WHEEL** to select the **CANADIAN RATINGS (FRN)** category that you want to block.

2. Press **SELECT** to block the **CANADIAN RATINGS (FRN)** that you have selected. Once rating is selected, for example **8 ANS+**, all movies and television programs rated **8 ANS+** and higher will be blocked automatically.

3. Press **EXIT** to quit the menu or select **CANADIAN RATINGS (FRN)** to return to the previous menu.





Canadian Ratings French Chart

G	General - Programming intended for audiences of all ages. Contains no violence, or the violence content is minimal or is depicted appropriately with humor or caricature or in an unrealistic manner.
8 ans +	8 + General - Not recommended for young children - Programming intended for a broad audience but contains light or occasional violence that could disturb young children. Viewing with an adult is therefore recommended for young children (under the age of 8) who cannot differentiate between real and imaginary portrayals.
13 ans +	Programming may not be suitable for children under the age of 13 - Contains either a few violent scenes or one or more sufficiently violent scenes to affect them. Viewing with an adult is therefore strongly recommended for children under 13.
16 ans +	Programming is not suitable for children under the age of 16 - Contains frequent scenes of violence or intense violence.
18 ans +	Programming restricted to adults - Contains constant violence or scenes of extreme violence.

Timers

Select **TIMERS** to set your Clock, Sleep Timer and Day/Night Timer.

1. Use the **CURSOR** buttons ▲ or ▼ to highlight the function to be adjusted.

2. Press the **SELECT** button to select.



Set The Clock
The Clock must be adjusted before you can use the **DAY/NIGHT TIMER** feature.

1. Use the **CURSOR** button ▼ to highlight the chosen **TIME ZONE** settings. Use CURSOR buttons ◀ or ▶ to set TIME ZONE and press SELECT to set.

2. Press CURSOR button ▼ to select Date. Use CURSOR buttons ◀, ▶, ▲ or ▼ to set Month, Day and Year. Press SELECT to set.

3. Press CURSOR button ▼ to select Time. Use CURSOR buttons ◀, ▶, ▲ or ▼ to set Hour, Minute, AM or PM. Press SELECT to set.

4. If you observe Daylight Saving Time, press CURSOR button ▼ to select DAYLIGHT SAVING CHANGE and press SELECT to set.





5. Press **EXIT** to quit the menu or select **SET THE CLOCK** to return to the previous menu.

NOTE: *1. When **AUTOMATICALLY ADJUST CLOCK FOR DAYLIGHT SAVING CHANGES** is checked ✔, the TV will automatically calculate the clock adjustment for Daylight Saving.*
*2. When the CableCARD is used, the TV will **SET THE CLOCK** automatically.*
*3. The TV counts electrical pulses for regulating the **TIMERS**. When the power cord is unplugged then plugged in quickly, the clock is stopped momentarily and the **TIME** indication will become slow.*
4. Time and Date is automatically set by the TV Guide On Screen system. These settings cannot be changed manually.

Timers

Set Sleep Timer

Select this feature to set your **SLEEP TIMER** from 30 minutes to 3 hours (30 minute increments).

1. Press the **CURSOR PAD ▶** repeatedly to set your Timer from **0:00**, **0:30**, **1:00**, **1:30**, **2:00**, **2:30** and **3:00**.





Set Day/Night Timer

Select this feature to activate and set your TV's **DAY/NIGHT PICTURE MODE** automatically. This feature is not available until the clock is set.

1. Use the **CURSOR PADS** to highlight **SET DAY/NIGHT TIMER** settings.
2. Press the **SELECT** button to select.
3. Use the **CURSOR PADS** to select **DAY MODE ON** and to set it's **TIMER**. Press SELECT to set.
4. Use the **CURSOR PADS** to select **DAY MODE OFF** and to set it's **TIMER**. Press SELECT to set.
5. Press **EXIT** to quit the menu or select **SET DAY/NIGHT TIMER** to return to the previous menu.





On-Screen Display

Setup

Select **SETUP** when setting your TV up for the first time.

1. Use the **CURSOR** PAD ▲, ▼, ◀ and ▶ to select the sub-menu of your choice.

2. Press the **SELECT** button to select.





Menu Preference
Setup the Language and background of the Menu OSD.

Set the Language
This feature will allow you to select any one of three different languages for all on-screen displays.

1. Use the **CURSOR PAD** ◀ or ▶ to select the language of your choice.

2. Press **EXIT** to quit menu or select **MENU PREFERENCE** to return to previous menu.





Set the Menu Background
This function allows you to choose from two menu backgrounds.



1. Use the **CURSOR PAD** ▲ or ▼ to highlight **SET THE MENU BACKGROUND (SHADED OR SOLID)** of your choice. Use the CURSOR PAD ◄ or ► to select shaded or solid.

2. Select **SOLID** for a black background (no picture can be seen behind menu screen), select **SHADED** and a light background is visible.

3. Press **EXIT** to quit menu or select MENU PREFERENCE to return to previous menu.

Screen Saver
Continuous on-screen displays such as video games, stock market quotations, computer generated graphics, and other fixed (non-moving) patterns can cause permanent damage to the Plasma Television. Use the SCREEN SAVER feature to hide screen burn.



1. Use CURSOR PAD ▲ or ▼ to highlight Screen Saver's Main Picture Moving and Image Power options.
2. Use the CURSOR PAD ◄ or ► to select your choices.



Option 1
The whole picture will shift every 20 minutes by two pixels.

Option 2
The whole picture will shift every 40 minutes by two pixels.

Option 3
The whole picture will shift every 60 minutes by two pixels.

Image Power
This function allows you to choose power consumption reduction based on 3 levels (min., medium and max).

Screen Wipe
If pattern mark occurs, use Screen Wipe (White Field Signal) for at least 10 minutes to refresh any damage that may have occurred from a pattern mark. Screen Wipe can resolve pattern mark to a certain degree, if caution is not used, permanent damage may occur. Use the cursor pad ▲ or ▼ to highlight Screen Wipe.
Press the SELECT button to start.
Press the EXIT button to return to normal viewing.

Screen Saver Picture's Movement



Automatic Power Saving
Use this feature to turn power off automatically when a video input signal is not detected in 15 minutes.

***NOTE**: This feature is only available in Inputs 1-5.*

Setup

Set The Inputs
Use this feature to give a name to any of the live video inputs.



1. Press the **CURSOR PAD** ▲, ▼ to highlight the video inputs.

2. Press the **CURSOR PAD** ◄, ► to select your choices.



INPUT 4 Auto Link
Use this function to automatically turn the TV on and tune to INPUT 4 when it detects a video signal to INPUT 4.

1. Use the **CURSOR** PAD ▲, ▼, ◄ or ► to highlight and select the **AUTO LINK** setting of your choice.

Auto
When **AUTO** is selected, the TV will turn on and switch to Input 4 automatically, when the Input 4 input device is turned on. This is convenient when you want to watch a movie with your VCR, laserdisc player, or DVD player.

Remote
When **REMOTE** is selected, the TV will turn on and switch to Input 4 automatically when the Input 4 input device is turned on and the VCR, laserdisc, or DVD play button on your remote control is pressed. This is convenient when you want to record a movie with your VCR and watch it later.

Off
Select **OFF** to disable this function.

2. Press **EXIT** to quit menu or select **SET THE INPUTS** to return to previous menu.

NOTE: *1. Once the TV has been turned on using the **AUTO LINK** feature, it must be reset before **AUTO LINK** is used again. To do this, turn your VCR, laserdisc, or DVD player OFF. This feature is now reset and will turn on your TV as described above.*
*2. When using **REMOTE** mode, any remote control button will substitute for your video input device play button. However, intended operation is for use with your VCR, laserdisc, or DVD play button.*
*3. If no remote control button is pressed after the TV is turned on by **AUTO LINK**, the TV will automatically turn off after three hours.*

Set AV Net
Use this feature to control your external Audio/Video equipment using your Hitachi Plasma TV Remote Control. The IR Mouse cable must be properly connected for the AV NET feature to work.

1. Press the **MENU** button.

2. Use the **CURSOR PAD** ▼ or **CHANNEL WHEEL** to highlight **SETUP**.

3. Press the **SELECT** button to select.

4. Use the **CURSOR PAD** ▼ or **CHANNEL WHEEL** to highlight **SET AV NET** feature.

5. Press the **SELECT** button to select.



AV NET SETUP WIZARD (Example: A/V RECEIVER Setup)

1. Press the SELECT button to start the SETUP WIZARD.


AV Net Setup Wizard
Welcome to the AV Net Setup Wizard.
Before starting this wizard, please make sure that all devices are connected appropiately and the IR blasters are placed in front of the devices IR sensor.
Back
Start
Move SEL Return

2. Use the CURSOR PAD ▲ or ▼ to highlight YES or NO.
3. Press the SELECT button to select “YES”. (Select YES to setup an A/V Receiver or NO to setup other devices).
4. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.



5. Use the CURSOR PAD ◀ or ▶ to choose the brand name of your A/V Receiver.
6. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.


AV Net Setup Wizard : A/V Receiver Setup
Please choose the Brand Name of your A/V Receiver. If you can not find the Brand Name, please choose “Other” and proceed to the Learning mode by pushing the Learning Mode Button.
Brand Name ◂ Hitachi ▸ (1/54)
Learning Mode
Back
Next
Move ◂▸ Change Brand Name

7. Use the CURSOR PAD ◀ or ▶ to choose the preset IR Code.
8. Use the CURSOR PAD ▼ to highlight the “ POWER ” Test button.
   These On-screen buttons are called “ Soft Keys ”.
9. Press the SELECT button to pass the Power command through the IR Mouse and onto the A/V Receiver (Repeat steps 7 to 9 until finding the IR code that will power up the A/V Receiver. If the A/V Receiver turns ON, then you have found the correct preset IR code).
10. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.


AV Net Setup Wizard : A/V Receiver Setup
Please choose the IR Code Set number. If the matched Code does not exist, please choose “Other” and proceed to the Learning mode.
Brand Name Hitachi (44/54)
IR Code Set ◂ 1 ▸ (1/12)
Learning Mode
Test Button POWER SOURCE 1 VOL▲
Back
Next
Move ◂▸ Change IR Code

11. Use the CURSOR PAD ◀ or ▶ to select the TV Input that connects to the video and audio output of the A/V Receiver.
12. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.


AV Net Setup Wizard : A/V Receiver Setup
Brand Name Hitachi (44/54)
Brand Name 3 (3/12)
TV Input Settings
If you connect the video or audio output of the A/V Receiver to this TV, please select a TV Input.
TV Input ◂ Not Connected ▸
Back
Next
Move ◂▸ Change Input SEL Select

13. Use the CURSOR PAD ◀ or ▶ to select the A/V Receiver Source if you have connected the Monitor Out and Optical Out to the A/V receiver. Select “ Not Connected “ if not used.
14. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.


AV Net Setup Wizard : A/V Receiver Setup
Brand Name Hitachi (44/54)
IR Code Set 3 (3/12)
TV Input Hitachi
Monitor Out Settings
If you connect the Monitor out or Optical out to an A/V Receiver, please select an A/V Receiver Source.
Monitor Out Not Connected
Optical Out ◂ Not Connected ▸
Back
Next
Move ◂▸ Change Source SEL Select

15. If you would like to label your A/V Receiver Source, use the CURSOR PAD ◀ or ▶ to highlight " Yes " then press the SELECT button to continue. Selecting " No " will bypass the Source labeling.


AV Net Setup Wizard : A/V Receiver Setup
Brand Name Hitachi (44/54)
IR Code Set 3 (3/12)
TV Input Not Connected
Monitor Out Not Connected
Optical Out Not Connected
Would you like to relabel the Source buttons?
Back No Yes
Move SEL Select

16. Use the CURSOR PAD ▲ or ▼ to select your A/V Receiver Sources.

17. Use the CURSOR PAD ◀ or ▶ to label your A/V Receiver Sources.

18 Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.

19. Confirm all settings, then press the SELECT button to move on to the next SETUP screen.

AV Net Setup Wizard : A/V Receiver Setup
Brand Name Hitachi (44/54)
IR Code Set 3 (3/12)
TV Input Not Connected
Monitor Out Not Connected
Optical Out Not Connected
All settings are complete!
Back Next
Move SEL Select

20. Press SELECT to setup another device or use the CURSOR PAD ◀ or ▶ to highlight " No thanks, I'm done ", then press the SELECT button to exit the A/V NET SETUP.


AV Net Setup Wizard : A/V Receiver Setup
Congratulations!
Your A/V Receiver is now connected to your AV network.
Would you like to setup another device?
No thanks, I'mdone. Yes
Move SEL Select

AV NET SETUP WIZARD (Example: DVD Setup)

1. Press the SELECT button to start the SETUP WIZARD.

AV Net Setup Wizard
Welcome to the AV Net Setup Wizard.
Before starting this wizard, please make sure that all devices are connected appropiately and the IR blasters are placed in front of the devices IR sensor.
Back Start
Move SEL Return

2. Use the CURSOR PAD ▲ or ▼ to highlight NO.
3. Press the SELECT button to select. (Select NO to setup other devices).
4. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.



5. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight the device. (Example : DVD Setup).
6. Press the SELECT button to select.
7. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.

8. Use the CURSOR PAD ◀ or ▶ to choose the brand name of your DVD.
9. Press the CURSOR PAD ▼ to highlight the IR CODE Set, then use the CURSOR PAD ◀ or ▶ to choose the preset IR Code.
10. Use the CURSOR PAD ▼ to highlight the " POWER " Test button.
    These On-screen buttons are called " Soft Keys ".
11. Press the SELECT button to pass the Power command through the IR Mouse and onto the DVD.
    (Repeat steps 9 to 11 until finding the IR code that will power up the A/V Receiver. If the DVD turns ON, then you have found the correct preset IR code).
12. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.


AV Net Setup Wizard : Device Settings
DVD Settings
Brand Name ◂ Hitachi ▸ (31/77)
IR Code Set 1 (1/5)
Transmission Test
Test Button POWER ▶ CH▲
Back Next
Move ◂▸ Change Brand Name

13. Use the CURSOR PAD ◀ or ▶ to select the TV Input that connects to the video and audio output of the DVD.
14. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.


AV Net Setup Wizard : Device Settings
DVD Settings
Brand Name ◂ Hitachi ▸ (31/77)
IR Code Set 1 (1/5)
Inputs settings
Video Input ◂ Not Connected ▸
Audio Input Not Connected
Back Next
Move ◂▸ Change Source SEL Select

15. Confirm all settings, then press the SELECT button to move on to the next SETUP screen.

16. Press the SELECT button to select YES to Setup another device. Press the CURSOR PAD ◀ or ▶ to highlight " No thanks, I'm done ", then press the SELECT button to exit the A/V NET SETUP.

AV Net Setup Wizard : Device Settings
Congratulations!
Your DVD is now
connected to your AV network.
Would you like to setup another device?
No thanks, I'mdone. Yes
◂▸ Move SEL Select

Learning Mode

This function of the AV NET allows the user to use equipment that is not supported by the AV/NET codes. After programming your equipment to the AV NET and the Soft Keys do not work, you can manually "LEARN" each one by completing the Learning Mode. The Learning Mode will transfer any remote control button IR code of your equipment to the "Soft Keys" of your AV NET.

Learning Mode (Example: A/V Receiver Setup)

1. Press the SELECT button to start the SETUP WIZARD.

AV Net Setup Wizard
Welcome to the AV Net Setup Wizard.
Before starting this wizard, please make sure
that all devices are connected appropiately
and the IR blasters are placed in front of the
devices IR sensor.
Back Start
Move SEL Return

2. Use the CURSOR PAD ▲ or ▼ to highlight YES.
3. Press the SELECT button to select.
4. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.



5. Use the CURSOR PAD ◀ or ▶ to select "Other" from brand name choices.
6. Use the CURSOR PAD ▲ or ▼ to highlight "Learning Mode" then press the SELECT button.


AV Net Setup Wizard : A/V Receiver Setup
Please choose the Brand Name of your A/V Receiver. If you can not find the Brand Name, please choose "Other" and proceed to the Learning mode by pushing the Learning Mode Button.
Brand Name ◂ Other ▸
Learning Mode
Back Next
Move ◂▸ Change Brand Name

7. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to select the Soft Key to learn (Ex. VOL ▲), then press the SELECT button.


AV Net Setup Wizard : Custom Settings
Select the A/V Receiver softkey to learn?
TV Softkeys
POWER CH▲ VOL▲
MUTE CH▼ VOL▼ AUDIO
SOURCE 1 SOURCE 2 SOURCE 3 SOURCE 4 SOURCE 5
SOURCE 6 SOURCE 7 SOURCE 8 SOURCE 9 SOURCE 10
Back Done
Move SEL Select

8. Press and hold the VOL ▲ button of your A/V Receiver remote control while pointing directly at the learning AV NET sensor of the Plasma TV (located at the lower right corner of the screen) at a distance of 3.2 feet or 1 meter maximum.


AV Net Setup Wizard : A/V Receiver Setup
Press and hold desired button to transfer the command to AV NET.
VOL▲
Please wait while AV NET Learns the command....
Move SEL Select

9. If the IR code transfer was not completed, the screen below appears. Repeat step 8 to try again.



10. If the IR code transfer was successful, the screen below appears, then select "OK" to continue setup.

11. Select another Soft Key to learn or select DONE to move on to the next screen.


AV Net Setup Wizard : Custom Settings
Select the A/V Receiver softkey to learn?
TV Softkeys
POWER CH▲ VOL▲
MUTE CH▼ VOL▼ AUDIO
SOURCE 1 SOURCE 2 SOURCE 3 SOURCE 4 SOURCE 5
SOURCE 6 SOURCE 7 SOURCE 8 SOURCE 9 SOURCE 10
Back Done
Move SEL Select

12. Select the Test button VOL ▲ to check the response of the device to this command.
13. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.


AV Net Setup Wizard : A/V Receiver Setup
Select the Test button. If device responds to this command, proceed to "Next". Otherwise, try another IR Code Set number.
Brand Name Other
IR Code Set Other
Learning Mode
Test Button POWER SOURCE 1 VOL▲
Back Next
Move SEL IR Out

14. Use the CURSOR PAD ◀ or ▶ to select the TV Input that connects to the video and audio output of the A/V Receiver.
15. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.


AV Net Setup Wizard : A/V Receiver Setup
Brand Name Other
IR Code Set Other
TV Input Settings
If you connect the video or audio output of the A/V Receiver to this TV, please select a TV Input.
TV Input ◂ Not Connected ▸
Back Next
Move ◂▸ Change Input SEL Select

16. Use the CURSOR PAD ◀ or ▶ to select the A/V Receiver Source if you have connected the Monitor Out and Optical Out to the A/V Receiver. Select “Not Connected” if not used.
17. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next step.

AV Net Setup Wizard : A/V Receiver Setup
Brand Name Other
IR Code Set Other
TV Input Not Connected
Monitor out Settings
If you connect the Monitor out or Optical out to an A/V Receiver, please selcet an A/V Receiver Source.
Monitor Out ◂Not Connected▸
Optical Out Not Connected
Back Next
Move Change Input SEL Select

18. If you would like to label your A/V Receiver Source, use the CURSOR PAD ◀ or ▶ to highlight “Yes”, then press the SELECT button to continue. Selecting “No” will bypass the Source Labeling.


AV Net Setup Wizard : A/V Receiver Setup
Brand Name Other
IR Code Set Other
TV Input Not Connected
Monitor Out Not Connected
Optical Out Not Connected
Would you like to relabel the Source buttons?
Back No Yes
Move SEL Select

19. Use the CURSOR PAD ▲ or ▼ to select your A/V Receiver Sources.
20. Use the CURSOR PAD ◀ or ▶ to label your A/V Receiver Sources.
21. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.



22. Confirm all settings, then press the SELECT button to move on to the next SETUP screen.

AV Net Setup Wizard : A/V Receiver Setup
Brand Name Other
IR Code Set Other
TV Input Not Connected
Monitor Out Not Connected
Optical Out Not Connected
All settings are complete!
Back Next
Move SEL Select

23. Select “YES” to setup another device or select “No, thanks, I’m done” to exit the AV Net setup.


AV Net Setup Wizard : A/V Receiver Setup
Congratulations!
Your A/V Receiver is now connected to your AV network.
Would you like to setup another device?
No thanks, I’m done. Yes
Move SEL Select

Learning Mode (Example: CUSTOM/DVD 3 Setup)

1. Press the SELECT button to start the SETUP WIZARD.

AV Net Setup Wizard
Welcome to the AV Net Setup Wizard.
Before starting this wizard, please make sure that all devices are connected appropiately and the IR blasters are placed in front of the devices IR sensor.
Back Start
Move SEL Return

2. Use the CURSOR PAD ▲ or ▼ to highlight NO.
3. Press the SELECT button to select “NO”. (Select NO to setup other devices).
4. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.



5. CURSOR PAD ◀, ▶, ▲ and ▼ to highlight “Custom”, then press the SELECT button to select.
6. Select NEXT to continue.

7. Use the CURSOR PAD ◀ or ▶ to choose the device you wish to learn. (Example: DVD 3)
8. Select NEXT to continue.

9. Select the DVD 3 softkey to learn. (Example: PLAY ▶ button).
10. Select NEXT to continue.



11. Press and hold the ▶ "Play button" of the DVD remote control while pointing directly at the learning AV NET sensor of the Plasma TV (located at the lower right corner of the screen) at a distance of 3.2 feet or 1 meter maximum.


AV Net Setup Wizard : Custom Settings
Press and hold desired button to transfer the command to AV NET.
Please wait while AV NET
Learns the command....
Move
SEL Select

12. If the IR Code transfer was successful, the screen below appears, then select "OK" to continue setup.

13. Select another softkey to learn or select "DONE" to move on to the next screen.



14. Select the Test button ▶ "Play button" to check the response of the device to this command.
15. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.



16. Use the CURSOR PAD ◀ or ▶ to select the TV Input that connects to the video and audio output of the DVD.
17. Use the CURSOR PAD ◀, ▶, ▲ and ▼ to highlight NEXT, then press the SELECT button to move on to the next SETUP screen.

18. Confirm all settings, then press the SELECT button to move on to the next SETUP screen.

19. Continue with the normal procedures to setup TV Input, Monitor Out, Optical Out and the labeling of the source buttons.
20. Select “YES” to setup another device or select “No thanks, I’m done” to exit the AV NET setup.



NOTE:
1. *After a successful A/V NET setup to a chosen TV Input, the user can access soft key controls by selecting the device in the inputs menu.*
2. *Each Device and Custom setting only accepts one device at a time. The second device/custom setup will give the user the options to either modify or delete the device.*
3. *When setting up devices that have Monitor Out options (examples: A/V receiver, VCR), the Monitor Out and Audio Out will have default settings of TV Tuner out and Fixed respectively.*
4. *Before changing or modifying the Video and Audio Inputs, both should be set to “Not Connected” to access available options.*
5. *The device label will show on the Inputs menu until deleted or modified.*
6. *The AV NET setup will have priority over the Input setup.*
7. *For devices which have any or all of these functions, Play, Rewind, Fast Forward, Record, Stop and Pause, the Remote Control equivalent buttons may be used to perform these operations.*

Setup

Set Closed Caption

Closed Captions are the dialogue, narration, and/or sound effects of a television program or home video which are displayed on the TV screen. Your local TV program guide denotes these programs as CC or .



1. Use the **CURSOR PAD** ◀, ▶, ▲ and ▼ to highlight and select the function to change.

2. Press **EXIT** to quit menu or select **SET CLOSED CAPTION** to return to the previous menu.



Caption Display:

ON/OFF will turn the CC display on or off.
AUTO will turn the CC display on when Mute/Soft Mute is on.

Analog Captions:

Set **CAPTIONS** for Analog programs. This function will help choose and set available mode and channel.

Caption Mode:

CAPTIONS is for the program you are viewing.
TEXT is for additional information such as news reports or a TV program guide. This information covers the entire screen and viewing the TV program is not possible. Text may not be available with every CC program.

Channel:

1 is used for the primary language (usually English).
2 is sometimes used for a second language (may vary by region).
3 is sometimes used for a third language (may vary by region).
4 is sometimes used for a fourth language (may vary by region).

Digital Captions

Set captions for digital programs. This function will help choose and set available language, font, size and style of digital captions.



1. Use the **CURSOR PAD** ◀, ▶, ▲ or ▼ to highlight and select desired **DIGITAL CAPTIONS** feature.

2. Press **EXIT** to quit menu or select **SET CLOSED CAPTION** to return to the previous menu.

NOTE: *1. Some types of digital closed captions will not work with this TV.*
*2. Caption Display will not work when viewing a 480p, 720p, or 1080i input via the **COMPONENT: Y-PBPR** inputs.*
*3. When **PIP SURF** is on, Closed Caption will not work.*
4. Digital Captions Font Style are sometimes different from the Font Style of Analog Captions.
5. Closed Caption and Digital Captions availability and content depends on the broadcaster. Closed Caption is available when Closed Caption icon is displayed on screen.
6. Digital Captions will not be available (grayed out) when using analog channels.

Set Monitor Out
This feature will select the source of the Monitor Output.



Monitor:
Select **MONITOR** to output the audio and video signals of the chosen input source **(CABLE, AIR, INPUT 1-5)** to a VCR or other A/V device.



TV Tuner Out:
Select **TV TUNER OUT** to output the audio and video signals of the last watched Antenna Source **(CABLE, AIR).**

Fixed
Select **AUDIO OUT FIXED** to have the Audio at fixed volume.

Variable
Select **AUDIO OUT VARIABLE** to have Audio volume that can be controlled by the Plasma TV Volume Up/Down.

Video Out	Audio Out	Use
Monitor	Fixed	To record currently viewed Video and Audio.
Monitor	Variable	When an external device like a monitor or Hi-Fi audio system is connected to the audio and video output of the TV. You can control the volume output by changing the volume of the TV.
TV Tuner Out	Fixed	To record currently viewed Video and Audio from either Cable or Air.

1. Use **CURSOR PAD** ▲ or ▼ to highlight the function to change
2. Use the **CURSOR PAD** ◄ or ► to select the function.
3. Press **EXIT** to quit menu or select **SET MONITOR OUT** to return to previous menu.

NOTE: *1. When **TV TUNER OUT** is selected, **VARIABLE AUDIO OUT** will not be available (grayed out).*
2. When using MONITOR OUT for recording, set the VIDEO OUT to MONITOR.

MONITOR: Available Monitor Out Signals

Input Mode				Monitor Out			
				S-Video	Video	L/R	HiFi
ANT (Air or Cable)	Digital Channel	No Macrovision	S-Video	YES	YES	YES	YES
		Macrovision	S-Video	-	-	-	YES
	Analog Channel		Video	-	YES	YES	YES
Input 1	HDMI_1			-	-	-	YES
	S-Video_1			YES	YES	YES	YES
	Video_1			-	YES	YES	YES
Input 2	HDMI_2			-	-	-	YES
	S-Video_2			YES	YES	YES	YES
	Video_2			-	YES	YES	YES
Input 3	Y-PbPr_3			-	-	-	YES
	Video_3			-	YES	YES	YES
Input4	Y-PbPr_4			-	-	-	YES
	Video_4			-	YES	YES	YES
Input5	S-Video_5			YES	YES	YES	YES
	Video_5			-	YES	YES	YES

TV TUNER OUT: Available Monitor Out Signals

Input Mode				Monitor Out (TV Tuner Out)			
				S-Video	Video	L/R	HiFi
ANT (Air or Cable)	Digital Channel	No Macrovision	S-Video	YES ANT	YES ANT	YES ANT	YES ANT
		Macrovision	S-Video	-	-	-	YES ANT
	Analog Channel		Video	-	YES ANT	YES ANT	YES ANT
Input 1	HDMI_1		Y-PbPr	YES ANT digital only	YES ANT	YES ANT	YES ANT
	S-Video_1						
	Video_1						
Input 2	HDMI_2		Y-PbPr				
	S-Video_2						
	Video_2						
Input 3	Y-PbPr_3						
	Video_3						
Input4	Y-PbPr_4						
	Video_4						
Input5	S-Video_5						
	Video_5						

Upgrades

This feature shows software information and easy upgrade procedure. This function allows the TV software to be upgraded by using a flash card **(MMC CARD).** If a future software upgrade is required for your TV, **HITACHI** will notify and provide you with a flash card. In order to receive written notification and the flash card, please complete and return the warranty card.

1. Insert **MMC CARD**
2. Press the **CURSOR PAD** ▲ or ▼ to highlight **UPGRADE NOW**.
3. Press the **SELECT** button to select and start upgrading.

NOTE: *Any power interruption during the upgrade process will cancel the upgrade. When this happens, repeat the upgrade procedure.*





Set Stand-By Mode

This function sets the IEEE1394 in Stand-By Mode to ON or OFF. Certain digital devices have a power save feature, in which the device automatically powers OFF when not in use (sleep mode). Only by setting the IEEE1394 function in Stand-By mode to ON, will the TV be able to control a device that is in sleep mode.

Use CURSOR PAD ▲ or ▼ to highlight "IEEE1394 Stand-By" and press SELECT to set this option.



NOTE: *By turning on the IEEE1394 function, your TV will no longer be set for power saving Stand-By mode. The IEEE Stand-By function must be set to OFF to return your TV set to power saving Stand-By mode.*



Power Swivel

This feature controls the motorized stand. It allows the customer to turn the plasma display left or right using the remote control. This feature is only available when the Table Top Stand is connected.

1. Use the **CURSOR PAD** ◀ or ▶ to unlock or lock the Power Swivel.
   Exit the OSD menu system before controlling the motorized stand.
2. Press the **CURSOR PAD** ▶ to to rotate the TV to the right.
3. Press the **CURSOR PAD** ◀ to to rotate the TV to the left.
4. Release the **CURSOR PAD** to stop rotation.



NOTE:
1. *The Power Swivel has a maximum turning radius of 30° (left and right).*
2. *Do not place any objects in the path of the monitor when using the power swivel feature.*
3. *Before using the power swivel, please make sure that the path of the monitor is clear of any fingers, hands or any other body parts to avoid causing injury.*
4. *When the Picture-In-Picture (PIP) or Freeze mode is ON, the Power Swivel is disabled.*

Equipment Care and Troubleshooting

DO

Dust the screen and cabinet with a soft cloth.

Clean the screen with a soft cloth moistened in warm water and dry with a soft cloth. A mild soap may be used if the screen is extremely dirty.

Place your Plasma Television away from extreme heat, humidity, and extremely dusty places.

Remove the plug from the wall outlet if your Plasma Television will not be used for a long period of time, for instance, when you go on vacation.

DO NOT

Do not clean your screen with strong cleaners, polishes or a chemically treated cloth.

Do not place rubber or vinyl products or cellophane tape on your Plasma Television.

Avoid repeatedly touching the screen.

Do not subject the remote control to shocks such as dropping it on the floor, etc. This may cause damage to the precision parts.

Avoid placing the remote control in a high humidity place or getting it wet. Do not leave it on or near a heater. Excessive heat or moisture may cause the unit to fail.

When the batteries run down, remote control operation will become erratic or become unresponsive. Replace the old batteries with two new “AA” size batteries. Do not use an old battery with a new battery.

Exposing the screen to direct sunlight for a long period of time or heat may cause damage to the plasma screen.

TROUBLESHOOTING

Your **HITACHI** Plasma Television incorporates advanced power surge protection technology designed to protect against component or circuit damage due to external or internal voltage power surges.

IF YOUR TELEVISION SHOULD APPEAR TO HAVE A LOSS OF POWER, PLEASE FOLLOW THIS PROCEDURE:

1. Press the **POWER SWITCH (ON/OFF SWITCH)** once.
2. If there is still no power, wait 30 seconds and press the **POWER SWITCH** again.
3. If there is still no power, unplug the power cord from the wall. Wait 30 seconds and plug the power cord back in. Press the **POWER SWITCH** again.

This protective technology should provide for years of lasting entertainment from your **HITACHI** Plasma Television.

SYMPTOMS / CHECK THESE ITEMS AND TRY THESE ADJUSTMENTS	Be sure external connection is correct	Be sure power cord is plugged in	Be sure TV is switched "ON"	Try another channel (station trouble)	Check antenna connections (back of TV)	Check antenna for broken lead-in wire	Check outside antenna	Check for local interference	Adjust Contrast control	Adjust Brightness control	Adjust Color control	Adjust Tint control	Adjust Volume control
No Picture, no sound	●	●	●	●	●	●	●						
Sound OK, picture poor	●			●	●	●	●	●	●	●			
Picture OK, sound poor	●			●	●	●	●	●					●
Picture blurred	●			●	●	●	●	●					
Lines or streaks in picture				●	●	●	●	●					
Poor reception on some channels				●	●	●	●	●					
Picture rolls vertically				●				●					
No color	●			●	●	●	●				●		
Poor color	●			●	●	●	●				●	●	

Reception Problems



IGNITION NOISE:
Black spots or horizontal streaks may appear, picture may flutter or drift. Usually caused by interference from automobile ignition systems, neon lamps, electrical drills, and other electrical appliances.

GHOSTS:
Ghosts are caused by the television signal following two paths. One is the direct path and the other is reflected from tall buildings, hills or some other objects. Changing the direction or position of the antenna may improve reception. Ghosting may also be caused by defects in the antenna system such as unshielded leads or connecting several sets to the same antenna without using multiple antenna couplers.

SNOW:
If your receiver is located in the fringe area of a television station where the signal is weak, your picture may be marred by the appearance of small dots. When the signal is extremely weak, it may be necessary to install a special antenna to improve the picture.



RADIO FREQUENCY INTERFERENCE:
• RADIO FREQUENCY INTERFERENCE:
The interference produces moving ripples or diagonal streaks, and in some cases, causes loss of contrast in the picture.
• PREVENTION OF AN OBSTACLE TO RADIO RECEIVERS
This television has been designed pursuant to the FCC class B Rules. This is to prevent a problem to Radio receivers. If this television causes a problem to Radio receivers, then take the following steps:
- Keep the television away from Radio.
- Adjust Radio antennas in order for the television not to receive interference.
- The antenna cable of Radio should be kept away from the television.
- Use a coaxial cable for antenna.
You can check if this television influences Radio receivers by turning off all other equipment other than the television. If you find a problem receiving Radio when using the television, check the instructions mentioned above.

BLOCK NOISE (DIGITAL INPUT):
Fuzzy blocks may appear in some area or the whole area of the screen. This is usually caused by interference from automobile ignition systems, neon lamps, electrical drills, ghosting of the image and weak signals.

BLACK SCREEN:
When using an antenna, weak signals will display a black screen. It may be necessary to upgrade your antenna.

NOTE: *The TV set can generate sound distortion in external devices such as a radio. Please separate radio equipment from the TV set to a considerable distance.*

Troubleshooting

1. Plasma Television Troubleshooting

No.	Items	Notes
1	Buzzing sound from Plasma display panel.	A buzzing sound may be heard when the plasma television is turned on in a very quiet room. This is due to the plasma panel drive circuit when it is functioning. The buzzing sound is normal and is not a malfunction.
2	Infrared interference	Some infrared rays are emitted from the plasma television panel that might affect the operation of other infrared controlling equipment.
3	Bright and dark spots	High precision technology is used to manufacture the plasma television. But there maybe points that do not illuminate, points that are too bright, and points with color different from that of the periphery. Please note that this is not a mafunction.
4	Picture Image	In some cases, residual images may remain after the short term display of still images when the picture changes.
5	Display panel surface temperature is too high.	The plasma display panel display images by means of electrical discharges inside the panel. This may cause the temperature of the panel surface to increase. Please note that this is not a malfunction.
6	Plasma Surface	A reinforced glass filter is installed over the plasma panel surface. A strong impact to the front panel risk a danger of glass breakage.
7	Transportation	Please transport the plasma television in it's packing box and placed in an upright position. Do not transport the plasma television in a horizontal position. This increases the posibility of panel breakage and pixel failure.
8	Granular spots	When a screen is seen at point-blank range, a random fine grain may be visible in the dark areas of the picture.
9	High temperature environment	High temperature affect the electric discharge/luminescence characteristic of the PDP panel. Do not place the plasma television in high temperature environments.
10	Operation	Operating altitude: 800 to 1,114hPa (6,194ft to -2,484ft). Operating temperature: 41˚F to 95˚F.
11	Storage	Storage altitude: 300 to 1,114hPa (31,912ft to -2,484ft). Storage temperature: 5˚F to 140˚F
12	Power ON or OFF	Repeatedly turning the plasma television Power ON and OFF at short intervals may result in failure of the television.

2. TV Guide On-Screen™ System Frequently Asked Questions

My Guide listings disappeared after a power failure.
You should begin to receive listings again within 24 hours.

Some channel numbers in the Guide are incorrect.
You can correct them using Change Channel Display under Setup.

I have not received any Guide show listings.
Listings usually begin to appear within 24 hours after a successful Setup. It may take up to 5 days to receive a full 8 days of program listings.

- Check the connections between the TV, cable, antenna, and the IR cable if using a cable box.
- Verify Setup information under Change System Settings.
- Make sure the cable box is On, if applicable.
- Review Screen 4 and Screen 5 in the Initial Guide Setup section.

A show I set to Record did not occur.

- Make sure your recorder is turned Off before the recording begins.
- Make sure there is a tape or DVD in the VCR or DVD Recorder.
- Check the Schedule menu and verify that the show is listed before recording begins.
- Check the placement of the IR cable in front of your recorder.

The TV did not tune to a show I scheduled with the Reminder feature.

- Check the Schedule menu and verify that the show is listed.
- If you have a cable box, check the IR cable connection.

I set a show to Auto-Tune and it did not.

- Check the Schedule menu and verify that the show is listed as a Reminder.
- Highlight the show under Listings and do the following:
  - Press the Menu button on the remote.
  - Use the down arrow to highlight Edit Reminder, and press SELECT.
  - Verify the Auto-Tune option reads Yes.
- The TV must be On at the scheduled time for Auto-Tune.

I set a show with the Power On TV option and it did not.

- Check the Schedule menu and verify that the show is listed as a Reminder.
- Highlight the show under Listings and do the following:
  - Press the Menu button on the remote.
  - Use the down arrow to highlight Edit Reminder, and press SELECT.
  - Verify the Power On TV option reads Yes.
  - The TV must be Off at the scheduled time for Power On TV.

TV Guide On-Screen™ Frequently asked quiestions continued

If I add a recorder or change my cable service, how do I change my Setup information?

1) Highlight the Setup Service in the Guide.
2) Use the down arrow to select Change System Settings.
3) Follow the on-screen instructions.

A show entry in the Guide reads "No Listing." What does that mean?
Show information for that entry was not available during the last Guide information update (download). Show information is updated on a daily basis.

When I entered the Guide, I was asked to choose from more than one channel lineup. What should I do?
Select the lineup that most closely matches the one for your area. If after you choose the lineup, you want to make changes:

1) Highlight the Setup Service in the Guide.
2) Use the down arrow to select Change Channel Display or change system settings.
3) Follow the on-screen instructions.

What do the color for shows in the Listings and Search screens indicate?
Green=Sports; Dark Blue=Children's; Purple=Movies; Teal=Other Show

If I have a power outage, do I need to complete Setup again?
No; Setup information is stored in TV Guide On Screen.

Is Help available in the Guide? If so, how do I find it?
Yes. Highlight any of the 5 main Services (i.e., Listings, Schedule, Recordings, Setup, Search) and press the Info Button. An Expanded Info Box displays additional help information; press Info again to close the box.

Help is also available in a Panel Menu. Press the Info Button to display an Expanded Info Box; press Info again to close the box.

After some show titles, I have noticed from 1 to 4 stars (****). What does that mean?
These stars are a broadcast-industry rating system used to inform you of a show's quality. The more stars, the better the rating.

I have seen the word "download" in reference to the Guide. What does that mean?
A download sends channel and show information to a TV Guide On Screen device. A download happens at least once a day.

Can I set a Record or Remind event without highlighting a show title in the Guide?
Yes. TV Guide On Screen has a Manual Record and Remind feature. Highlight Schedule and press menu. Choose the event type, press SELECT and then enter date, start and stop time, channel number, etc.

What do the frequencies for Record and Remind mean?

- **Once**—records/reminds the show one time
- **Daily** (manual only)—records/reminds the time, channel, and input combination Monday through Friday
- **Regularly**— records/reminds for the channel/time combination on any day of the week, on the same channel
- **Weekly**— records/reminds for the channel/time combination on a specific day of the week
- **Off** (not cancel)—keeps the show in the schedule list but will not record/remind the show until the frequency is changed

How can I look for a specific show in the Guide?
Search lets you find shows by Category (HDTV, Movies, Sports, Children, Educational, News, Variety, Series), Keyword, or Alphabetical.

In the United States, TV GUIDE and other related marks are registered marks of Gemstar-TV Guide International, Inc. and/or one of its affiliates. In Canada, TV GUIDE is a registered mark of Transcontinental Inc., and is used under license by Gemstar-TV Guide International, Inc.

The TV Guide On Screen system is manufactured under license from Gemstar-TV Guide International, Inc. and/or one of its affiliates.

The TV Guide On Screen system is protected by one or more of the following issued United States patents 6,498,895; 6,418,556; 6,331,877; 6,239,794; 6,154,203; 5,940,073; 4,908,713; 4,751,578; 4,706,121.

Gemstar-TV Guide International Inc. and/or its related affiliates are not in any way liable for the accuracy or availability of the program schedule information or other data in the TV Guide On Screen system and cannot guarantee service availability in your area. In no event shall Gemstar-TV Guide International, Inc. and/or its related affiliates be liable for any damages in connection with the accuracy or availability of the program schedule information or other data in the TV Guide On Screen system.

PLUG AND PLAY

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Cable Compatible Television Apparatus- Tèlèvision câblocompatible, Canada.

This Plasma Television receiver will display television closed captioning, (CC or), in accordance with paragraph 15.119 of the FCC rules.

AGENCY REGULATORY INFORMATION

Federal Communications Commission Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Hitachi Home Electronics (America), Inc. may void the user's warranty.

Cables

Connections to this device must be made with shielded cables with metallic RFI/EMI connector hoods to maintain compliance with FCC Rules and Regulations.

Any cables that are supplied with the system must be replaced with identical cables in order to assure compliance with FCC rules. Order Hitachi spares as replacement cables.

Features and Specifications

Features:

- New Easy-to-Use On-Screen Menu Control (3 Language)
- New AV Network System Control
  Control up to 4 components with one remote control 2 IR Mouse cables included
- Illuminated and Preprogrammed Remote Control
- Power Management: ON/OFF via signal detection
- Picture Enhancement
- Input Signal Identification
- CableCARD compatible - Contact your local cable operator for more information
- HDMI (High Definition Multimedia Interface)(High Bandwidth Digital Content Protection V1.1 Compatible)
- Photo Input (for your digital camera, USB drive or memory card USB drive)
- DOLBY DIGITAL® Technology
- TV Guide On Screen™

Video:

- 1024 x 1024 Display Resolution (42")
  1366 x 768 Display Resolution (55")
- ALiS (Alternate Lighting of Surfaces Technology)
- High-Contrast Pure-Color Glass Shield
- Wide Viewing Angle: More than 160˚
- 4 Color Temperature Presets: Black/White-5400K, Standard-6500K, Medium-9300K, High-12000K.
- Multiple Screen Fill Modes
  (4:3 Standard/Expanded/Zoom1/ Zoom2/16:9 Standard/Zoom)[1]
- 4MB 10-bit 3D Y/C Comb Filter
- Picture Modes (Day and Night)

Inputs:

- Power Input . . . . . .AC 120V, 60Hz
- Power Consumption
  - Refer to rear panel at the back of the Plasma Monitor
- Antenna input impedance . . . . . .75 Ohm
- Channel coverage . . . . . 191ch.
  VHF-Band . . . . . 2 ~ 13
  UHF-Band . . . . . 14 ~ 69
  CATV Mid Band . . . . . A-5 ~ A-1
  . . . . . A-I
  Super Band . . . . . J-W
  Hyper Band . . . . . W+1 - W+28
  Ultra Band . . . . . W+29 - W+94
- Video . . . . . 1.0Vp-p, 75 Ohm
- S-Video
  Luminance (Y) . . . . . 1.0Vp-p, 75 Ohm
  Chrominance (C) . . . . . 0.286Vp-p, 75 Ohm
- Component Video
  Luminance (Y) . . . . . 1.0Vp-p, 75 Ohm
  Chrominance (P_B/P_R) . . . . . 0.7Vp-p, 75 Ohm
- Audio input Impedance . . . . . 270k Ohm
- Average input level 470mVrms
- HDMI . . . . . (19 PIN)

Outputs:

- Video1.0Vp-p. 75 Ohm
- Audio . . . . . .470mVrms, 1k Ohm
- Optical Out (Digital Audio) . . . . . .1 Optical Connector

Audio:

- MTS Stereo/SAP
- TruBass
- 40W
- Soft Mute (50%)

Supplied Accessories:

- Remote Control
- Batteries
- 6' AC Cable
- Table Top Stand (only in 42" models)
- IR Mouse Cable (2)
- Cleaning Cloth
- Power Swivel Cable (only in 42" models)
- Ferrite Core (2)

Optional Accessories:

- For U.S. Models: Please access our website: www.hitachi.us/tv

INPUTS/OUTPUTS

- •Wideband Component Y, Pb,Pr 2
- •Composite Video 3
- •S-Video 3
- •Antenna (RF) Inputs 2
- •Audio Output 1
- •Monitor Output 1
- •Optical Output 1
- •IR Blaster 2
- •G-LINK 1
- •CableCARD Slot 1
- •Upgrade Card Slot 1
- •Swivel Output 1
- •Subwoofer Output 1
- •HDMI 2
- •Photo Input 1
- •IEEE 1394/DV Inputs 2

SPECIFICATIONS

- •Pixel Pitch . . 0.90(horiz.) x 0.51(vert.) mm. (42")
  . . . . . 0.90(horiz.) x 0.90(vert.) mm. (55")
- •FCC class: . . . . . B for Consumer Use
- •Power Requirements:. 108-132V, 60Hz

[1] Screen mode availability varies by input format

HDTV Monitors display HDTV when combined with an HDTV Tuner and Source.

All specifications, weights, and dimensions are subject to change without prior notice. Please access www.hitachi.com/tv for detailed specifications and dimensions for custom installations.

UltraVision Digital is a registered trademark of Hitachi Home Electronics (America), Inc.

TruBass, SRS and the ((●)) ® symbol are trademarks of SRS Labs, Inc. TruBass technology is incorporated under license from SRS Labs, Inc.

Licensed by BBE Sound, Inc. under USP5510752 and 5736897. BBE and BBE symbol are registered trademarks of BBE Sound, Inc. Manufactured under license from BBE Sound, Inc.

HDMI™ HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

*Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.

Set Dimensions

42 Inch Models (Includes Table Top Stand) Weight (lbs./kg): 98/44.5



	A	B	C	D	E	F	G	H	I	J	K	L	M	N
Inches	44-5/8	4-1/8	4-1/8	28-11/16	25-1/2	20-1/2	16-1/16	12-15/16	36-7/16	20-11/16	4-1/4	11/16	3-9/16	14-3/16
mm	1134	104	104	728.2	648	520	408.2	328	926	525	107.5	17	90.5	360

55 Inch Models (Plasma Television Only) Weight (lbs./kg): 135.6/61.5



	A	B	C	D	E	F	G	H	I	J	K	L	M	N
Inches	59 7/16	5 7/16	5 7/16	33 1/16	16 5/8	48 3/16	27 3/8	7/8	3 2/8	4 1/8				
mm	1510	138	138	840	422	1234	696	23	82	105				

HITACHI
Inspire the Next

Service Hotline

To locate an authorized **HITACHI** service facility in the continental U.S.A. and Canada,

DIAL TOLL FREE

7 days a week, 24 hours a day

1-800-HITACHI

(1-800-448-2244)

HITACHI AMERICA, LTD.
HOME ELECTRONICS DIVISION

HITACHI has made every effort to assure you hours of trouble free operation from your unit. However, should you require service, a network of **HITACHI** Authorized Service Facilities has been established in all 50 states and Puerto Rico. Each facility will provide you with convenient and expedient assistance. Our service hotline operator will direct you to the **HITACHI** Authorized Service Facility nearest you. Just present proof of purchase and/or delivery receipts to the Hitachi Authorized Service Facility, and service will be rendered in accordance with the terms of the limited warranty as stated on your warranty card or operating guide.

Should you have any questions regarding warranty, service, operation, or technical assistance, please contact:

Hitachi America, LTD.
Home Electronics Division
900 Hitachi Way
Chula Vista, CA 91914-3556

HITACHI CANADA, LTD.
DIGITAL MEDIA DIVISION

Should you have any questions regarding warranty, service, operation, or technical assistance, please contact:

In Canada: 1-800-HITACHI (1-800-448-2244)

Monday – Friday (EST).....9:00am – 7:00pm
Saturday (EST) .....9:00am – 5:00pm

Look for your French Manual on the outside of the box. If the manual is missing, call **1-800-HITACHI (1-800-448-2244)** for a copy.

Pour de plus amples renseignements sur le service durant la période couverte par la garantie, sur le fonctionnement ou pour de l'assistance technique communiquez avec:

Au Canada: 1-800-HITACHI (1-800-448-2244)

Lundi - Vendredi L'EST .....9:00am – 7:00pm
Samedi L'EST.....9:00am – 5:00pm

La version français de votre manual se trouve a l'exterieur de la boîte. Si le manuel est manquant, coposez le **1-800-HITACHI (1-800-448-2244)** pour obenir votre copie.

HITACHI CANADA, LTD.
2495 Meadowpine Blvd.
Mississauga, Ontario L5N 6C3

End User License Agreement for HITACHI DTV Software

END USER LICENSE AGREEMENT FOR HITACHI DTV SOFTWARE

IMPORTANT – READ CAREFULLY: This End User License Agreement for **HITACHI** DTV Software (this "Agreement") is a legal agreement between you ("you" or "your"), in your capacity as the owner of a **HITACHI** brand digital television (the "DTV"), and **HITACHI** America, Ltd., Home Electronics Division ("**HITACHI**"). By using the DTV or the operating system software installed on the DTV (the "System Software") or any Upgrade (as defined below, and together with the System Software, the "Software"), you agree to be bound by the terms and conditions of this Agreement. IF YOU DO NOT AGREE TO BE BOUND BY THIS LICENSE AGREEMENT, DO NOT USE THE DTV OR THE SOFTWARE.

1. **LICENSE GRANT. HITACHI** grants to you, for the life of the DTV, a non-exclusive, non-transferable, revocable license to install and use one copy of the Software on the DTV, subject to the following limitations and restrictions:
   a. You may not share, duplicate, republish or redistribute the Software;
   b. You may not resell, rent, lease, sublicense, gift, loan, assign or otherwise transfer the Software or any of your rights under this Agreement;
   c. You may not modify, adapt, translate, reverse engineer, decompile, disassemble or make derivative works from the Software or use the Software in combination with any non-Hitachi software; and
   d. You may not use the Software for any commercial purpose.

2. **VIOLATIONS; INDEMNITY.** You understand and agree that your use of the Software in any manner except as permitted under this Agreement could constitute a serious crime and could subject you to damages and an award to **HITACHI** of attorneys' fees in connection with your violation of this Agreement. You further understand that you may be held legally responsible for any copyright infringement or other violation of intellectual property rights caused or facilitated by your failure to abide by the terms of this Agreement. You agree to defend, indemnify and hold **HITACHI** and its parent and affiliate companies harmless from and against any and all liability resulting from any breach by you of this Agreement.

3. **INTELLECTUAL PROPERTY.** The Software is protected by federal copyright laws, international copyright treaties and other intellectual property laws and treaties. The Software is licensed, not sold, to you. All right, title and interest in and to the Software and any intellectual property associated therewith, including any accompanying printed materials, shall belong to **HITACHI** and its licensors and suppliers. Except as expressly provided herein, neither **HITACHI** nor any of its licensors or suppliers grants to you under this Agreement any express or implied right in or to any patents, copyrights, trademarks, trade secrets or other intellectual property. All right, title and interest in and to the intellectual property rights associated with any content that is accessible through use of the Software shall belong to the applicable content owners and may be protected by copyright or other intellectual property laws and treaties. This Agreement grants you no rights to use such content. Any rights of **HITACHI** not expressly granted to you hereunder are reserved expressly by Hitachi.

4. **SOFTWARE UPGRADES.** In the future, **HITACHI** may release or make available one or more upgrades to the System Software (each, an "Upgrade"). You understand and agree that if you decide to install or use any Upgrade, your installation and use of such Upgrade and/or any other software or intellectual property **HITACHI** may provide in connection therewith shall be governed by the terms and conditions of this Agreement, except to the extent that **HITACHI** provides different or supplementary license terms or conditions that accompany such Upgrade or other software or intellectual property. In the event **HITACHI** provides you with a "flash card" or other media to effect or facilitate an Upgrade, you understand and acknowledge that your failure to return such flash card or other media to **HITACHI** as **HITACHI** may require could result in **HITACHI** placing your name and your DTV's serial number on a "No Further Upgrades" list, which will prohibit you from receiving any subsequent Upgrades **HITACHI** may later release or make available. IF YOU DO NOT AGREE WITH ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT OR ALL THE TERMS AND CONDITIONS OF ANY DIFFERENT OR SUPPLEMENTARY LICENSE THAT MAY ACCOMPANY SUCH UPGRADE, (A) DO NOT USE ANY HITACHI-PROVIDED FLASH CARD OR OTHER MEDIA, (B) DO NOT PERFORM INSTALL ANY HITACHI-PROVIDED UPGRADE SOFTWARE ON YOUR DTV, AND (C) PROMPTLY RETURN SUCH FLASH CARD OR OTHER MEDIA TO HITACHI.

5. **EXPORT RESTRICTIONS. HITACHI** is licensing the Software for use within North America only. You agree that you will not export or re-export the Software. You specifically agree not to export or re-export the Software: (i) to any country to which the U.S. has embargoed or restricted the export of goods or services, which currently include, but are not necessarily limited to Cuba, Iran, Libya, North Korea, Sudan and Syria, or to any national of any such country, wherever located, who intends to transmit or transport the Software back to such country; (ii) to any person or entity who you know or have reason to know will utilize the Software in the design, development, or production of nuclear, chemical, or biological weapons; or (iii) to any person or entity who has been prohibited from participating in U.S. export transactions by any federal agency of the U.S. government. You warrant and represent that neither the U.S. Bureau of Industry and Security nor any other U.S federal Agency has suspended, revoked, or denied your export privileges.

6. **NO WARRANTIES.** The software is provided to you in "as is" condition and **HITACHI** makes no warranties of any kind whatsoever regarding the software and, to the maximum extent permitted by law, hereby expressly disclaims all warranties of any kind whatsoever, express or implied, with respect to the software. All implied warranties, including without limitation, the implied warranties of non-infringement, merchantability and fitness for a particular purpose are hereby expressly disclaimed by hitachi to the maximum extent permitted by law.

7. **LIMITATION OF LIABILITY.** To the maximum extent permitted by applicable law, **HITACHI**, its licensors, suppliers, parent companies, affiliates, subsidiaries, employees and agents shall not under any circumstances be liable to you or any third parties for any damages of any nature arising in any way from this agreement, your use of the software or otherwise, whether indirect, special, incidental, consequential or otherwise, including, without limitation, any claims for lost profits, lost good will, lost data, business interruption, procurement of substitute goods or services, or expenditures made or committed for in reliance on the continuation of this agreement, even if advised in advance of the possibility of such damages.

8. **NO FAILURE OF ESSENTIAL PURPOSE.** You agree that neither **HITACHI'S** breach of this agreement nor its failure to repair a defect, error or bug in the software shall constitute a failure of the essential purpose of this agreement.

9. **CRYPTOGRAPHIC SOFTWARE.** The software contains software developed by the openssl project, including cryptographic software written by eric young (the "cryptographic software"). The cryptographic software is provided by the openssl project in "as is'' condition and any express or implied warranties, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose are hereby expressly disclaimed to the maximum extent permitted by law. In no event shall the openssl project, its contributors, **HITACHI** or any of its parent or affiliate companies be liable for any direct, indirect, incidental, special, exemplary, or consequential damages (including, but not limited to, procurement of substitute goods or services; loss of use, data, or profits; or business interruption) however caused and on any theory of liability, whether in contract, strict liability, or tort (including negligence or otherwise) arising in any way out of the use of the software or the cryptographic software, even if advised in advance of the possibility of such damages.

10. **TERMINATION. HITACHI** may terminate this Agreement immediately at any time by providing notice to you.

11. **GOVERNING LAW; SEVERABILITY.** This Agreement will be governed by the laws of the State of New York, and you consent to the exclusive jurisdiction and venue in the federal courts sitting in the Southern District of New York, unless no federal subject matter jurisdiction exists, in which case you consent to the exclusive jurisdiction and venue in the Borough of Manhattan, New York, USA.

Appendixes

Appendix A:

IMAGE INPUT

INPUT	TYPE	FORMAT	ASPECT	VIDEO ID	AUTO ASPECT
Air or Cable (Analog Channels)	--	NTSC	4:3	--	On/Off
INPUT 1 & 2	HDMI	480i/480p	16:9	16:9	Off
			Letter	Letter	Off
			4:3	4:3	Off
			--	No Info.	On/Off
INPUT 1-5	S-Video[1] Video	NTSC	16:9	16:9	Off
			Letter	Letter	Off
			4:3	4:3	Off
			--	No Info.	On/Off
INPUT 3 & 4	$Y\text{-}P_bP_r$	480i/480p	16:9	16:9	Off
			Letter	Letter	Off
			4:3	4:3	Off
			--	No Info.	On/Off

[1]S-Video = Not available in INPUT 3 & 4

Appendix B:

IMAGE INPUT

INPUT	TYPE	FORMAT	ASPECT	VIDEO ID	AUTO ASPECT
Air or Cable (Digital Channels)	--	1080i	4:3	--	On/Off
INPUT 1 & 2	HDMI	480i/480p	Letter	Letter	On
			4:3	4:3	On
INPUT 1-5	S-Video[2] Video	NTSC	Letter	Letter	On
			4:3	4:3	On
INPUT 3 & 4	$Y\text{-}P_bP_r$	480i/480p	Letter	Letter	On
			4:3	4:3	On

[2]S-Video = Not available in INPUT 3 & 4

Appendix C:

IMAGE INPUT

INPUT	TYPE	FORMAT	ASPECT	VIDEO ID	AUTO ASPECT
INPUT 1 & 2	HDMI	480i/480p	16:9	16:9	On
INPUT 1-5	S-Video[3] Video	NTSC	16:9	16:9	On
INPUT 3 & 4	$Y\text{-}P_bP_r$	480i/480p	16:9	16:9	On

[3]S-Video = Not available in INPUT 3 & 4

Appendix D:

IMAGE INPUT

INPUT	TYPE	FORMAT	ASPECT	VIDEO ID	AUTO ASPECT
Air or Cable (Digital Channels)	--	1080i	16:9	--	On/Off
INPUT 1 & 2	HDMI	1080i/720p	16:9	--	On/Off
INPUT 3 & 4	$Y\text{-}P_bP_r$	1080i/720p	16:9	--	On/Off

Appendix E

After the CableCARD has been successfully installed, a CableCARD Information menu appears in the **SETUP** menu of the On-Screen Display.

Follow the instructions below to access the CableCARD Information menu.

1. Press the **MENU** button on the Remote Control to access the Main Menu screen.

2. Use the **CURSOR PAD ▼** to highlight **SETUP** in the Main Menu and press the **SELECT** button.

3. Use the **CURSOR PAD ▼** to highlight **CableCARD Information** and press the **SELECT** button.



4. To view the CableCARD ID and Host ID, use the **CURSOR PAD ▼** to highlight **CableCARD Info** and press the **SELECT** button.





NOTE: *The **Diagnostics Info.** window is for Service use only.*

THINGS TO CHECK WHEN USING THE CableCARD / CableCARD Services

1. Check that the CableCARD is properly inserted in the CableCARD slot.

2. Remove the CableCARD by pressing the eject button and pull the CableCARD straight out.

3. Visually inspect the CableCARD to ensure all pin-holes are in good condition, with none blocked or damaged.

4. Make sure the CableCARD is re-inserted in the correct direction, then slowly push until it is fully seated in the slot.

5. When the CableCARD is installed, note all screen messages that appear (“CableCARD Installed”, “Acquiring Data”, “CableCARD is not Installed”). If the “CableCARD Installed” message does not appear when card is installed, check the TV’s card slot and CableCARD pins for obstructions or damage.

6. If problems still remain, please contact your Cable Service Provider.

NOTES:

1. *When a CableCARD is installed, Auto Channel scan will not be needed because the channel list is automatically loaded to the TV's channel memory.*
2. *The TV will take several seconds to detect and recognize the presence of the CableCARD. This process must be completed before any CableCARD information or Channel listings is accessed.*

Index

A

Accessories, ...4
Antennas (Connecting), ...6
Aspect Ratio, ...25, 45
Audio
  TruBass 47
Audio Settings 47-48
Audio Source 48
Auto Noise Cancel 48
A/V Network 21, 79-86

B

Balance 47
Bass 47
Black Enhancement 45
Black Side Panel 46
Brightness 44

C

CableCARD 12, 101
Caution and Safety Tips 2-3
Channel Manager 68-69
  Auto Channel Scan 68
Clock 75
Closed Captions
  Captions 87
Color Temperature 45
Color 44
Contrast 44
Contrast Mode 45

E

External Video Source 16-22

F

Favorite Channel 30
Freeze 8, 33

H

HDMI 17

I

Input Setup 79

L

Language
  Set the Language 77
Locks
  Change Access Code 70
  Set Channel Lock 70
  Front Panel Lock 70
  Movie Ratings 71
  TV Ratings 72
  Canadian Ratings (Eng) 73
  Canadian Ratings (Frn) 74

M

Menu Preference
  Set the Language 77
  Set the Menu Background 78
Monitor Out 88-89

P

Perfect Volume 48
Photo Input 27-28
Picture Mode 44
Picture-in-Picture (PIP) 31-33
Power Swivel 4, 5, 7, 90

R

Remote Control
  Functions 23-41
  Programming Codes 40-41
  Installing Batteries 4

S

Screen Saver 78
Sharpness 44
Speakers 48
  Connecting External Speakers 20
  Internal 48
Split Mode 32

T

Timers 75-76
Tint 44
Treble 47
TV Guide On Screen™ 49-67
  Troubleshooting 93-94

V

Video Settings 44-46

Notes

HITACHI

Inspire the Next

QR64865